

Replacing a failed power supply unit in an H600S series chassis

Each H600S series chassis includes two power supply units for power redundancy. If a power supply unit fails, you must replace it as soon as possible to ensure that the chassis has a redundant power source.


Before you begin

- You have determined that the power supply unit has failed.
- You have a replacement power supply unit.
- You have verified that the redundant power source is operating.
- You have an electrostatic discharge (ESD) wristband, or you have taken other antistatic precautions.

About this task

The instructions apply if you have a one-rack unit (1U) chassis with H600S series storage nodes.

The following illustration shows the back of a chassis with the two power supply units:




1	Power supply units PSU0 is on the right and PSU1 is on the left.
---	---

Steps


1. Locate the failed power supply unit.
The LED on the failed unit displays amber.
2. Unplug the power cord from the power supply unit that you are replacing.

3. Remove the power supply unit as shown in the following illustrations:

- i. Lift the cam handle.




- ii. Press the blue latch and slide the power supply unit out.




Attention: Ensure that you use both hands to support the weight of the power supply unit.

4. Install the replacement as shown in the following illustrations:

- i. Slide the power supply unit into the chassis. Ensure that the blue latch is on the right side when you slide the unit in.



- ii. Push the cam handle down.



Attention: Do not use excessive force when sliding the power supply unit into the chassis to prevent damage to the hardware.

5. Plug in the power cord.
6. Return the failed unit to NetApp by following the instructions in the box that was shipped to you.

Contacting NetApp Support

If you need help with or have questions or comments about NetApp products, contact NetApp Support.

- Web: mysupport.netapp.com

- Phone:
 - 888.4.NETAPP (888.463.8277) (US and Canada)
 - 00.800.44.638277 (EMEA/Europe)
 - +800.800.80.800 (Asia/Pacific)

Where to find additional information

You can learn more about using and managing SolidFire storage systems in NetApp's documentation library.

[*NetApp Element Software Documentation Library*](#)

Includes documentation for various releases of Element software.

[*NetApp SolidFire Resources page*](#)

Provides resources about SolidFire, including links to video content and technical reports.

Copyright information

Copyright © 2018 NetApp, Inc. All rights reserved. Printed in the U.S.

No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

Data contained herein pertains to a commercial item (as defined in FAR 2.101) and is proprietary to NetApp, Inc. The U.S. Government has a non-exclusive, non-transferrable, non-sublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b).

Trademark information

NETAPP, the NETAPP logo, and the marks listed on the NetApp Trademarks page are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.

How to send comments about documentation and receive update notifications

You can help us to improve the quality of our documentation by sending us your feedback. You can receive automatic notification when production-level (GA/FCS) documentation is initially released or important changes are made to existing production-level documents.

If you have suggestions for improving this document, send us your comments by email.

doccomments@netapp.com

To help us direct your comments to the correct division, include in the subject line the product name, version, and operating system.

If you want to be notified automatically when production-level documentation is released or important changes are made to existing production-level documents, follow Twitter account @NetAppDoc.

You can also contact us in the following ways:

- NetApp, Inc., 1395 Crossman Ave., Sunnyvale, CA 94089 U.S.
- Telephone: +1 (408) 822-6000
- Fax: +1 (408) 822-4501
- Support telephone: +1 (888) 463-8277