



NetApp Element 11.1

API Reference Guide

March 2019 | 215-14021_A0
doccomments@netapp.com

Contents

About the Element software API	12
Request object members	12
Response object members	13
Request endpoints	13
API authentication	14
Asynchronous methods	14
Attributes	14
Common objects	16
account	16
bulkVolumeJob	17
binding (virtual volumes)	18
certificateDetails	18
cluster	19
clusterAdmin	20
clusterCapacity	21
clusterInfo	22
clusterPair	24
clusterStats	24
clusterStructure	27
drive	27
driveStats	29
error	30
event	30
fault	32
fibreChannelPort	33
fipsErrorNodeReport	34
fipsNodeReport	35
fipsReport	35
groupSnapshot	35
hardwareInfo	36
host (virtual volumes)	37
initiator	38
ldapConfiguration	38
loggingServer	39
network (bonded interfaces)	40
network (all interfaces)	43
network (Ethernet interfaces)	43
network (local interfaces)	45
network (SNMP)	46
networkInterface	46
node	47

nodeStats	48
ontapVersionInfo	49
pendingActiveNode	50
pendingNode	51
protectionDomainLevel	52
protectionDomainResiliency	53
protectionDomainTolerance	53
protectionSchemeResiliency	54
protectionSchemeTolerance	54
protocolEndpoint	55
QoS	56
QoSPolicy	56
schedule	57
session (Fibre Channel)	59
session (iSCSI)	59
snapMirrorAggregate	61
snapMirrorClusterIdentity	61
snapMirrorEndpoint	62
snapMirrorJobScheduleCronInfo	62
snapMirrorLunInfo	63
snapMirrorNetworkInterface	63
snapMirrorNode	64
snapMirrorPolicy	65
snapMirrorPolicyRule	66
snapMirrorRelationship	66
snapMirrorVolume	69
snapMirrorVolumeInfo	70
snapMirrorVserver	70
snapMirrorVserverAggregateInfo	71
snapshot	72
snmpTrapRecipient	74
storageContainer	74
syncJob	75
task (virtual volumes)	76
usmUser	78
virtualNetwork	78
virtualVolume	79
volume	80
volumeAccessGroup	83
volumePair	84
volumeStats	85
Common methods	89
GetAPI	89
GetAsyncResult	94
GetCompleteStats	96

GetLimits	96
GetOrigin	98
GetRawStats	98
ListAsyncResults	99
Account methods	101
AddAccount	101
GetAccountByID	102
GetAccountByName	103
GetAccountEfficiency	104
ListAccounts	106
ModifyAccount	107
RemoveAccount	109
Administrator API methods	110
AddClusterAdmin	110
GetCurrentClusterAdmin	111
GetLoginBanner	112
ListClusterAdmins	113
ModifyClusterAdmin	114
RemoveClusterAdmin	115
SetLoginBanner	116
Cluster API methods	118
AddNodes	118
ClearClusterFaults	120
CreateClusterInterfacePreference	121
DeleteClusterInterfacePreference	121
DisableEncryptionAtRest	122
EnableEncryptionAtRest	123
EnableFeature	124
GetClusterCapacity	125
GetClusterFullThreshold	127
GetClusterHardwareInfo	130
GetClusterInfo	131
GetClusterInterfacePreference	132
GetClusterMasterNodeID	133
GetClusterStats	133
GetClusterVersionInfo	134
GetFeatureStatus	136
GetLoginSessionInfo	138
GetNodeHardwareInfo	139
GetNodeStats	140
ListActiveNodes	141
ListAllNodes	141
ListClusterFaults	143
ListClusterInterfacePreferences	144
ListEvents	145

ListNodeStats	148
ListISCSISessions	149
ListServices	150
ListPendingNodes	151
ListPendingActiveNodes	153
ModifyClusterFullThreshold	154
ModifyClusterInterfacePreference	159
RemoveNodes	159
SetLoginSessionInfo	160
Shutdown	161
Cluster creation API Methods	163
CheckProposedCluster	163
CreateCluster	164
GetBootstrapConfig	166
Drive API methods	168
AddDrives	168
GetDriveHardwareInfo	169
GetDriveStats	170
ListDrives	172
ListDriveStats	173
RemoveDrives	174
SecureEraseDrives	175
Fibre Channel API methods	177
GetVolumeAccessGroupLunAssignments	177
ListFibreChannelPortInfo	178
ListFibreChannelSessions	180
ListNodeFibreChannelPortInfo	181
ModifyVolumeAccessGroupLunAssignments	183
LDAP API methods	185
AddLdapClusterAdmin	185
EnableLdapAuthentication	186
DisableLdapAuthentication	189
GetLdapConfiguration	189
TestLdapAuthentication	190
Node API methods	192
CheckProposedNodeAdditions	192
CreateClusterSupportBundle	193
CreateSupportBundle	195
DeleteAllSupportBundles	196
DisableSsh	197
EnableSsh	198
GetClusterConfig	198
GetClusterState	199
GetConfig	200
GetDriveConfig	201

GetHardwareConfig	202
GetHardwareInfo	204
GetIpmiConfig	205
GetIpmiInfo	208
GetNetworkConfig	211
GetNetworkInterface	211
GetPendingOperation	214
GetSshInfo	214
ListNetworkInterfaces	215
ListDriveHardware	217
ListTests	218
ListUtilities	219
ResetNode	220
ResetDrives	221
RestartNetworking	222
RestartServices	223
SetClusterConfig	224
SetConfig	225
SetNetworkConfig	227
Shutdown	228
TestConnectEnsemble	229
TestConnectMvip	230
TestConnectSvip	232
TestDrives	234
TestHardwareConfig	235
TestLocateCluster	237
TestLocalConnectivity	238
TestNetworkConfig	239
TestPing	241
TestRemoteConnectivity	243
Replication API methods	246
Cluster pairing order of operations	246
Volume pairing order of operations	246
Supported modes of replication for paired clusters	247
CompleteClusterPairing	247
CompleteVolumePairing	248
ListClusterPairs	249
ListActivePairedVolumes	250
ModifyVolumePair	251
RemoveClusterPair	253
RemoveVolumePair	254
StartClusterPairing	254
StartVolumePairing	255
SnapMirror API methods	258
AbortSnapMirrorRelationship	258

BreakSnapMirrorRelationship	258
BreakSnapMirrorVolume	259
CreateSnapMirrorEndpoint	260
CreateSnapMirrorEndpointUnmanaged	261
CreateSnapMirrorRelationship	261
CreateSnapMirrorVolume	263
DeleteSnapMirrorEndpoints	264
DeleteSnapMirrorRelationships	264
GetOntapVersionInfo	265
GetSnapMirrorClusterIdentity	265
InitializeSnapMirrorRelationship	266
ListSnapMirrorAggregates	267
ListSnapMirrorEndpoints	267
ListSnapMirrorLuns	268
ListSnapMirrorNetworkInterfaces	268
ListSnapMirrorNodes	269
ListSnapMirrorPolicies	270
ListSnapMirrorSchedules	270
ListSnapMirrorRelationships	271
ListSnapMirrorVolumes	272
ListSnapMirrorVservers	273
ModifySnapMirrorEndpoint	274
ModifySnapMirrorEndpoint (unmanaged)	275
ModifySnapMirrorRelationship	275
UpdateSnapMirrorRelationship	276
QuiesceSnapMirrorRelationship	277
ResumeSnapMirrorRelationship	278
ResyncSnapMirrorRelationship	278
System configuration API methods	280
DisableClusterSsh	280
DisableSnmp	281
EnableClusterSsh	281
EnableSnmp	282
GetClusterSshInfo	283
GetClusterStructure	284
GetFipsReport	285
GetLldpConfig	286
GetLldpInfo	287
GetNtpInfo	287
GetNvramInfo	288
GetRemoteLoggingHosts	289
GetSnmpACL	290
GetSnmpInfo	291
GetSnmpState	292
GetSnmpTrapInfo	293

GetNodeSSLCertificate	294
GetSSLCertificate	296
ListProtectionDomainLevels	297
RemoveNodeSSLCertificate	299
RemoveSSLCertificate	299
ResetNetworkConfig	300
SetClusterStructure	300
SetLldpConfig	301
SetNodeSSLCertificate	302
SetNtpInfo	304
SetRemoteLoggingHosts	305
SetSnmpACL	306
SetSnmpInfo	307
SetSnmpTrapInfo	309
SetSSLCertificate	310
SnmpSendTestTraps	312
TestAddressAvailability	312
Multitenant networking API methods	314
Virtual network naming conventions	314
AddVirtualNetwork	314
ModifyVirtualNetwork	317
ListVirtualNetworks	319
RemoveVirtualNetwork	321
Volume API methods	323
AddInitiatorsToVolumeAccessGroup	323
AddVolumesToVolumeAccessGroup	325
CancelClone	326
CancelGroupClone	327
CloneMultipleVolumes	327
CloneVolume	330
CopyVolume	333
CreateQoSPolicy	334
CreateVolume	336
CreateVolumeAccessGroup	339
CreateBackupTarget	341
CreateInitiators	342
DeleteInitiators	344
DeleteQoSPolicy	345
DeleteVolume	346
DeleteVolumes	348
DeleteVolumeAccessGroup	350
GetBackupTarget	351
GetVolumeStats	352
GetDefaultQoS	354
GetQoSPolicy	355

GetVolumeCount	356
GetVolumeAccessGroupEfficiency	356
GetVolumeEfficiency	358
ListActiveVolumes	359
ListBackupTargets	360
ListBulkVolumeJobs	361
ListDeletedVolumes	362
ListInitiators	364
ListQoS Policies	365
ListSyncJobs	366
ListVolumeQoSHistograms	368
ListVolumes	369
ListVolumeStats	372
ListVolumeAccessGroups	374
ListVolumesForAccount	375
ListVolumeStatsByAccount	377
ListVolumeStatsByVirtualVolume	378
ListVolumeStatsByVolume	379
ListVolumeStatsByVolumeAccessGroup	381
ModifyBackupTarget	382
ModifyInitiators	383
ModifyQoS Policy	385
Modify Volume	387
Modify Volumes	391
Modify VolumeAccessGroup	396
PurgeDeletedVolume	398
PurgeDeletedVolumes	399
RemoveBackupTarget	400
RemoveInitiatorsFromVolumeAccessGroup	401
RemoveVolumesFromVolumeAccessGroup	403
RestoreDeletedVolume	405
SetDefaultQoS	405
StartBulkVolumeRead	407
StartBulkVolumeWrite	409
UpdateBulkVolumeStatus	410
Volume snapshot API methods	413
Snapshots overview	413
CreateGroupSnapshot	413
CreateSchedule	416
CreateSnapshot	423
DeleteGroupSnapshot	425
DeleteSnapshot	426
GetSchedule	427
ListGroupSnapshots	428
ListSchedules	430

ListSnapshots	431
ModifyGroupSnapshot	433
ModifySchedule	435
ModifySnapshot	439
RollbackToGroupSnapshot	441
RollbackToSnapshot	443
Virtual volume API methods	446
CreateStorageContainer	446
DeleteStorageContainers	447
GetStorageContainerEfficiency	448
GetVirtualVolumeCount	449
ListProtocolEndpoints	450
ListStorageContainers	451
ListVirtualVolumeBindings	453
ListVirtualVolumeHosts	454
ListVirtualVolumes	455
ListVirtualVolumeTasks	457
ModifyStorageContainer	459
Cluster fault codes	461
Access control	468
Response examples	472
GetConfig	472
GetClusterHardwareInfo	473
GetLldpInfo	482
GetNetworkConfig	501
GetNodeHardwareInfo (output for iSCSI)	504
GetNodeHardwareInfo (output for Fibre Channel nodes)	505
GetNvramInfo	510
ListActiveNodes	516
ListActiveVolumes	518
TestHardwareConfig	524
Contacting NetApp Support	528
Copyright	529
Trademark	530
How to send comments about documentation and receive update notifications	531
Index	532

About the Element software API

The Element API is based on the JSON-RPC protocol over HTTPS. JSON-RPC is a simple text-based RPC protocol based on the lightweight JSON data-interchange format. Client libraries are available for all major programming languages.

You can make API requests via HTTPS POST requests to the API endpoint. The body of the POST request is a JSON-RPC request object. The API does not currently support batch requests (multiple request objects in a single POST). When submitting API requests, you must use "application/json-rpc" as the content-type of the request, and ensure that the body is not form-encoded.

Note: The Element web UI makes use of the API methods described in this document. You can monitor API operations in the UI by enabling the API Log; this enables you to see the methods that are being issued to the system. You can enable both requests and responses to see how the system replies to the methods that are issued.

Unless stated otherwise, all date strings in the API responses are in UTC+0 format.

Note: When the storage cluster is heavily loaded or you submit many consecutive API requests with no intervening delay, a method might fail and return the error "xDBVersionMismatch". If this happens, retry the method call.

Request object members

Each Element software API request has the following basic parts:

Name	Description	Type	Default value	Required
method	Name of the method to be invoked.	string	None	Yes
parameters	Object containing the parameters to the method being invoked. Named parameters are required. Positional parameters (passed as an array) are not allowed.	JSON object	{ }	No
id	Identifier used to match the request to response, returned in the result.	string or integer	{ }	No

Response object members

Each Element software API response body has the following basic parts:

Name	Description	Type
result	The object returned by the method. The system returns an object with named members corresponding to the documented return value for the method. This member is not present if an error has occurred.	JSON object
error	The object returned when an error occurs. This member is present only if an error has occurred.	Object
id	An identifier used to match the request to response, as provided in the request.	string or integer
unusedParameters	A warning message that at least one incorrect parameter has been passed to the API method and has not been used.	Object

Request endpoints

There are three types of request endpoints used in the API (storage cluster, storage cluster creation, and per-node). You should always use the latest endpoint supported by your version of Element software.

The three request endpoints in the API are designated in the following ways:

Cluster API methods

The HTTPS endpoint for storage-cluster-wide API requests is `https://<mvip>/json-rpc/<api-version>`, where:

- `<mvip>` is the management virtual IP address for the storage cluster.
- `<api-version>` is the version of the API you are using.

Cluster creation and bootstrap API methods

The HTTPS endpoint for creating a storage cluster and accessing bootstrap API requests is `https://<nodeIP>/json-rpc/<api-version>`, where:

- `<nodeIP>` is the IP address of the node you are adding to the cluster.
- `<api-version>` is the version of the API you are using.

Per-node API methods

The HTTPS endpoint for individual storage node API requests is `https://<nodeIP>:442/json-rpc/<api-version>`, where:

- `<nodeIP>` is the management IP address of the storage node; 442 is the port the HTTPS server is running on.
- `<api-version>` is the version of the API you are using.

API authentication

You can authenticate with the system when using the API by including an HTTP Basic authentication header with all API requests. If you omit authentication information, the system rejects the unauthenticated request with an HTTP 401 response. The system supports HTTP Basic authentication over TLS.

Use the cluster admin account for API authentication.

Asynchronous methods

Some API methods are asynchronous, which means that the operation they perform might not be complete when the method returns. Asynchronous methods return a handle that you can query to see the status of the operation; status information for some operations might include a percentage of completion.

When you query an asynchronous operation, its result can be one of the following types:

- `DriveAdd`: The system is adding a drive to the cluster.
- `BulkVolume`: The system is performing a copy operation between volumes, such as a backup or restore.
- `Clone`: The system is cloning a volume.
- `DriveRemoval`: The system is copying data from a drive in preparation to remove it from the cluster.
- `RtFIPendingNode`: The system is installing compatible software on a node before adding it to the cluster.

Note the following points when using asynchronous methods or obtaining the status of a running asynchronous operation:

- Asynchronous methods are indicated in the individual method documentation.
- Asynchronous methods return an “`asyncHandle`”, which is a handle that is known by the issuing API method. You can use the handle to poll for the status or result of the asynchronous operation.
- You can obtain the result of individual asynchronous methods with the `GetAsyncResult` method. When you use `GetAsyncResult` to query a completed operation, the system returns the result and automatically purges the result from the system. When you use `GetAsyncResult` to query an incomplete operation, the system returns the result but does not purge it.
- You can obtain the status and results of all running or completed asynchronous methods using the `ListAsyncResults` method. In this case, the system does not purge results for completed operations.

Attributes

Many of the API requests and responses use objects as well as simple types. Objects are a collection of key-value pairs, where the value is a simple type or possibly another object. Attributes are custom

name-value pairs that can be set by the user in JSON objects. Some methods enable you to add attributes when creating or modifying objects.

There is a 1000-byte limit on encoded attribute objects.

Object member

This object contains the following member:

Name	Description	Type
attributes	List of name-value pairs in JSON object format.	JSON object

Request example

The following request example uses the `AddClusterAdmin` method:

```
{
  "method": "AddClusterAdmin",
  "params": {
    "username": "joeadmin",
    "password": "68!5Aru268)$",
    "access": [
      "volume",
      "reporting"
    ],
    "attributes": {
      "name1": "value1",
      "name2": "value2",
      "name3": "value3"
    }
  }
}
```

Common objects

The Element software API uses JSON objects to represent organized data concepts. Many of these API methods make use of these objects for data input and output. This section documents these commonly used objects; objects that are only used within a single method are documented with that method instead of in this section.

account

The `account` object contains information about an account. This object includes only "configured" information about the account, not any runtime or usage information.

Object members

This object contains the following members:

Name	Description	Type
accountID	The unique account ID for the account.	integer
attributes	List of name-value pairs in JSON object format.	JSON object
initiatorSecret	The initiator CHAP secret.	string
status	The current status of the account. Possible values: <ul style="list-style-type: none"> <code>active</code>: An active account. <code>locked</code>: A locked account. <code>removed</code>: An account that has been deleted and purged. 	string
storageContainerID	The unique ID of the virtual volume storage container associated with this account.	UUID
targetSecret	The target CHAP secret.	string
username	The username for the account.	string
volumes	A list of volume IDs for volumes owned by this account.	integer array

Related references

[AddAccount](#) on page 101

[GetAccountByID](#) on page 102

[GetAccountByName](#) on page 103

[ListAccounts](#) on page 106

bulkVolumeJob

The `bulkVolumeJob` object contains information about bulk volume read or write operations, such as cloning or snapshot creation.

Object members

This object contains the following members:

Name	Description	Type
attributes	JSON attribute of the bulk volume job.	JSON object
bulkVolumeID	The internal bulk volume job ID.	integer
createTime	Timestamp created for the bulk volume job in UTC+0 format.	ISO 8601 date string
elapsedTime	The number of seconds since the job began.	string
format	The format of the bulk volume operation. Possible values: <ul style="list-style-type: none"> compressed native 	string
key	The unique key created by the bulk volume session.	string
percentComplete	The completed percentage reported by the operation.	integer
remainingTime	The estimated time remaining in seconds.	integer
srcVolumeID	The source volume ID.	integer
status	The status of the operation. Possible values: <ul style="list-style-type: none"> preparing active done failed 	string
script	The name of the script if one is provided.	string
snapshotID	The ID of the snapshot if a snapshot is in the source of the bulk volume job.	integer
type	The type of bulk operation. Possible values: <ul style="list-style-type: none"> read write 	string

binding (virtual volumes)

The `binding` object contains information about the binding for a virtual volume. You can retrieve a list of this information for all virtual volumes using the `ListVirtualVolumeBindings` API method.

Object members

This object contains the following members:

Name	Description	Type
<code>protocolEndpointID</code>	The unique ID of the protocol endpoint.	UUID
<code>protocolEndpointInBandID</code>	The <code>scsiNAADeviceID</code> of the protocol endpoint.	string
<code>protocolEndpointType</code>	The type of protocol endpoint. SCSI is the only value returned for the protocol endpoint type.	string
<code>virtualVolumeBindingID</code>	The unique ID of the virtual volume binding object.	integer
<code>virtualVolumeHostID</code>	The unique ID of the virtual volume host.	UUID
<code>virtualVolumeID</code>	The unique ID of the virtual volume.	UUID
<code>virtualVolumeSecondaryID</code>	The secondary ID of the virtual volume.	string

Related references

[ListVirtualVolumeBindings](#) on page 453

[protocolEndpoint](#) on page 55

certificateDetails

The `certificateDetails` object contains the decoded information about a security certificate.

Object members

This object contains the following members:

Name	Description	Type
<code>issuer</code>	The name of the issuer.	string
<code>modulus</code>	The modulus of the public key.	string
<code>notAfter</code>	The expiry date of the certificate.	ISO 8601 string
<code>notBefore</code>	The start date of the certificate.	ISO 8601 string
<code>serial</code>	The certificate serial number.	string
<code>sha1Fingerprint</code>	The digest of the DER-encoded version of the certificate.	string
<code>subject</code>	The subject name.	string

cluster

The `cluster` object contains information that the node uses to communicate with the cluster. You can retrieve this information with the `GetClusterConfig` API method.

Object members

This object contains the following members:

Name	Description	Type
<code>cipi</code>	Network interface used for cluster communication.	string
<code>cluster</code>	Unique cluster name.	string
<code>encryptionCapable</code>	Indicates if the node supports drive encryption.	boolean
<code>ensemble</code>	The nodes that are participating in the cluster.	string array
<code>mipi</code>	The network interface used for node management.	string
<code>name</code>	The cluster name.	string
<code>nodeID</code>	The node ID of the node in the cluster.	string
<code>pendingNodeID</code>	The ID of the pending node in the cluster.	integer
<code>role</code>	Identifies the role of the node.	integer
<code>sipi</code>	The network interface used for storage traffic.	string
<code>state</code>	<p>The current state of the node. Possible values:</p> <ul style="list-style-type: none"> <code>Available</code>: The node has not been configured with a cluster name. <code>Pending</code>: The node is pending for a specific named cluster and can be added. <code>Active</code>: The node is an active member of a cluster and cannot be added to another cluster. <code>PendingActive</code>: The node is currently being returned to the factory software image, and is not yet an active member of a cluster. When complete, it will transition to the <code>Active</code> state. 	string
<code>version</code>	The version of software running on the node.	string

Member modifiability and node states

This table indicates whether or not the object parameters can be modified at each possible node state.

Parameter name	Available state	Pending state	Active state
<code>cipi</code>	No	No	No
<code>cluster</code>	Yes	Yes	No
<code>encryptionCapable</code>	No	No	No
<code>ensemble</code>	No	No	No

Parameter name	Available state	Pending state	Active state
mipi	Yes	Yes	No
name	Yes	Yes	Yes
nodeID	No	No	No
pendingNodeID	No	No	No
role	No	No	No
sipi	No	No	No
state	No	No	No
version	No	No	No

Related references

[GetClusterConfig](#) on page 198

clusterAdmin

The `clusterAdmin` object contains information about the current cluster administrator user. You can retrieve admin user information with the `GetCurrentClusterAdmin` API method.

Object members

This object contains the following members:

Name	Description	Type
access	The methods this cluster admin can use.	string array
authMethod	The type of authorization the cluster admin user has. Possible values: <ul style="list-style-type: none"> LDAP Cluster Local 	string
attributes	List of name-value pairs in JSON object format.	JSON object
clusterAdminID	The cluster administrator ID for this cluster admin user.	integer
username	User name for this cluster admin.	string

Related references

[GetCurrentClusterAdmin](#) on page 111

clusterCapacity

The `clusterCapacity` object contains high-level capacity measurements for the cluster. You can get cluster capacity information with the `GetClusterCapacity` API method. Space measurements in the object members are calculated in bytes.

Object members

This object contains the following members:

Name	Description	Type
<code>activeBlockSpace</code>	The amount of space on the block drives. This includes additional information such as metadata entries and space which can be cleaned up.	integer
<code>activeSessions</code>	The number of active iSCSI sessions communicating with the cluster.	integer
<code>averageIOPS</code>	The average IOPS for the cluster since midnight Coordinated Universal Time (UTC).	integer
<code>clusterRecentIOSize</code>	The average size of IOPS to all volumes in the cluster.	integer
<code>currentIOPS</code>	The average IOPS for all volumes in the cluster over the last 5 seconds.	integer
<code>maxIOPS</code>	The estimated maximum IOPS capability of the current cluster.	integer
<code>maxOverProvisionableSpace</code>	The maximum amount of provisionable space. This is a computed value. You cannot create new volumes if the current provisioned space plus the new volume size would exceed this number. The value is calculated as follows: <code>maxOverProvisionableSpace = maxProvisionedSpace * maxMetadataOverProvisionFactor</code>	integer
<code>maxProvisionedSpace</code>	The total amount of provisionable space if all volumes are 100% filled (no thin provisioned metadata).	integer
<code>maxUsedMetadataSpace</code>	The number of bytes on volume drives used to store metadata.	integer
<code>maxUsedSpace</code>	The total amount of space on all active block drives.	integer
<code>nonZeroBlock</code>	The total number of 4KiB blocks that contain data after the last garbage collection operation has completed.	integer
<code>peakActiveSessions</code>	The peak number of iSCSI connections since midnight UTC.	integer
<code>peakIOPS</code>	The highest value for <code>currentIOPS</code> since midnight UTC.	integer

Name	Description	Type
provisionedSpace	The total amount of space provisioned in all volumes on the cluster.	integer
timestamp	The date and time, in UTC+0 format, that this cluster capacity sample was taken.	ISO 8601 string
totalOps	The total number of I/O operations performed throughout the lifetime of the cluster.	integer
uniqueBlocks	The total number of blocks stored on the block drives. The value includes replicated blocks.	integer
uniqueBlocksUsedSpace	The total amount of data the uniqueBlocks take up on the block drives. See the <code>GetClusterCapacity</code> method for information about how this number relates to the uniqueBlocks value.	integer
usedMetadataSpace	The total number of bytes on volume drives used to store metadata.	integer
usedMetadataSpaceInSnapshots	The number of bytes on volume drives used for storing unique data in snapshots. This number provides an estimate of how much metadata space would be regained by deleting all snapshots on the system.	integer
usedSpace	The total amount of space used by all block drives in the system.	integer
zeroBlocks	The total number of empty 4KiB blocks without data after the last round of garbage collection operation has completed.	integer

Related references

[GetClusterCapacity](#) on page 125

clusterInfo

The `clusterInfo` object contains information that the node uses to communicate with the cluster. You can get this information with the `GetClusterInfo` API method.

Object members

This object contains the following members:

Name	Description	Type
attributes	List of name-value pairs in JSON object format.	JSON object
defaultProtectionScheme	The protection scheme used by default for new volumes, unless a protection scheme is provided with the Create Volume method call.	string
enabledProtectionSchemes	A list of all protection schemes that have been enabled on this storage cluster.	string array

Name	Description	Type
encryptionAtRestState	<p>The state of the Encryption at Rest feature. Possible values:</p> <ul style="list-style-type: none"> Enabling: Encryption at rest is being enabled. Enabled: Encryption at rest is enabled. Disabling: Encryption at rest is being disabled. Disabled: Encryption at rest is disabled. 	string
ensemble	The nodes that are participating in the cluster.	string array
mvip	The floating (virtual) IP address for the cluster on the management network.	string
mvipInterface	The physical interface associated with the MVIP address.	string
mvipNodeID	The node that holds the master MVIP address.	string
mvipVlanTag	The VLAN identifier for the MVIP address.	string
name	The unique cluster name.	string
repCount	The number of replicas of each piece of data to store in the cluster. The valid value is "2".	integer
supportedProtectionSchemes	A list of all protection schemes that are supported on this storage cluster.	string array
svip	The floating (virtual) IP address for the cluster on the storage (iSCSI) network.	string
svipInterface	The physical interface associated with the master SVIP address.	string
svipNodeID	The node holding the master SVIP address.	string
svipVlanTag	The VLAN identifier for the master SVIP address.	string
uniqueID	The unique ID for the cluster.	string
uuid	The unique identifier for the cluster.	string

Related references

[GetClusterInfo](#) on page 131

clusterPair

The `clusterPair` object contains information about clusters paired with the local cluster. You can retrieve a list of `clusterPair` objects for the local cluster with the `ListClusterPairs` method.

Object members

This object contains the following members:

Name	Description	Type
clusterName	The name of the other cluster in the pair.	string
clusterPairID	A unique ID given to each cluster in the pair.	integer
clusterPairUUID	The universally unique identifier for the cluster pair.	string
UUID	Unique identifier for the remote cluster in the cluster pair.	integer
latency	The latency, in milliseconds, between clusters.	integer
mvip	The IP address of the management connection for paired clusters.	string
status	The status of the connection between the paired clusters. Possible values: <ul style="list-style-type: none"> Unconfigured Connected Misconfigured Disconnected 	string
version	The Element version of the other cluster in the pair.	string

Related references

[ListClusterPairs](#) on page 249

clusterStats

The `clusterStats` object contains statistical data for a cluster. Many of the volume-related statistics contained in the object are averaged for all volumes in the cluster. You can use the `GetClusterStats` method to retrieve this information for a cluster.

Object members

This object contains the following members:

Name	Description	Calculation	Type
actualIOPS	Current actual IOPS for the entire cluster in the last 500 milliseconds.	Point in time	integer

Name	Description	Calculation	Type
averageIOPSize	Average size in bytes of recent I/O to the cluster in the last 500 milliseconds.	Point in time	integer
clientQueueDepth	The number of outstanding read and write operations to the cluster.	N/A	integer
clusterUtilization	The cluster capacity being utilized.	N/A	float
latencyUsec	The average time, in microseconds, to complete operations to a cluster in the last 500 milliseconds.	Point in time	integer
normalizedIOPS	Average number of IOPS for the entire cluster in the last 500 milliseconds.	Point in time	integer
readBytes	The total cumulative bytes read from the cluster since the creation of the cluster.	Monotonically increasing	integer
readBytesLastSample	The total number of bytes read from the cluster during the last sample period.	Point in time	integer
readLatencyUsec	The average time, in microseconds, to complete read operations to the cluster in the last 500 milliseconds.	Point in time	integer
readLatencyUsecTotal	The total time spent performing read operations since the creation of the cluster.	Monotonically increasing	integer
readOps	The total cumulative read operations to the cluster since the creation of the cluster.	Monotonically increasing	integer
readOpsLastSample	The total number of read operations during the last sample period.	Point in time	integer
samplePeriodMsec	The length of the sample period, in milliseconds.	N/A	integer
servicesCount	The number of services running on the cluster. If equal to the servicesTotal, this indicates that valid statistics were collected from all nodes.	Point in time	integer

Name	Description	Calculation	Type
servicesTotal	The total number of expected services running on the cluster.	N/A	integer
timestamp	The current time in UTC +0 format.	N/A	ISO 8601 date string
unalignedReads	The total cumulative unaligned read operations to a cluster since the creation of the cluster.	Monotonically increasing	integer
unalignedWrites	The total cumulative unaligned write operations to a cluster since the creation of the cluster.	Monotonically increasing	integer
writeBytes	The total cumulative bytes written to the cluster since the creation of the cluster.	Monotonically increasing	integer
writeBytesLastSample	The total number of bytes written to the cluster during the last sample period.	Monotonically increasing	integer
writeLatencyUsec	The average time, in microseconds, to complete write operations to a cluster in the last 500 milliseconds.	Point in time	integer
writeLatencyUsecTotal	The total time spent performing write operations since the creation of the cluster.	Monotonically increasing	integer
writeOps	The total cumulative write operations to the cluster since the creation of the cluster.	Monotonically increasing	integer
writeOpsLastSample	The total number of write operations during the last sample period.	Point in time	integer

Related references

[GetClusterStats](#) on page 133

clusterStructure

The `clusterStructure` object holds cluster configuration backup information created by the `GetClusterStructure` method. You can use the `SetClusterStructure` method to restore this information to a storage cluster you are rebuilding.

Object members

This object contains the combined return information from the following methods:

- [*GetClusterInfo*](#)
- [*ListAccounts*](#)
- [*ListInitiators*](#)
- [*ListVolumes*](#) (with `includeVirtualVolumes=false`)
- [*ListVolumeAccessGroups*](#)
- [*ListStorageContainers*](#)
- [*ListQoS Policies*](#)
- [*GetSnmpInfo*](#)
- [*GetNtpInfo*](#)
- [*ListVirtualNetworks*](#)
- [*ListClusterAdmins*](#)
- [*ListSchedules*](#)
- [*ListSnapMirrorEndpoints*](#)
- [*GetFeatureStatus*](#)
- [*GetLdapConfiguration*](#)
- [*GetRemoteLoggingHosts*](#)
- [*GetDefaultQoS*](#)
- [*GetVolumeAccessGroupLunAssignments*](#)

Related references

[*GetClusterStructure*](#) on page 284

[*SetClusterStructure*](#) on page 300

drive

The `drive` object contains information about individual drives in the cluster's active nodes. This object contains details on drives that have been added as volume metadata or block drives, as well as

drives that have not yet been added and are available. You can retrieve this information with the `ListDrives` API method.

Object members

This object contains the following members:

Name	Description	Type
attributes	List of name-value pairs in JSON object format. This object is always null and is not modifiable.	JSON object
capacity	The total capacity of the drive, in bytes.	integer
chassisSlot	For HCI platforms, this value is the node letter and slot number in the server chassis where this drive is located. For storage platforms, the slot number is a string representation of the "slot" integer.	string
driveID	The ID of this drive.	integer
nodeID	The ID of the node containing this drive.	integer
segmentFileSiz e	The segment file size of the drive, in bytes.	integer
serial	The drive serial number.	string
slot	The slot number in the server chassis where this drive is located, or -1 if a SATADimm device is used for the internal metadata drive.	integer
status	The status of the drive. Possible values: <ul style="list-style-type: none"> • <code>available</code>: An available drive. • <code>active</code>: An active drive. • <code>erasing</code>: A drive is in the process of being secure erased. Any data on that drive is permanently removed. • <code>failed</code>: A drive that has failed. Any data that was previously on the drive has been migrated to other drives in the cluster. • <code>removing</code>: A drive is in the process of being removed. Any data previously on the drive is being migrated to other drives in the cluster. 	string
type	The type of drive. Possible values: <ul style="list-style-type: none"> • <code>volume</code>: Stores volume metadata. • <code>block</code>: Stores block data. • <code>unknown</code>: Drive type not yet active and is yet to be determined. 	string
usableCapacity	The usable capacity of the drive, in bytes.	integer

Related references

[ListDrives](#) on page 172

driveStats

The `driveStats` object contains high-level activity measurements for a single drive. You can retrieve measurement information with the API method `GetDriveStats`.

Object members

This object contains the following members:

Name	Description	Type
<code>activeSessions</code>	Number of iSCSI sessions currently using this drive (only present for metadata drives).	integer
<code>driveID</code>	Unique ID of the drive in the cluster.	integer
<code>failedDieCount</code>	Number of failed drive hardware elements.	integer
<code>lifeRemainingPercent</code>	Drive media wear out indicator.	integer
<code>lifetimeReadBytes</code>	Total bytes read from this drive for the lifetime of the drive.	integer
<code>lifetimeWriteBytes</code>	Total bytes written to this drive for the lifetime of the drive.	integer
<code>powerOnHours</code>	Number of hours this drive has been powered on.	integer
<code>readBytes</code>	Total bytes read from the drive due to client operations.	integer
<code>readOps</code>	Total read operations on the drive due to client operations.	integer
<code>reallocatedSectors</code>	Number of bad sectors replaced in this drive.	integer
<code>reserveCapacityPercent</code>	The available reserve capacity of the drive.	integer
<code>timestamp</code>	The current time in UTC+0 format.	ISO 8601 date string
<code>totalCapacity</code>	Total capacity of the drive, in bytes.	integer
<code>uncorrectableErrors</code>	The Reported Uncorrectable Errors value from the Self-Monitoring, Analysis and Reporting Technology (SMART) monitoring system in the drive.	integer
<code>usedCapacity</code>	Used capacity of the drive, in bytes.	integer
<code>usedMemory</code>	Amount of memory currently used by the node hosting this drive.	integer
<code>writeBytes</code>	Total bytes written to the drive due to client activity.	integer
<code>writeOps</code>	Total write operations to the drive due to client activity.	integer

Related references

[GetDriveStats](#) on page 170

error

The `error` object contains an error code and message if an error occurs during a method call. All system-generated errors have an error code of 500.

Object members

This object contains the following members:

Name	Description	Type
code	The numeric code used to identify the error. All system-generated errors return a code of 500.	integer
name	The unique identifier for the specific error that occurred. Each method returns a documented set of errors, although you should be prepared to handle unrecognized errors as well.	string
message	A description of the error, possibly with additional details.	string

event

The `event` object contains details of events that occur during an API method call or while the system is performing an operation.

Object members

This object contains the following members:

Name	Description	Type
details	Extra information about the event.	JSON object
driveID	The driveID of the drive reporting the failure. 0 if not applicable.	integer
driveIDs	A list of the driveIDs of the drives reporting the failure. An empty list if not applicable.	integer array
eventID	Unique ID associated with each event.	integer
eventInfoType	The type of fault.	string
message	A string description of the event that occurred.	string
nodeID	The nodeID of the node reporting the failure. 0 if not applicable.	integer
serviceID	The serviceID of the service reporting the failure. 0 if not applicable.	integer
severity	Severity the event is reporting.	integer
timeOfPublish	The time at which the cluster's event log received the event, in UTC+0 format.	ISO 8601 date string
timeOfReport	The time at which the event occurred on the cluster, in UTC+0 format.	ISO 8601 date string

Note: There might be a slight difference between `timeOfReport` and `timeOfPublish` if the event occurred and was not able to be immediately published.

Event types

The following list describes the possible event types that the `eventInfoType` member can contain:

- `apiEvent`: Events initiated through the API or web UI that modify settings.
- `binAssignmentsEvent`: Events related to the assignment of data to internal containers.
- `binSyncEvent`: Events related to a reassignment of data among block services.
- `bsCheckEvent`: Events related to block service checks.
- `bsKillEvent`: Events related to block service terminations.
- `bulkOpEvent`: Events that operate on an entire volume, such as a volume backup, restore, snapshot, or clone.
- `cloneEvent`: Events related to volume cloning.
- `clusterMasterEvent`: Cluster configuration change events such as adding or removing nodes.
- `dataEvent`: Events related to reading and writing data.
- `dbEvent`: Events related to the ensemble node database.
- `driveEvent`: Events related to drive operations.
- `encryptionAtRestEvent`: Events related to stored data encryption.
- `ensembleEvent`: Events related to ensemble size increase or decrease.
- `fibreChannelEvent`: Events related to Fibre Channel node configuration or connections.
- `gcEvent`: Events related to garbage collection. These processes run every 60 minutes to reclaim storage on block drives.
- `ieEvent`: Events related to internal system errors.
- `installEvent`: Events related to automatic software installation on pending storage nodes.
- `iSCSIEvent`: Events related to iSCSI connection or configuration issues.
- `limitEvent`: Events related to the number of volumes or virtual volumes in an account or in the cluster nearing the maximum allowed.
- `networkEvent`: Events related to virtual networking.
- `platformHardwareEvent`: Events related to issues detected on hardware devices.
- `remoteClusterEvent`: Events related to remote cluster pairing.
- `schedulerEvent`: Events related to scheduled snapshots.
- `serviceEvent`: Events related to system service status.
- `statEvent`: Events related to system statistics.
- `sliceEvent`: Events related to metadata storage.
- `snmpTrapEvent`: Events related to SNMP traps.
- `tsEvent`: System transport service events.

- `unexpectedException`: Events related to unexpected errors.
- `vasaProviderEvent`: Events related to a VMware VASA provider.

Related references

[ListEvents](#) on page 145

fault

The `fault` object contains information about faults that are detected in the cluster. The `ListClusterFaults` method returns cluster fault information.

Object members

This object contains the following members:

Name	Description	Type
<code>clusterFaultID</code>	The unique ID associated with each cluster fault.	integer
<code>code</code>	The fault code for the specific fault that was detected. For further details, see Cluster Fault Codes.	string
<code>data</code>	Additional fault-specific information.	JSON object
<code>date</code>	The current time in UTC+0 format.	ISO 8601 string
<code>details</code>	The description of the fault with additional details.	string
<code>driveID</code>	The first drive ID in the <code>driveIDs</code> list. If the <code>driveIDs</code> list is empty (which means that no faults were returned that deal with drives), this value is 0.	integer
<code>driveIDs</code>	A list of <code>driveID</code> values for the drives that this fault refers to. Included for faults dealing with drives. If none, this is an empty array.	integer array
<code>nodeHardwareFaultID</code>	The identifier assigned to a hardware fault on the cluster.	integer
<code>nodeID</code>	The node ID for the node that this fault refers to. Included for node and drive faults, otherwise set to 0.	integer
<code>resolved</code>	The resolved status of the fault. Possible values: <ul style="list-style-type: none"> • <code>true</code>: The fault is no longer detected. • <code>false</code>: The fault is still present. 	boolean
<code>resolvedDate</code>	The date and time the fault was resolved.	ISO 8601 string
<code>serviceID</code>	The service associated with the fault. This value is "0" (zero) if the fault is not associated with a service.	integer

Name	Description	Type
severity	<p>The severity of the fault. Possible values:</p> <ul style="list-style-type: none"> <code>warning</code>: A minor issue. The cluster is functioning and upgrades are allowed at this severity level. <code>error</code>: A failure that generally should not affect service (except possible performance degradation or loss of HA). Some features might be disabled. <code>critical</code>: A serious failure that is affecting service. The system is unable to serve API requests or client I/O and is at risk of data loss. <code>bestPractice</code>: Faults triggered by sub-optimal system configuration. 	string
type	<p>The type of fault. Possible values:</p> <ul style="list-style-type: none"> <code>node</code>: A fault affecting an entire node. <code>drive</code>: A fault affecting an individual drive. <code>cluster</code>: A fault affecting the entire cluster. <code>service</code>: A fault affecting a service on the cluster. <code>volume</code>: A fault affecting an individual volume. 	string

Related references

[ListClusterFaults](#) on page 143

[Cluster fault codes](#) on page 461

fibreChannelPort

The `fibreChannelPort` object contains information about individual ports on a node, or for an entire node in the cluster. You can retrieve this information using the `ListNodeFibreChannelPortInfo` method.

Object members

This object contains the following members:

Name	Description	Type
firmware	The version of the firmware installed on the Fibre Channel port.	integer
hbaPort	The ID of the individual host bus adapter (HBA) port.	integer

Name	Description	Type
model	Model of the HBA on the port.	string
nPortID	The unique port node ID.	string
pciSlot	The slot containing the PCI card in the Fibre Channel node chassis.	integer
serial	The serial number on the Fibre Channel port.	string
speed	The speed of the HBA on the port.	string
state	Possible values: <ul style="list-style-type: none"> Unknown NotPresent Online Offline Blocked Bypassed Diagnostics Linkdown Error Loopback Deleted 	string
switchWwn	The World Wide Name of the Fibre Channel switch port.	string
wwnn	World Wide Node Name of the HBA node.	string
wwpn	World Wide Port Name assigned to the physical port of the HBA.	string

Related references

[ListNodeFibreChannelPortInfo](#) on page 181

fipsErrorNodeReport

The `fipsErrorNodeReport` object contains error information for each node that does not respond with information about FIPS 140-2 support when you query it with the `GetFipsReport` method.

Object members

This object contains the following members:

Name	Description	Type
nodeID	The ID of the node that did not respond.	integer
error	A JSON object containing error information.	JSON object

fipsNodeReport

The `fipsNodeReport` object contains information about FIPS 140-2 support for a single node in the storage cluster. You can retrieve this information using the `GetFipsReport` method.

Object members

This object contains the following members:

Name	Description	Type
<code>nodeID</code>	The ID of the node reporting the information.	integer
<code>httpsEnabled</code>	Whether or not FIPS 140-2 HTTPS encryption is enabled for this node. Possible values: <ul style="list-style-type: none"> <code>true</code>: enabled <code>false</code>: disabled 	boolean

fipsReport

The `fipsReport` object contains information about FIPS 140-2 support for all nodes in the storage cluster. You can retrieve this information using the `GetFipsReport` method.

Object members

This object contains the following members:

Name	Description	Type
<code>nodes</code>	A report on FIPS 140-2 support status for each node in the storage cluster.	JSON object array
<code>errorNodes</code>	Error information for each node that did not respond with FIPS 140-2 support status.	JSON object array

groupSnapshot

The `groupSnapshot` object contains information about a snapshot for a group of volumes. You can use the `ListGroupSnapshots` API method to retrieve group snapshot information.

Object members

This object contains the following members:

Name	Description	Type
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object
<code>createTime</code>	The UTC+0 formatted day and time on which the group snapshot was created.	ISO 8601 date string
<code>groupSnapshotID</code>	The unique ID of the group snapshot.	integer
<code>groupSnapshotUUID</code>	The UUID of the group snapshot.	string

Name	Description	Type
members	An array of objects containing information about each member of the group snapshot.	<i>snapshot</i> array
name	The name of the group snapshot, or, if none was given, the UTC formatted day and time on which the snapshot was created.	string or ISO 8601 date string
status	The current status of the snapshot. Members: <ul style="list-style-type: none"> Preparing: A snapshot that is being prepared for use and is not yet writable. Done: A snapshot that has finished preparation and is now usable. 	string

Related references

[ListGroupSnapshots](#) on page 428

hardwareInfo

The `hardwareInfo` object contains detailed information about the hardware and status of each node in the cluster. You can retrieve this information with the `GetHardwareInfo` API method.

Object members

This object contains the following members:

Name	Description	Type
boardSerial	The DMI board serial number.	string
bus	Motherboard media bus information.	JSON object
chassisSerial	The serial number of the chassis.	string
driveHardware	A list of information for each drive in the node.	JSON object array
fibreChannelPorts	A list of Fibre Channel ports on the node.	integer array
hardwareConfig	Motherboard peripheral configuration information.	JSON object
kernelCrashDumpState	The crash dump configuration of the operating system kernel.	string
memory	Firmware and system memory hardware information.	JSON object
network	Descriptions of the hardware of each of the node's network interfaces.	JSON object
networkInterfaces	The status of the node's network interfaces.	JSON object
nodeSlot	For HCI platforms, the letter corresponding to the chassis slot this node is in ("A", "B", "C", or "D"). For storage platforms, this value is null.	string

Name	Description	Type
nvrAm	NVRAM statistics for the node.	JSON object
origin	The vendor of the motherboard.	string
platform	A description of the chassis platform.	JSON object
serial	The serial number of the product.	string
storage	Storage controller information.	JSON object
systemMemory	Operating system memory usage and performance information.	JSON object
system	The type of node chassis.	JSON object
uuid	The unique ID of the node.	UUID

Related references

[GetHardwareInfo](#) on page 204

host (virtual volumes)

The `host` object contains information about a virtual volume host. You can use the `ListVirtualVolumeHosts` method to get this information for all virtual volume hosts.

Object members

This object contains the following members:

Name	Description	Type
bindings	A list of objects describing the bindings for the virtual volume host.	integer array
clusterID	The unique ID of the cluster this host is associated with.	UUID
hostAddress	The IP address or DNS name of the virtual volume host.	string
initiatorNames	A list of initiator IQNs for the virtual volume host.	string array
virtualVolumeHostID	The unique ID of this virtual volume host.	UUID
visibleProtocolEndpointIDs	A list of IDs of protocol endpoints visible on this host.	UUID array

Related references

[ListVirtualVolumeHosts](#) on page 454

initiator

The `initiator` object contains information about an iSCSI or Fibre Channel initiator. An initiator object can contain IQN or WWPN identifiers. You can use the `ListInitiators` method to get a list of all initiators known on the system.

Object members

This object contains the following members:

Name	Description	Type
alias	The friendly name assigned to the initiator, if any.	string
attributes	A set of JSON attributes assigned to this initiator. Empty if no attributes are assigned.	JSON object
initiatorID	The identifier for the initiator.	integer
initiatorName	The initiator name, in IQN or WWPN format.	string
volumeAccessGroups	A list of volume access group IDs that this initiator belongs to.	integer array

Related references

[ListInitiators](#) on page 364

LdapConfiguration

The `ldapConfiguration` object contains information about the LDAP configuration on the storage system. You can retrieve LDAP information with the `GetLdapConfiguration` API method.

Object members

This object contains the following members:

Name	Description	Type
authType	Identifies which user authentication method to use. Possible values: <ul style="list-style-type: none">DirectBindSearchAndBind	string
enabled	Identifies whether or not the system is configured for LDAP. Possible values: <ul style="list-style-type: none">truefalse	boolean

Name	Description	Type
groupSearchBaseDN	The base DN of the tree to start the group search (the system will perform a subtree search from here).	string
groupSearchCustomFilter	The custom search filter used.	string
groupSearchType	Controls the default group search filter used. Possible values: <ul style="list-style-type: none"> NoGroups: No group support. ActiveDirectory: Nested membership of all of a user's AD groups. MemberDN: MemberDN style groups (single-level). 	string
searchBindDN	A fully qualified DN to log in with to perform an LDAP search for the user (needs read access to the LDAP directory).	string
serverURIs	A comma-separated list of LDAP server URIs (for example, <code>ldap://1.2.3.4</code> and <code>ldaps://1.2.3.4:123</code> .)	string
userDNTemplate	A string that is used to form a fully qualified user DN.	string
userSearchBaseDN	The base DN of the tree used to start the search (will do a subtree search from here).	string
userSearchFilter	The LDAP filter used.	string

Related references

[GetLdapConfiguration](#) on page 189

loggingServer

The `loggingServer` object contains information about any logging hosts configured for the storage cluster. You can use `GetRemoteLoggingHosts` to determine what the current logging hosts are and then use `SetRemoteLoggingHosts` to set the desired list of current and new logging hosts.

Object members

This object contains the following members:

Name	Description	Type
host	IP address of the log server.	string
port	Port number used to communicate with the log server.	integer

network (bonded interfaces)

The `network` (bonded interfaces) object contains configuration information for bonded network interfaces on a storage node. You can use the `GetConfig` and `GetNetworkConfig` methods to obtain this information for a storage node.

Object members

This object contains the following members:

Name	Description	Type
address	The IPv4 address assigned to this interface on the node.	string
addressV6	The IPv6 management address assigned to the Bond1G interface on the node.	string
bond-downdelay	Time to wait before disabling a slave after a link failure has been detected.	string
bond-fail_over_mac	The configuration of the MAC address of the network interface.	string
bond-miimon	How often the MII link state is inspected for link failures.	integer
bond-mode	The bonding mode. Possible values: <ul style="list-style-type: none"> ActivePassive (Default) ALB LACP (Recommended) 	string
bond-primary_reselect	Specifies when the primary bond slave is chosen as the active slave. Possible values: <ul style="list-style-type: none"> Always Better Failure 	string
bond-slaves	The list of slave interfaces for the bond.	string
bond-lacp_rate	When Bond Mode is LACP, the rate may change to one of the following: <ul style="list-style-type: none"> LACP Fast (Default) LACP Slow 	integer
bond-updelay	The time to wait before enabling a slave after a link is detected.	integer
dns-nameservers	A list of addresses used for domain name services, separated by comma or space.	string
dns-search	A space or comma separated list of DNS search domains.	string

Name	Description	Type
family	Address family that the interface is configured to use. Currently "inet" for IPv4 is supported.	string
gateway	The IPv4 router network address used to send traffic from the local network.	string
gatewayV6	The IPv6 router network address used to send traffic from the local Bond1G network.	string
ipV6PrefixLength	The subnet prefix length for static routes of type "net" for IPv6 traffic on the Bond1G network.	string
macAddress	The actual MAC address assigned to the interface and observed by the network.	string
macAddressPermanent	The immutable MAC address assigned by the manufacturer to the interface.	string
method	<p>The method used to configure the interface. Possible values:</p> <ul style="list-style-type: none"> • <code>Loopback</code>: Used to define the IPv4 loopback interface. • <code>manual</code>: Used to define interfaces that are not configured automatically. • <code>dhcp</code>: Can be used to obtain an IP address via DHCP. • <code>static</code>: Used to define Ethernet interfaces with statically allocated IPv4 addresses. 	string
mtu	The largest packet size (in bytes) that the interface can transmit. Must be greater than or equal to 1500; up to 9000 is supported.	string
netmask	The bitmask that specifies the subnet for the interface.	string
network	Indicates where the IP address range begins based on the netmask.	string
routes	Comma separated array of route strings to apply to the routing table.	string array
status	<p>The state of the interface. Possible values:</p> <ul style="list-style-type: none"> • <code>Down</code>: The interface is inactive. • <code>Up</code>: The interface is ready, but has no link. • <code>UpAndRunning</code>: The interface is ready and a link is established. 	string
symmetricRouteRules	The symmetric routing rules configured on the node.	string array
upAndRunning	Indicates if the interface is ready and has a link.	boolean
virtualNetworkTag	The virtual network identifier of the interface (VLAN tag).	string

Member modifiability and node states

This table indicates whether or not the object parameters can be modified at each possible node state.

Member name	Available state	Pending state	Active state
address	Yes	Yes	No
addressV6	Yes	Yes	No
bond-downdelay	Configured by the system	N/A	N/A
bond-fail_over_mac	Configured by the system	N/A	N/A
bond-miimon	Configured by the system	N/A	N/A
bond-mode	Yes	Yes	Yes
bond-primary_reselect	Configured by the system	N/A	N/A
bond-slaves	Configured by the system	N/A	N/A
bond-lacp_rate	Yes	Yes	Yes
bond-updelay	Configured by the system	N/A	N/A
dns-nameservers	Yes	Yes	Yes
dns-search	Yes	Yes	Yes
family	No	No	No
gateway	Yes	Yes	Yes
gatewayV6	Yes	Yes	Yes
ipV6PrefixLength	Yes	Yes	Yes
macAddress	Configured by the system	N/A	N/A
macAddressPermanent	Configured by the system	N/A	N/A
method	No	No	No
mtu	Yes	Yes	Yes
netmask	Yes	Yes	Yes
network	No	No	No
routes	Yes	Yes	Yes
status	Yes	Yes	Yes
symmetricRouteRules	Configured by the system	N/A	N/A
upAndRunning	Configured by the system	N/A	N/A
virtualNetworkTag	Yes	Yes	Yes

Related references

[GetConfig](#) on page 200

[GetNetworkConfig](#) on page 211

network (all interfaces)

The `network (all interfaces)` object collects information about network interface configuration for a storage node. You can use the `GetConfig` and `GetNetworkConfig` methods to obtain this information for a storage node.

Object members

This object contains the following members:

Name	Description	Type
Bond10G	Configuration information for the Bond10G bonded interface.	network (bonded interfaces)
Bond1G	Configuration information for the Bond1G bonded interface.	network (bonded interfaces)
eth0-5	One object for each Ethernet interface in the storage node, describing configuration information for the interface. These objects are numbered 0 through 5 to match the interface name.	network (Ethernet interfaces)
lo	Configuration information for the loopback interface.	network (local interfaces)

Related references

[GetConfig](#) on page 200

[GetNetworkConfig](#) on page 211

network (Ethernet interfaces)

The `network (Ethernet interfaces)` object contains configuration information for individual Ethernet interfaces. You can use the `GetConfig` and `GetNetworkConfig` methods to obtain this information for a storage node.

Object members

This object contains the following members:

Name	Description	Type
bond-master	Specifies which bonded interface this physical interface join as a bond slave.	string
family	Address family that the interface is configured to use. Currently "inet" for IPv4 is supported.	string
macAddress	The actual MAC address assigned to the interface and observed by the network.	string

Name	Description	Type
macAddressPermanent	The immutable MAC address assigned by the manufacturer to the interface.	string
method	<p>The method used to configure the interface. Possible values:</p> <ul style="list-style-type: none"> • <code>loopback</code>: Used to define the IPv4 loopback interface. • <code>manual</code>: Used to define interfaces that are not configured automatically. • <code>dhcp</code>: Can be used to obtain an IP address via DHCP. • <code>static</code>: Used to define Ethernet interfaces with statically allocated IPv4 addresses. 	string
status	<p>The state of the interface. Possible values:</p> <ul style="list-style-type: none"> • <code>Down</code>: The interface is inactive. • <code>Up</code>: The interface is ready, but has no link. • <code>UpAndRunning</code>: The interface is ready and a link is established. 	string
upAndRunning	(boolean) Indicates if the interface is ready and has a link.	boolean

Member modifiability and node states

This table indicates whether or not the object parameters can be modified at each possible node state.

Parameter name	Available state	Pending state	Active state
bond-master	No	No	No
family	No	No	No
macAddress	Configured by system	N/A	N/A
macAddressPermanent	Configured by system	N/A	N/A
method	No	No	No
status	Yes	Yes	Yes
upAndRunning	Configured by system	N/A	N/A

Related references

[GetConfig](#) on page 200

[GetNetworkConfig](#) on page 211

network (local interfaces)

The `network (local interfaces)` object contains configuration information for local network interfaces, such as the loopback interface, on a storage node. You can use the `GetConfig` and `GetNetworkConfig` methods to obtain this information for a storage node.

Object members

This object contains the following members:

Name	Description	Type
<code>family</code>	Address family that the interface is configured to use. Currently "inet" for IPv4 is supported.	string
<code>macAddress</code>	The actual MAC address assigned to the interface and observed by the network.	string
<code>macAddressPermanent</code>	The immutable MAC address assigned by the manufacturer to the interface.	string
<code>method</code>	The method used to configure the interface. Possible values: <ul style="list-style-type: none"> <code>loopback</code>: Used to define the IPv4 loopback interface. <code>manual</code>: Used to define interfaces that are not configured automatically. <code>dhcp</code>: Can be used to obtain an IP address via DHCP. <code>static</code>: Used to define Ethernet interfaces with statically allocated IPv4 addresses. 	string
<code>status</code>	The state of the interface. Possible values: <ul style="list-style-type: none"> <code>Down</code>: The interface is inactive. <code>Up</code>: The interface is ready, but has no link. <code>UpAndRunning</code>: The interface is ready and a link is established. 	string
<code>upAndRunning</code>	Indicates if the interface is ready and has a link.	boolean

Member modifiability and node states

This table indicates whether or not the object parameters can be modified at each possible node state.

Parameter name	Available state	Pending state	Active state
<code>family</code>	No	No	No
<code>macAddress</code>	Configured by system	N/A	N/A
<code>macAddressPermanent</code>	Configured by system	N/A	N/A
<code>method</code>	No	No	No

Parameter name	Available state	Pending state	Active state
status	Yes	Yes	Yes
upAndRunning	Configured by system	N/A	N/A

Related references

[GetConfig](#) on page 200

[GetNetworkConfig](#) on page 211

network (SNMP)

The SNMP `network` object contains information about SNMP v3 configuration for the cluster nodes.

Object members

This object contains the following members:

Name	Description	Type
access	The type of access allowed for SNMP information requests. Possible values: <ul style="list-style-type: none"> <code>ro</code>: Read-only access. <code>rw</code>: Read-write access. <code>rosys</code>: Read-only access to a restricted set of system information. 	string
cidr	A CIDR network mask. This network mask must be an integer greater than or equal to 0, and less than or equal to 32. It must also not be equal to 31.	integer
community	The SNMP community string.	string
network	This member, along with the <code>cidr</code> member, controls which network the access and community string apply to. The special value of "default" is used to specify an entry that applies to all networks. The CIDR mask is ignored when this member is either a host name or "default".	string

Related references

[GetSnmplInfo](#) on page 291

networkInterface

The `networkInterface` object contains configuration information for individual network interfaces on a storage node.

Object members

This object contains the following members:

Name	Description	Type
address	The IPv4 management address of the interface.	string
addressV6	The IPv6 management address of the interface.	string
broadcast	The broadcast address of the interface.	string
macAddress	The MAC address of the interface.	string
mtu	The Maximum Transfer Unit, in bytes, of the interface.	integer
name	The name of the interface.	string
namespace	Whether or not this interface is assigned a virtual network namespace.	boolean
netmask	The subnet mask of the interface.	string
status	The operational status of the interface.	string
type	The type of interface (bond master, bond slave, etc).	string
virtualNetworkTag	The VLAN ID assigned to the interface on the virtual network.	integer

node

The `node` object contains information about each node in the cluster. You can retrieve this information using the `ListActiveNodes` and `ListAllNodes` methods.

Object members

This object contains the following members:

Name	Description	Type
associatedFServiceID	The Fibre Channel service ID for the node. "0" if the node is not a Fibre Channel node.	integer
associatedMasterServiceID	Master service ID for the node.	integer
attributes	List of name-value pairs in JSON object format.	JSON object
chassisName	Uniquely identifies a chassis; identical for all nodes in a single chassis.	string
cip	The cluster IP address assigned to the node.	string
cipi	Network interface used for cluster communication.	string
fibreChannelTargetPortGroup	The target group associated with this node. "null" if the node is not a Fibre Channel node.	integer
mip	The IP address used for node management.	string
mipi	The network interface used for node management.	string

Name	Description	Type
name	Host name for the node.	string
nodeID	NodeID for this node.	integer
nodeSlot	For HCI platforms, the letter corresponding to the chassis slot this node is in ("A", "B", "C", or "D"). For storage platforms, this value is null.	string
platformInfo	Hardware information for the node. Members: <ul style="list-style-type: none"> chassisType: The hardware platform of the node. cpuModel: The CPU model of the hardware platform. nodeMemoryGB: The amount of memory installed in the physical platform in GB. nodeType: The node model name. platformConfigVersion: The version of software configured for this node hardware. 	JSON object
protocolEndpointIDs	A list of unique IDs of protocol endpoints that are assigned to the node.	UUID array
sip	The storage IP address assigned to the node.	string
sipi	The network interface used for storage traffic.	string
softwareVersion	Returns the current version of Element software running on the node.	string
uuid	The universally unique identifier associated with this node.	string
virtualNetworks	Object containing virtual network IP addresses and IDs.	<i>virtualNetwork</i> array

Related references

[ListActiveNodes](#) on page 141

[ListAllNodes](#) on page 141

nodeStats

The `nodeStats` object contains high-level activity measurements for a node. You can use the `GetNodeStats` and `ListNodeStats` API methods to get some or all of the `nodeStats` objects.

Object members

This object contains the following members:

Name	Description	Type
count	The number of total samples in the nodeStats object.	integer
cpu	CPU usage, in %.	integer
cpuTotal	Monotonically increasing value of cpu utilization.	integer
cBytesIn	Bytes in on the cluster interface.	integer
cBytesOut	Bytes out on the cluster interface.	integer
sBytesIn	Bytes in on the storage interface.	integer
sBytesOut	Bytes out on the storage interface.	integer
mBytesIn	Bytes in on the management interface.	integer
mBytesOut	Bytes out on the management interface.	integer
networkUtilizationCluster	Network interface utilization (in %) for the cluster network interface.	integer
networkUtilizationStorage	Network interface utilization (in %) for the storage network interface.	integer
readLatencyUsecTotal	Monotonically increasing value of total time spent performing read operations to the node.	integer
readOps	Monotonically increasing value of total read operations to a node.	integer
ssLoadHistogram	Histogram data illustrating slice service load over time.	JSON object
timestamp	The current time in UTC+0 format.	ISO 8601 date string
usedMemory	Total memory usage in bytes.	integer
writeLatencyUsecTotal	Monotonically increasing value of total time spent performing write operations to the node.	integer
writeOps	Monotonically increasing value of total write operations to a node.	integer

Related references

[GetNodeStats](#) on page 140

[ListNodeStats](#) on page 148

ontapVersionInfo

The `ontapVersionInfo` object contains information about the API version of the ONTAP cluster in a SnapMirror relationship. The Element web UI uses the `GetOntapVersionInfo` API method to get this information.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
clientAPIMajorVesion	The ONTAP API major version in use by the Element API client.	string
clientAPIMinorVesion	The ONTAP API minor version in use by the Element API client.	string
ontapAPIMajorVersion	The current API major version supported by the ONTAP system.	string
ontapAPIMinorVesion	The current API minor version supported by the ONTAP system.	string
ontapVersion	The current software version running on the ONTAP cluster.	string

pendingActiveNode

The `pendingActiveNode` object contains information about a node that is currently in the `pendingActive` state, between the `pending` and `active` states. These are nodes that are currently being returned to the factory software image. Use the `ListPendingActiveNodes` API method to return a list of this information for all `pendingActive` nodes.

Object members

This object contains the following members:

Name	Description	Type
activeNodeKey	A unique key that allows the node to join the cluster automatically after a successful installation of software.	string
assignedNodeID	The assigned node ID for the node.	string
asyncHandle	The asynchronous method handle that you can use to query the status of the operation.	integer
cip	The cluster IP address assigned to the node.	string
mip	The management IP address assigned to the node.	string
nodeSlot	For HCI platforms, the letter corresponding to the chassis slot this node is in ("A", "B", "C", or "D"). For storage platforms, this value is null.	string
pendingActiveNodeID	The pending node ID of the node.	integer

Name	Description	Type
platformInfo	Hardware information for the node. Members: <ul style="list-style-type: none"> <code>chassisType</code>: The hardware platform of the node. <code>cpuModel</code>: The CPU model of the hardware platform. <code>nodeMemoryGB</code>: The amount of memory installed in the physical platform in GB. <code>nodeType</code>: The node model name. <code>platformConfigVersion</code>: The version of software configured for this node hardware. 	JSON object
sip	The storage (iSCSI) IP address assigned to the node.	string
softwareVersion	The current version of Element software running on the node.	string

Related references

[ListPendingActiveNodes](#) on page 153

pendingNode

The `pendingNode` object contains information about a node that can be added to a cluster. Use the `ListPendingNodes` API method to return a list of this information for all pending nodes. You can add any of the listed nodes to a cluster using the `AddNodes` API method.

Object members

This object contains the following members:

Name	Description	Type
cipi	The cluster IP address assigned to the node.	string
activeNodeKey	A unique key that allows the node to join the cluster automatically after a successful installation of software.	string
assignedNodeID	The assigned node ID for the node.	string
asyncHandle	The asynchronous method handle that you can use to query the status of the operation.	integer
chassisName	Uniquely identifies a chassis; identical for all nodes in a single chassis.	string
cip	The cluster IP address assigned to the node.	string
mip	The management IP address assigned to the node.	string
nodeSlot	For HCI platforms, the letter corresponding to the chassis slot this node is in ("A", "B", "C", or "D"). For storage platforms, this value is null.	string

Name	Description	Type
pendingActiveNodeID	The pending node ID of the node.	integer
platformInfo	Hardware information for the node. Members: <ul style="list-style-type: none"> chassisType: The hardware platform of the node. cpuModel: The CPU model of the hardware platform. nodeMemoryGB: The amount of memory installed in the physical platform in GB. nodeType: The node model name. platformConfigVersion: The version of software configured for this node hardware. 	JSON object
sip	The storage (iSCSI) IP address assigned to the node.	string
softwareVersion	The current version of Element software running on the node.	string

Related references

[AddNodes](#) on page 118

[ListPendingNodes](#) on page 151

protectionDomainLevel

The `protectionDomainLevel` object contains information about the storage cluster's current tolerance and resiliency levels. Tolerance levels indicate the cluster's ability to continue reading and writing data in the event of a failure, and resiliency levels indicate the cluster's ability to automatically heal itself from one or more failures within its associated type of protection domain.

Object members

This object contains the following members:

Name	Description	Type
protectionDomainType	The type of the protection domain which has the associated tolerance and resiliency. Possible values: <ul style="list-style-type: none"> node: Any individual node. chassis: Any individual node or all storage nodes in a single chassis. 	string
resiliency	The current resiliency of this cluster from the perspective of this protection domain type.	protectionDomainResiliency
tolerance	The current tolerance of this cluster from the perspective of this protection domain type.	protectionDomainTolerance

protectionDomainResiliency

The `protectionDomainResiliency` object contains the resiliency status of this storage cluster. Resiliency indicates the storage cluster's ability to automatically heal itself from one or more failures all within a single protection domain of its associated protection domain type. A storage cluster is considered healed when it can continue reading and writing data through the failure of any single storage node (a state known as node tolerance).

Object members

This object contains the following members:

Name	Description	Type
<code>protectionSchemeResiliencies</code>	A list of objects (one for each protection scheme) containing failure resiliency information for the associated type of protection domain.	<i>protectionSchemeResiliency</i> array
<code>singleFailureThresholdBytesForBlockData</code>	The maximum number of bytes that can be stored on the storage cluster before losing the ability to automatically heal to a state of node tolerance.	integer
<code>sustainableFailuresForEnsemble</code>	The predicted number of simultaneous failures that can occur without losing the ability to automatically heal to a state of node tolerance for the ensemble quorum.	integer

protectionDomainTolerance

The `protectionDomainTolerance` object contains information about the ability of the storage cluster to continue reading and writing data in the event of one or more failures all within a single protection domain of its associated protection domain type.

Object members

This object contains the following members:

Name	Description	Type
protectionSchemeTolerances	A list of objects (one for each protection scheme) containing failure tolerance information for the associated type of protection domain.	<i>protectionSchemeTolerance</i> array
sustainableFailuresForEnsemble	The number of simultaneous failures within the associated type of protection domain that can occur without losing the ensemble quorum.	integer

protectionSchemeResiliency

The `protectionSchemeResiliency` object contains information about whether a storage cluster, for a specific protection scheme, can automatically heal itself from one or more failures within its associated `protectionDomainType`. A storage cluster is considered healed when it can continue reading and writing data through the failure of any single storage node (a state known as node tolerance).

Object members

This object contains the following members:

Name	Description	Type
protectionScheme	The current protection scheme of this storage cluster. The only possible value is <code>doubleHelix</code> .	string
sustainableFailuresForBlockData	The predicted number of simultaneous failures which can occur without losing the ability to automatically heal to a state of node tolerance for data.	integer
sustainableFailuresForMetadata	The predicted number of simultaneous failures which can occur without losing the ability to automatically heal to a state of node tolerance for metadata.	integer

protectionSchemeTolerance

The `protectionSchemeTolerance` object contains information about whether a storage cluster, for a specific protection scheme, can continue to read and write data after failures.

Object members

This object contains the following members:

Name	Description	Type
protectionScheme	The current protection scheme of this storage cluster. The only possible value is <code>doubleHelix</code> .	string

Name	Description	Type
sustainableFailuresForBlockData	The current number of simultaneous failures which can occur without losing block data availability for the associated protection scheme.	integer
sustainableFailuresForMetadata	The current number of simultaneous failures which can occur without losing metadata availability for the associated protection scheme.	integer

protocolEndpoint

The `protocolEndpoint` object contains the attributes of a protocol endpoint. You can retrieve this information for all protocol endpoints in the cluster using the `ListProtocolEndpoints` API method.

Object members

This object contains the following members:

Name	Description	Type
primaryProviderID	The ID of the primary protocol endpoint provider object for the protocol endpoint.	integer
protocolEndpointID	The unique ID of the protocol endpoint.	UUID
protocolEndpointState	The status of the protocol endpoint. Possible values: <ul style="list-style-type: none"> Active: The protocol endpoint is in use. Start: The protocol endpoint is starting. Failover: The protocol endpoint has failed over. Reserved: The protocol endpoint is reserved. 	string
providerType	The type of the protocol endpoint's provider. Possible values: <ul style="list-style-type: none"> Primary Secondary 	string
scsiNAADeviceID	The globally unique SCSI device identifier for the protocol endpoint in NAA IEEE Registered Extended Format.	string
secondaryProviderID	The ID of the secondary protocol endpoint provider object for the protocol endpoint.	integer

Related references

[ListProtocolEndpoints](#) on page 450

QoS

The `QoS` object contains information about Quality of Service (QoS) settings for volumes. Volumes created without specified QoS values are created using the default values. You can find default values using the `GetDefaultQoS` method.

Object members

This object contains the following members:

Name	Description	Type
burstIOPS	Maximum "peak" 4KB IOPS allowed for short periods of time. Allows for bursts of I/O activity over the normal maxIOPS value.	integer
burstTime	The length of time burstIOPS is allowed. The value returned is represented in seconds. This value is calculated by the system based on IOPS set for QoS.	integer
curve	The curve is a set of key-value pairs. The keys are I/O sizes in bytes. The values represent the cost of performing one IOP at a specific I/O size. The curve is calculated relative to a 4096 byte operation set at 100 IOPS.	JSON object
maxIOPS	The desired maximum 4KB IOPS allowed over an extended period of time.	integer
minIOPS	The desired minimum 4KB IOPS to guarantee. The allowed IOPS will only drop below this level if all volumes have been capped at their minIOPS value and there is still insufficient performance capacity.	integer

Related references

[GetDefaultQoS](#) on page 354

QoSPolicy

The `QoSPolicy` object contains information about a QoS policy on a storage cluster running Element software.

Object members

This object contains the following members:

Name	Description	Type
qosPolicyID	A unique integer identifier for the QoSPolicy automatically assigned by the storage cluster.	integer
name	The name of the QoS policy. For example: gold, platinum, or silver.	string
qos	The QoS settings that this policy represents.	QoS
volumeIDs	A list of volumes associated with this policy.	integer array

Related references

[GetQoSPolicy](#) on page 355

schedule

The `schedule` object contains information about a schedule created to autonomously make a snapshot of a volume. You can retrieve schedule information for all schedules with the `ListSchedules` API method.

Object members

This object contains the following members:

Name	Description	Type
<code>attributes</code>	Indicates the frequency of the schedule occurrence. Possible values: <ul style="list-style-type: none"> • <code>Day of Week</code> • <code>Day of Month</code> • <code>Time Interval</code> 	JSON object
<code>hasError</code>	Indicates whether or not the schedule has errors. Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean
<code>hours</code>	Shows the hours that will elapse before the next snapshot is created. Possible values are 0 through 24.	integer
<code>lastRunStatus</code>	Indicates the status of the last scheduled snapshot. Possible values: <ul style="list-style-type: none"> • <code>Success</code> • <code>Failed</code> 	string
<code>lastRunTimeStart</code>	Indicates the last time the schedule started.	ISO 8601 date string
<code>minutes</code>	Shows the minutes that will elapse before the next snapshot is created. Possible values are 0 through 59.	integer
<code>monthdays</code>	Indicates the days of the month that a snapshot will be made.	array
<code>paused</code>	Indicates whether or not the schedule is paused. Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean

Name	Description	Type
recurring	Indicates whether or not the schedule is recurring. Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean
runNextInterval	Indicates whether or not the schedule will run the next time the scheduler is active. When <code>true</code> , the schedule will run the next time the scheduler is active and then this value is set back to <code>false</code> . Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean
scheduleID	The unique ID of the schedule.	integer
scheduleInfo	Includes the unique name given to the schedule, the retention period for the snapshot that was created, and the volume ID of the volume from which the snapshot was created.	JSON object
scheduleName	The unique name assigned to the schedule.	string
scheduleType	Only schedule types of <code>snapshot</code> are supported at this time.	string
snapMirrorLabel	The <code>snapMirrorLabel</code> to be applied to the created Snapshot or Group Snapshot, contained in the <code>scheduleInfo</code> . If not set, this value is null.	string
startingDate	Indicates the date the first time the schedule began or will begin; formatted in UTC time.	ISO 8601 date string
toBeDeleted	Indicates if the schedule is marked for deletion. Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean
weekdays	Indicates the days of the week that a snapshot will be made.	array

Related references

[ListSchedules](#) on page 430

session (Fibre Channel)

The `session` object contains information about each Fibre Channel session that is visible to the cluster and what target ports it is visible on. You can retrieve this information with the `ListFibreChannelSessions` API method.

Object members

This object contains the following members:

Name	Description	Type
<code>initiatorWWPN</code>	The World Wide Port Name (WWPN) of the initiator that is logged into the target port.	string
<code>nodeID</code>	The node that owns the Fibre Channel session.	integer
<code>initiator</code>	Information about this Fibre Channel session's server initiator. Members: <ul style="list-style-type: none"> <code>alias</code>: The friendly name assigned to the initiator. <code>attributes</code>: The attributes of this initiator. <code>initiatorID</code>: The ID of this initiator. <code>initiatorName</code>: The name of this initiator. <code>volumeAccessGroups</code>: A list of volume access groups associated with this initiator. 	JSON object
<code>serviceID</code>	The service ID of the target port involved in this session.	integer
<code>targetWWPN</code>	The WWPN of the target port involved in this session.	string
<code>volumeAccessGroupID</code>	The ID of the volume access group to which the <code>initiatorWWPN</code> belongs. If not in a volume access group, this value is null.	integer

Related references

[ListFibreChannelSessions](#) on page 180

session (iSCSI)

The `session (iSCSI)` object contains detailed information about each volume's iSCSI session. You can retrieve iSCSI session information with the `ListISCSISessions` API method.

Object members

This object contains the following members:

Name	Description	Type
accountID	The account ID of the account used for CHAP authentication, if any.	integer
accountName	The name of the account used for CHAP authentication, if any.	string
createTime	The time of the creation of the iSCSI session, in UTC+0 format.	ISO 8601 date string
driveID	The driveID associated with the transport service hosting the session.	integer
driveIDs	A list of the driveIDs of the drives reporting the failure. An empty list if not applicable.	integer array
initiator	Information about this iSCSI session's server initiator. Members: <ul style="list-style-type: none"> alias: The friendly name assigned to the initiator. attributes: The attributes of this initiator. initiatorID: The ID of this initiator. initiatorName: The name of this initiator. volumeAccessGroups: A list of volume access groups associated with this initiator. 	JSON object
initiatorIP	The IP address and port number of the iSCSI server initiator.	string
initiatorName	The iSCSI Qualified Name (IQN) of the iSCSI server initiator.	string
initiatorPortName	The initiatorName combined with the initiatorSessionID; identifies the initiator port.	string
initiatorSessionID	A 48-bit ID provided by the initiator that identifies the iSCSI session as belonging to that initiator.	integer
msSinceLastIscsiPDU	The time, in milliseconds, since the last iSCSI PDU was received for this session.	integer
msSinceLastScsiCommand	The time, in milliseconds, since the last SCSI command was received for this session.	integer
nodeID	The nodeID associated with the transport service hosting the session.	integer
serviceID	The serviceID of the transport service hosting the session.	integer
sessionID	The iSCSI session ID.	integer
targetIP	The IP address and port number of the iSCSI storage target.	string
targetName	The IQN of the iSCSI target.	string

Name	Description	Type
targetPortName	The targetName combined with the target portal group tag; identifies the target port.	string
virtualNetworkID	The virtual network ID associated with the session.	integer
volumeID	The volumeID of the volume associated with the session, if any.	integer
volumeInstance	Identifies the volume object associated with the iSCSI session, if any.	integer

Related references

[ListISCSISessions](#) on page 149

snapMirrorAggregate

The `snapMirrorAggregate` object contains information about the available ONTAP aggregates, which are collections of disks made available to volumes as storage. You can get this information using the `ListSnapMirrorAggregates` API method.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
aggregateName	The name of the aggregate.	string
nodeName	The name of the ONTAP node that owns this aggregate.	string
sizeAvailable	The number of available bytes remaining in the aggregate.	integer
sizeTotal	The total size (in bytes) of the aggregate.	integer
percentUsedCapacity	The percentage of disk space currently in use.	integer
volumeCount	The number of volumes in the aggregate.	integer

snapMirrorClusterIdentity

The `snapMirrorClusterIdentity` object contains identification information about the remote ONTAP cluster in a `SnapMirror` relationship.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
clusterName	The name of the destination ONTAP cluster.	string

Name	Description	Type
clusterUUID	The 128-bit universally-unique identifier of the destination ONTAP cluster.	string
clusterSerialNumber	The serial number of the destination ONTAP cluster.	string

snapMirrorEndpoint

The `snapMirrorEndpoint` object contains information about the remote SnapMirror storage systems communicating with the Element storage cluster. You can retrieve this information with the `ListSnapMirrorEndpoints` API method.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The unique identifier for the object in the local cluster.	integer
managementIP	The cluster management IP address of the endpoint.	string
clusterName	The ONTAP cluster name. This value is automatically populated with the value of “clusterName” from the <code>snapMirrorClusterIdentity</code> object.	string
username	The management user name for the ONTAP system.	string
ipAddresses	List of the inter-cluster storage IP addresses for all nodes in the cluster. You can get these IP addresses with the <code>ListSnapMirrorNetworkInterfaces</code> method.	string array
isConnected	The connectivity status of the control link to the ONTAP cluster.	boolean

snapMirrorJobScheduleCronInfo

The `snapMirrorJobScheduleCronInfo` object contains information about a cron job schedule on the ONTAP system.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
jobScheduleName	The name of the job schedule.	string
jobScheduleDescription	An automatically-generated human-readable summary of the schedule.	string

snapMirrorLunInfo

The `snapMirrorLunInfo` object contains information about the ONTAP LUN object.

Object members

This object contains the following members:

Name	Description	Type
<code>snapMirrorEndpointID</code>	The ID of the destination ONTAP system.	integer
<code>creationTimestamp</code>	The creation time of the LUN.	ISO 8601 date string
<code>lunName</code>	The name of the LUN.	string
<code>path</code>	The path of the LUN.	string
<code>size</code>	The size of the LUN in bytes.	integer
<code>sizeUsed</code>	The number of bytes used by the LUN.	integer
<code>state</code>	The current access state of the LUN. Possible values: <ul style="list-style-type: none"> online offline foreign_lun_error nvfail space_error 	string
<code>volume</code>	The name of the volume that contains the LUN.	string
<code>vserver</code>	The Vserver that contains the LUN.	string

snapMirrorNetworkInterface

The `snapMirrorNetworkInterface` object contains information about the intercluster Logical Interfaces (LIFs).

Object members

This object contains the following members:

Name	Description	Type
<code>administrativeStatus</code>	Whether the logical interface (LIF) is administratively enabled or disabled. Possible values: <ul style="list-style-type: none"> up down 	string
<code>snapMirrorEndpointID</code>	The ID of the destination ONTAP system.	integer
<code>interfaceName</code>	The LIF name.	string

Name	Description	Type
networkAddress	The IP address of the LIF.	string
networkMask	The network mask of the LIF.	string
interfaceRole	The role of the LIF. Possible values: <ul style="list-style-type: none"> undef cluster data node_mgmt intercluster cluster_mgmt 	string
operationalStatus	The operational state of the LIF (whether or not it has formed a successful connection). This status can differ from the administrative status if there is a network problem that prevents the interface from functioning. Possible values: <ul style="list-style-type: none"> up down 	string
vserverName	The name of the Vserver.	string

snapMirrorNode

The `snapMirrorNode` object contains information about the nodes of the destination ONTAP cluster in a SnapMirror relationship.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
name	The name of the ONTAP node.	string
model	The model of the ONTAP node.	string
serialNumber	The serial number of the ONTAP node.	string
productVersion	The ONTAP product version.	string
isNodeHealthy	The health of a node in the ONTAP cluster. Possible values: <ul style="list-style-type: none"> true false 	string

Name	Description	Type
isNodeEligible	Whether or not the node is eligible to participate in an ONTAP cluster. Possible values: <ul style="list-style-type: none"> true false 	string

snapMirrorPolicy

The `snapMirrorPolicy` object contains information about a SnapMirror policy that is stored on an ONTAP system.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
policyName	The unique name assigned to the policy.	string
policyType	The type of policy. Possible values: <ul style="list-style-type: none"> async_mirror mirror_vault 	string
comment	A human-readable description associated with the SnapMirror policy.	string
transferPriority	The priority at which a SnapMirror transfer runs. Possible values: <ul style="list-style-type: none"> normal: The default priority. These transfers are scheduled before most low priority transfers. low: These transfers have the lowest priority and are scheduled after most normal priority transfers. 	string
policyRules	A list of objects describing the policy rules.	<i>snapMirrorPolicyRule</i> array
totalKeepCount	The total retention count for all rules in the policy.	integer
totalRules	The total number of rules in the policy.	integer
vserverName	The name of the Vserver for the SnapMirror policy.	string

snapMirrorPolicyRule

The `snapMirrorPolicyRule` object contains information about the rules in a SnapMirror policy.

Object members

This object contains the following members:

Name	Description	Type
<code>snapMirrorLabel</code>	The snapshot copy label, used for snapshot copy selection in extended data protection relationships.	string
<code>keepCount</code>	Specifies the maximum number of snapshot copies that are retained on the SnapMirror destination volume for a rule.	integer

snapMirrorRelationship

The `snapMirrorRelationship` object contains information about a SnapMirror relationship between a Element volume and an ONTAP volume.

Object members

This object contains the following members:

Name	Description	Type
<code>snapMirrorEndpointID</code>	The ID of the destination ONTAP system.	integer
<code>snapMirrorRelationshipID</code>	The unique identifier for each <code>snapMirrorRelationship</code> object in an array as would be returned in <code>ListSnapMirrorRelationships</code> . This UUID is created and returned from the ONTAP system.	string
<code>sourceVolume</code>	An object describing the source volume.	<i>snapMirrorVolumeInfo</i>
<code>destinationVolume</code>	An object describing the destination volume.	<i>snapMirrorVolumeInfo</i>
<code>currentMaxTransferRate</code>	The current maximum transfer rate between the source and destination volumes, in kilobytes per second.	integer

Name	Description	Type
isHealthy	<p>Whether the relationship is healthy or not. Possible values:</p> <ul style="list-style-type: none"> <code>true</code>: The relationship is healthy. <code>false</code>: The relationship is not healthy. This can be caused by a manual or scheduled update failing or being aborted, or by the last scheduled update being delayed. 	boolean
lagtime	The amount of time in seconds by which the data on the destination volume lags behind the data on the source volume.	integer
lastTransferDuration	The amount of time in seconds it took for the last transfer to complete.	integer
lastTransferError	A message describing the cause of the last transfer failure.	string
lastTransferSize	The total number of bytes transferred during the last transfer.	integer
lastTransferEndTimestamp	The timestamp of the end of the last transfer.	ISO 8601 date string
lastTransferType	The type of the previous transfer in the relationship.	string
maxTransferRate	Specifies the maximum data transfer rate between the volumes in kilobytes per second. The default value, 0, is unlimited and permits the SnapMirror relationship to fully utilize the available network bandwidth.	integer
mirrorState	<p>The mirror state of the SnapMirror relationship. Possible values:</p> <ul style="list-style-type: none"> <code>uninitialized</code>: The destination volume has not been initialized. <code>snapmirrored</code>: The destination volume has been initialized and is ready to receive SnapMirror updates. <code>broken-off</code>: The destination volume is read-write and snapshots are present. 	string

Name	Description	Type
newestSnapshot	The name of the newest Snapshot copy on the destination volume.	string
policyName	Specifies the name of the ONTAP SnapMirror policy for the relationship. A list of available policies can be retrieved with <code>ListSnapMirrorPolicies</code> . Example values are “MirrorLatest” and “MirrorAndVault”.	string
policyType	The type of the ONTAP SnapMirror policy for the relationship. See <code>ListSnapMirrorPolicies</code> . Examples are: “async_mirror” or “mirror_vault”.	string
relationshipProgress	The total number of bytes that have been processed so far for the current activity of the relationship as returned in the relationship-status. This is set only when the "relationshipStatus" member indicates that an activity is in progress.	integer
relationshipStatus	The status of the SnapMirror relationship. Possible values: <ul style="list-style-type: none"> idle transferring checking quiescing quiesced queued preparing finalizing aborting breaking 	string
relationshipType	The type of the SnapMirror relationship. On storage clusters running Element software, this value is always “extended_data_protection”.	string

Name	Description	Type
scheduleName	The name of the pre-existing cron schedule on the ONTAP system that is used to update the SnapMirror relationship. A list of available schedules can be retrieved with <code>ListSnapMirrorSchedules</code> .	string
unhealthyReason	The reason the relationship is not healthy.	string

snapMirrorVolume

The `snapMirrorVolume` object contains information about an ONTAP volume.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
name	The name of the volume.	string
type	The type of volume. Possible values: <ul style="list-style-type: none"> <code>rw</code>: Read-write volume <code>ls</code>: Load-sharing volume <code>dp</code>: Data protection volume 	string
vserver	The name of the Vserver that owns this volume.	string
aggrName	The containing aggregate name.	string
state	The state of volume. Possible values: <ul style="list-style-type: none"> <code>online</code> <code>restricted</code> <code>offline</code> <code>mixed</code> 	string
size	The total filesystem size (in bytes) of the volume.	string
availSize	The size (in bytes) of the available space in the volume.	string

snapMirrorVolumeInfo

The `snapMirrorVolumeInfo` object contains information about a volume location in a `SnapMirror` relationship, such as its name and type.

Object members

This object contains the following members:

Name	Description	Type
type	The type of volume. Possible values: <ul style="list-style-type: none"><code>solidfire</code>: The volume resides on a storage cluster running Element software.<code>ontap</code>: The volume resides on a remote ONTAP cluster.	string
volumeID	The ID of the volume. Only valid if "type" is <code>solidfire</code> .	integer
vserver	The name of the Vserver that owns this volume. Only valid if "type" is <code>ontap</code> .	string
name	The name of the volume.	string

snapMirrorVserver

The `snapMirrorVserver` object contains information about the Storage Virtual Machines (or Vservers) at the destination ONTAP cluster.

Object members

This object contains the following members:

Name	Description	Type
snapMirrorEndpointID	The ID of the destination ONTAP system.	integer
vserverName	The name of the Vserver.	string
vserverType	The type of Vserver. Possible values: <ul style="list-style-type: none"><code>data</code><code>admin</code><code>system</code><code>node</code>	string

Name	Description	Type
vserverSubtype	The subtype of the Vserver. Possible values: <ul style="list-style-type: none"> default dp_destination data sync_source sync_destination 	string
rootVolume	The root volume of the Vserver.	string
rootVolumeAggregate	The aggregate on which the root volume will be created.	string
vserverAggregateInfo	An array of snapMirrorVserverAggregateInfo objects.	JSON object
adminState	The detailed administrative state of the Vserver. Possible values: <ul style="list-style-type: none"> running stopped starting stopping initializing deleting 	string
operationalState	The basic operational state of the Vserver. Possible values: <ul style="list-style-type: none"> running stopped 	string

snapMirrorVserverAggregateInfo

The `snapMirrorVserverAggregateInfo` object contains information about the available data Storage Virtual Machines (also called Vservers) at the destination ONTAP cluster.

Object members

This object contains the following members:

Name	Description	Type
aggrName	The name of the aggregate assigned to a Vserver.	string
aggrAvailSize	The assigned aggregate's available size.	integer

snapshot

The `snapshot` object contains information about a snapshot made for a volume. You can use the `ListSnapshots` API method to retrieve a list of snapshot information for a volume or for all volumes. The object includes information about the active snapshot as well as each snapshot created for a volume.

Object members

This object contains the following members:

Name	Description	Type
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object
<code>checksum</code>	A small string representation of the data in the stored snapshot. This checksum can be used later to compare other snapshots to detect errors in the data.	string
<code>createTime</code>	The UTC+0 formatted time the snapshot was created.	ISO 8601 date string
<code>enableRemoteReplication</code>	Identifies if snapshot is enabled for remote replication.	boolean
<code>expirationReason</code>	Indicates how the snapshot expiration is set. Possible values: <ul style="list-style-type: none"> <code>Api</code>: The expiration time is set by using the API. <code>None</code>: No expiration time is set. <code>Test</code>: The expiration time is set for testing. 	string
<code>expirationTime</code>	The time at which this snapshot will expire and be purged from the cluster.	ISO 8601 date string
<code>groupID</code>	The group ID if the snapshot is a member of a group snapshot.	integer
<code>groupsnapshotUUID</code>	Contains information about each snapshot in the group. Each of these members will have a UUID parameter for the snapshot's UUID.	string
<code>instanceCreateTime</code>	The time that the snapshot was created on the local cluster.	ISO 8601 date string
<code>instanceSnapshotUUID</code>	The universally unique ID of the snapshot on the local cluster. This ID does not get replicated to other clusters.	string
<code>name</code>	The unique name assigned to the snapshot. If no name is specified, the name is the UTC+0 formatted timestamp of when the snapshot was created.	string

Name	Description	Type
remoteStatus	<p>The current remote status of the snapshot. Possible values:</p> <ul style="list-style-type: none"> <code>Present</code>: The snapshot exists on a remote cluster. <code>NotPresent</code>: The snapshot does not exist on a remote cluster. <code>Syncing</code>: This is a target cluster and it is currently replicating the snapshot. <code>Deleted</code>: This is a target cluster, the snapshot has been deleted, and it still exists on the source. 	string
snapMirrorLabel	The label used by SnapMirror software to specify snapshot retention policy on SnapMirror endpoints. If not set, this value is null.	string
snapshotID	The unique ID of an existing snapshot.	string
snapshotUUID	The universally unique ID of an existing snapshot. When the snapshot is replicated across clusters, this ID is replicated along with it and is used to identify the snapshot across clusters.	string
status	<p>Current status of the snapshot. Possible values:</p> <ul style="list-style-type: none"> <code>unknown</code>: There was an error obtaining the status of the snapshot. <code>preparing</code>: This snapshot is being prepared for use and is not yet writable. <code>remoteSyncing</code>: This snapshot is being replicated from a remote cluster. <code>done</code>: This snapshot has finished preparation or replication and is now usable. <code>active</code>: This snapshot is the active branch. <code>cloning</code>: This snapshot is involved in a <code>CopyVolume</code> operation. 	string
totalSize	The total size in bytes of the snapshot.	integer
virtualVolumeID	The ID of the virtual volume associated with this snapshot.	UUID
volumeID	The ID of the volume the snapshot was created from.	integer
volumeName	The name of the volume at the time the snapshot was created.	string

Related references

[ListSnapshots](#) on page 431

snmpTrapRecipient

The `snmpTrapRecipient` object contains information about a host that is configured to receive SNMP traps generated by the storage cluster. You can use the `GetSnmpTrapInfo` API method to get a list of hosts configured to receive SNMP traps.

Object members

This object contains the following members:

Name	Description	Type
host	The IP address or host name of the target host.	string
port	The UDP port number on the host where the trap should be sent. Valid range is 1 through 65535. 0 (zero) is not a valid port number. The default port is 162.	integer
community	SNMP community string.	string

storageContainer

The `storageContainer` object contains the attributes of a virtual volume storage container. You can retrieve this information for each storage container in the cluster using the `ListStorageContainers` API method.

Object members

This object contains the following members:

Name	Description	Type
accountID	The ID of the storage system account associated with the storage container.	integer
initiatorSecret	The CHAP authentication secret for the initiator associated with the storage container.	string
name	The name of the storage container.	string
protocolEndpointType	The storage container's protocol endpoint type. SCSI is the only valid value.	string
status	The status of the storage container. Possible values: <ul style="list-style-type: none"> Active: The storage container is in use. Locked: The storage container is locked. 	string
storageContainerID	The unique ID of the storage container.	UUID
targetSecret	The CHAP authentication secret for the target associated with the storage container.	string
virtualVolumes	A list of IDs of the virtual volumes associated with the storage container.	UUID array

Related references

[ListStorageContainers](#) on page 451

syncJob

The `syncJob` object contains information about clone, remote replication, or slice synchronization jobs that are running on a cluster.

You can retrieve synchronization information with the `ListSyncJobs` API method.

Object members

This object contains the following members:

Name	Description	Type
<code>blocksPerSecond</code>	The number of data blocks being transferred per second from the source cluster to the target cluster. Present only if the <code>type</code> member is set to <code>remote</code> .	float
<code>branchType</code>	Returned for remote replication sync jobs only. Possible values: <ul style="list-style-type: none"> <code>snapshot</code> <code>volume</code> 	string
<code>bytesPerSecond</code>	The number of bytes the clone is processing per second. Present only if the <code>type</code> member is set to <code>clone</code> or <code>slice</code> .	float
<code>cloneID</code>	The identifier of the clone operation that is in progress. Present only if the <code>type</code> member is set to <code>clone</code> .	integer
<code>currentBytes</code>	The number of bytes the clone has processed in the source volume. Present only if the <code>type</code> member is set to <code>clone</code> or <code>slice</code> .	integer
<code>dstServiceID</code>	The service identifier hosting the primary replica for the volume. Present only if the <code>type</code> member is set to <code>remote</code> .	integer
<code>dstVolumeID</code>	The destination volume ID. Present only if the <code>type</code> member is set to <code>clone</code> or <code>remote</code> .	integer
<code>elapsedTime</code>	The time elapsed, in seconds, since the sync job started.	float
<code>groupCloneID</code>	The ID of the group clone operation that is in progress.	integer
<code>nodeID</code>	Specifies the node the clone is occurring on. Present only if the <code>type</code> member is set to <code>clone</code> .	integer
<code>percentComplete</code>	The percentage of sync job completion.	integer
<code>remainingTime</code>	The estimated time, in seconds, to complete the operation.	integer
<code>sliceID</code>	The ID of the slice drive being synced.	integer

Name	Description	Type
stage	<p>Present only if the <code>type</code> member is set to <code>remote</code> or <code>clone</code>. Possible values:</p> <ul style="list-style-type: none"> <code>metadata</code>: Replication is in the process of determining what data needs to be transferred to the remote cluster. Status is not reported for this stage of the replication process. <code>data</code>: Replication is in the process of transferring the bulk of the data to the remote cluster. <code>whole</code>: Indicates backward compatibility of the slice for slice sync jobs. 	string
snapshotID	The ID of the snapshot the clone was created from. Present only if the <code>type</code> member is set to <code>clone</code> .	integer
srcServiceID	The source service ID.	integer
srcVolumeID	The source volume ID.	integer
totalBytes	The total number of bytes of the clone. Present only if the <code>type</code> member is set to <code>clone</code> or <code>slice</code> .	integer
type	<p>The type of sync operation. Possible values:</p> <ul style="list-style-type: none"> <code>clone</code> <code>slice</code> <code>block</code> <code>remote</code> 	string

Related references

[ListSyncJobs](#) on page 366

task (virtual volumes)

The `task` object contains information about a currently running or finished virtual volume task in the system. You can use the `ListVirtualVolumeTasks` method to retrieve this information for all virtual volume tasks.

Object members

This object contains the following members:

Name	Description	Type
cancelled	<p>Indicates whether or not the task was cancelled. Possible values:</p> <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean

Name	Description	Type
cloneVirtualVolumeID	The unique virtual volume ID of the virtual volume being cloned (for clone tasks).	UUID
parentMetadata	An object containing metadata of the parent for tasks which clone or create snapshots of a virtual volume.	JSON object
parentTotalSize	The total space available (in bytes) on the parent for clone or snapshot tasks.	integer
parentUsedSize	The used space of the parent (in bytes) for clone or snapshot tasks.	integer
operation	<p>The type of operation the task is performing. Possible values:</p> <ul style="list-style-type: none"> unknown: The task operation is unknown. prepare: The task is preparing a virtual volume. snapshot: The task is creating a snapshot of a virtual volume. rollback: The task is rolling back a virtual volume to a snapshot. clone: The task is creating a clone of the virtual volume. fastClone: The task is creating a fast clone of a virtual volume. copyDiffs: The task is copying differing blocks to a virtual volume. 	string
status	<p>The current status of the virtual volume task. Possible values:</p> <ul style="list-style-type: none"> error: The task has failed and returned an error. queued: The task is waiting to be run. running: The task is currently running. success: The task has completed successfully. 	string
virtualVolumeHostID	The unique ID of the host that started the task.	UUID
virtualVolumeID	The new, unique virtual volume ID (for tasks that create a new virtual volume).	UUID
virtualVolumeTaskID	The unique ID of the task.	UUID

Related references

[List Virtual Volume Tasks](#) on page 457

usmUser

You can use the SNMP `usmUser` object with the `SetSnmpInfo` API method to configure SNMP on the storage cluster.

Object members

This object contains the following members:

Name	Description	Type
access	The type of SNMP access for this user. Possible values: <ul style="list-style-type: none"> <code>rouser</code>: Read-only access. <code>rwuser</code>: Read-write access. All Element software MIB objects are read-only. 	string
name	The name of the user.	string
password	The password of the user.	string
passphrase	The passphrase of the user.	string
secLevel	The type of credentials required for this user. Possible values: <ul style="list-style-type: none"> <code>noauth</code>: No password or passphrase is required. <code>auth</code>: A password is required for user access. <code>priv</code>: A password and passphrase are required for user access. 	string

Related references

[SetSnmpInfo](#) on page 307

virtualNetwork

The `virtualNetwork` object contains information about a specific virtual network. You can use the `ListVirtualNetworks` API method to retrieve a list of this information for all virtual networks in the system.

Object members

This object contains the following members:

Name	Description	Type
addressBlocks	<p>The range of address blocks currently assigned to the virtual network. Members:</p> <ul style="list-style-type: none"> <code>available</code>: Binary string in "1"s and "0"s. "1" denotes that the IP address is available, and "0" denotes that the IP is not available. The string is read from right to left with the digit to the far right being the first IP address in the list of address blocks. <code>size</code>: The size of this block of addresses. <code>start</code>: The first IP address in the block. 	JSON object array
attributes	List of name-value pairs in JSON object format.	JSON object
name	The name assigned to the virtual network.	string
netmask	The IP address of the netmask for the virtual network.	string
svip	The storage IP address for the virtual network.	string
gateway	The gateway used for the virtual network.	string
virtualNetworkID	The unique identifier for a virtual network.	integer
virtualNetworkTag	The VLAN tag identifier.	integer

Related references

[ListVirtualNetworks](#) on page 319

virtualVolume

The `virtualVolume` object contains configuration information about a virtual volume as well as information about snapshots of the virtual volume. It does not include runtime or usage information. You can use the `ListVirtualVolumes` method to retrieve this information for a cluster.

Object members

This object contains the following members:

Name	Description	Type
bindings	A list of binding IDs for this virtual volume.	UUID array
children	A list of virtual volume UUIDs that are children of this virtual volume.	UUID array
descendants	When you pass <code>recursive: true</code> to the <code>ListVirtualVolumes</code> method, contains a list of virtual volume UUIDs that are descendants of this virtual volume.	UUID array
metadata	Key-value pairs of the virtual volume's metadata, such as virtual volume type, guest OS type, and so on.	JSON object

Name	Description	Type
parentVirtualVolumeID	The virtual volume ID of the parent virtual volume. If the ID is all zeros, this is an independent virtual volume with no link to a parent.	UUID
snapshotID	The ID of the underlying volume snapshot. This value is "0" if the virtual volume does not represent a snapshot.	integer
snapshotInfo	The <i>snapshot</i> object for the associated snapshot (null if nonexistent).	<i>snapshot</i>
status	Current status of the virtual volume. Possible values: <ul style="list-style-type: none"> <i>cloning</i>: The virtual volume is being processed in response to a clone or snapshot operation. <i>waiting</i>: The virtual volume is waiting for a snapshot operation to complete. <i>ready</i>: The virtual volume is ready for general purpose use. 	string
storageContainer	An object describing the storage container that owns this virtual volume.	<i>storageContainer</i>
virtualVolumeID	The unique ID of the virtual volume.	UUID
virtualVolumeType	The type of the virtual volume.	string
volumeID	The ID of the underlying volume.	integer
volumeInfo	When you pass <code>details: true</code> to the <code>ListVirtualVolumes</code> method, this member is an object describing the volume.	<i>volume</i>

Related references

[ListVirtualVolumes](#) on page 455

[snapshot](#) on page 72

[storageContainer](#) on page 74

[volume](#) on page 80

volume

The `volume` object contains configuration information about unpaired or paired volumes. It does not include runtime or usage information, and does not contain information about virtual volumes.

Object members

This object contains the following members:

Name	Description	Type
access	<p>The type of access allowed for the volume. Possible values:</p> <ul style="list-style-type: none"> readOnly: Only read operations are allowed. readWrite: Reads and writes are allowed. locked: No reads or writes are allowed. replicationTarget: Designated as a target volume in a replicated volume pair. 	string
accountID	The accountID of the account containing the volume.	integer
attributes	List of name-value pairs in JSON object format.	JSON object
blockSize	The size of blocks on the volume.	integer
createTime	The UTC+0 formatted time the volume was created.	ISO 8601 string
currentProtectionScheme	The protection scheme that is being used for this volume. If a volume is converting from one protection scheme to another, this member reflects the protection scheme to which the volume is converting.	string
deleteTime	The UTC+0 formatted time the volume was deleted.	ISO 8601 string
enable512e	If set to true, the volume provides 512 byte sector emulation.	boolean
enableSnapMirrorReplication	Whether or not the volume can be used for replication with SnapMirror endpoints.	boolean
iqn	The iSCSI Qualified Name of the volume.	string
lastAccessTime	The last time any access (including I/O) to the volume occurred (formatted as UTC+0). If the last access time is not known, this value is null.	ISO 8601 string

Name	Description	Type
lastAccessTimeIO	The last time any I/O to the volume occurred (formatted as UTC+0). If the last access time is not known, this value is null.	ISO 8601 string
name	The name of the volume as provided at creation time.	string
previousProtectionScheme	If a volume is converting from one protection scheme to another, this member reflects the protection scheme from which the volume is converting. This member does not change until a conversion is started. If a volume has never been converted, this member is null.	string
purgeTime	The UTC+0 formatted time the volume was purged from the system.	ISO 8601 string
qos	The quality of service settings for this volume.	QoS
qosPolicyID	The QoS policy ID associated with the volume. The value is null if the volume is not associated with a policy.	integer
scsiEUIDeviceID	Globally unique SCSI device identifier for the volume in EUI-64 based 16-byte format.	string
scsiNAADeviceID	Globally unique SCSI device identifier for the volume in NAA IEEE Registered Extended format.	string
sliceCount	The number of slices on the volume. This value is always "1".	integer
status	The current status of the volume. Possible values: <ul style="list-style-type: none"> <code>init</code>: A volume that is being initialized and is not ready for connections. <code>active</code>: An active volume ready for connections. <code>deleted</code>: A volume that has been marked for deletion, but not yet purged. 	string
totalSize	The total bytes of provisioned capacity.	integer

Name	Description	Type
virtualVolumeID	The unique virtual volume ID associated with the volume, if any.	UUID
volumeAccessGroups	List of IDs of volume access groups to which a volume belongs. This value is an empty list if a volume does not belong to any volume access groups.	integer array
volumeConsistencyGroupUUID	The universally unique ID of the volume consistency group of which the volume is a member.	UUID
volumeID	The unique volumeID for the volume.	integer
volumePairs	Information about a paired volume. Visible only if a volume is paired. This value is an empty list if the volume is not paired.	<i>volumePair</i> array
volumeUUID	The universally unique ID of the volume.	UUID

Related references

[ListActiveVolumes](#) on page 359

[ListDeletedVolumes](#) on page 362

[ListVolumes](#) on page 369

[ListVolumesForAccount](#) on page 375

[QoS](#) on page 56

volumeAccessGroup

The `volumeAccessGroup` object contains information about a specific volume access group. You can retrieve a list of this information for all access groups with the API method `ListVolumeAccessGroups`.

Object members

This object contains the following members:

Name	Description	Type
attributes	List of name-value pairs in JSON object format.	JSON object
deletedVolumes	Array of volumes that have been deleted from the volume access group that have not yet been purged from the system.	integer array
initiatorIDs	A list of IDs of initiators that are mapped to the volume access group.	integer array
initiators	Array of unique IQN/WWPN initiators that are mapped to the volume access group.	string array
name	Name of the volume access group.	string

Name	Description	Type
volumeAccessGroupID	Unique VolumeAccessGroupID identifier for the volume access group.	integer
volumes	A list of VolumeIDs belonging to the volume access group.	integer array

Related references

[ListVolumeAccessGroups](#) on page 374

volumePair

The `volumePair` object contains information about a volume that is paired with another volume on a different cluster. If the volume is not paired, this object is empty. You can use the `ListActivePairedVolumes` and `ListActiveVolumes` API methods to return information about paired volumes.

Object members

This object contains the following members:

Name	Description	Type
clusterPairID	The cluster on which the volume is paired.	integer
remoteReplication	Details on volume replication. Members: <ul style="list-style-type: none"> <code>mode</code>: (string) One of "Async", "Sync", or "SnapshotsOnly". <code>pauseLimit</code>: (integer) Internal use only. <code>remoteServiceID</code>: (integer) The remote slice service ID. <code>resumeDetails</code>: (string) Reserved for future use. <code>snapshotReplication</code> (JSON object) <ul style="list-style-type: none"> <code>state</code>: (string) The state of the ongoing snapshot replication, if one is in progress. <code>stateDetails</code>: (string) Reserved for future use. <code>state</code>: (string) The state of the volume replication. <code>stateDetails</code>: (string) Reserved for future use. 	JSON object
remoteSliceID	The cluster-defined slice ID on the remote cluster.	integer
remoteVolumeID	The ID of the volume on the remote cluster that the local volume is paired with.	integer
remoteVolumeName	The name of the remote volume.	string

Name	Description	Type
volumePairUUID	A universally unique, cluster-defined identifier for this pairing in a canonical format.	string

Related references

[ListActivePairedVolumes](#) on page 250

[ListActiveVolumes](#) on page 359

volumeStats

The `volumeStats` object contains statistical data for an individual volume.

You can use the following methods to get `volumeStats` objects for some or all volumes:

- [GetVolumeStats](#)
- [ListVolumeStatsByAccount](#)
- [ListVolumeStatsByVolume](#)
- [ListVolumeStatsByVolumeAccessGroup](#)

Object members

This object contains the following members:

Name	Description	Calculation	Type
accountID	The ID of the account of the volume owner.	N/A	integer
actualIOPS	The current actual IOPS to the volume in the last 500 milliseconds.	Point in time	integer
asyncDelay	The length of time since the volume was last synced with the remote cluster. If the volume is not paired, this is null. Note: A target volume in an active replication state always has an <code>asyncDelay</code> of 0 (zero). Target volumes are system-aware during replication and assume <code>asyncDelay</code> is accurate at all times.	N/A	ISO 8601 duration string or null
averageIOPSize	The average size in bytes of recent I/O to the volume in the last 500 milliseconds.	Point in time	integer
burstIOPSCredit	The total number of IOP credits available to the user. When volumes are not using up to the configured <code>maxIOPS</code> , credits are accrued.	N/A	integer

Name	Description	Calculation	Type
clientQueueDepth	The number of outstanding read and write operations to the volume.	N/A	integer
clusterUtilization	The amount of cluster capacity being utilized.	N/A	float
desiredMetadataHosts	The volume services being migrated to if the volume metadata is getting migrated between volume services. A "null" value means the volume is not migrating.	N/A	JSON object
latencyUsec	The average time, in microseconds, to complete operations to the volume in the last 500 milliseconds. A "0" (zero) value means there is no I/O to the volume.	Point in time	integer
metadataHosts	The volume services on which the volume metadata resides. Possible values: <ul style="list-style-type: none"> primary: The primary metadata (slice) services hosting the volume. liveSecondaries: Secondary metadata (slice) services that are currently in a "live" state. deadSecondaries: Secondary metadata (slice) services that are in a dead state. 	N/A	JSON object
nonZeroBlocks	The total number of 4KiB blocks that contain data after the last garbage collection operation has completed.	N/A	integer
readBytes	The total cumulative bytes read from the volume since the creation of the volume.	Monotonically increasing	integer
readBytesLastSample	The total number of bytes read from the volume during the last sample period.	Point in time	integer
readLatencyUsec	The average time, in microseconds, to complete read operations to the volume in the last 500 milliseconds.	Point in time	integer
readLatencyUsecTotal	The total time spent performing read operations from the volume.	Monotonically increasing	integer

Name	Description	Calculation	Type
readOps	The total read operations to the volume since the creation of the volume.	Monotonically increasing	integer
readOpsLastSample	The total number of read operations during the last sample period.	Point in time	integer
samplePeriodMSec	The length of the sample period, in milliseconds.	N/A	integer
throttle	A floating value between 0 and 1 that represents how much the system is throttling clients below their maxIOPS because of re-replication of data, transient errors, and snapshots taken.	N/A	float
timestamp	The current time in UTC+0 format.	N/A	ISO 8601 date string
unalignedReads	The total cumulative unaligned read operations to a volume since the creation of the volume.	Monotonically increasing	integer
unalignedWrites	The total cumulative unaligned write operations to a volume since the creation of the volume.	Monotonically increasing	integer
volumeAccessGroups	The list of IDs of volume access group(s) to which a volume belongs.	N/A	integer array
volumeID	The ID of the volume.	N/A	integer
volumeSize	Total provisioned capacity in bytes.	N/A	integer
volumeUtilization	<p>A floating value that describes how much the client is using the volume. Possible values:</p> <ul style="list-style-type: none"> 0: The client is not using the volume. 1: The client is using their maximum. >1: The client is using their burst. 	N/A	float
writeBytes	The total cumulative bytes written to the volume since the creation of the volume.	Monotonically increasing	integer
writeBytesLastSample	The total number of bytes written to the volume during the last sample period.	Monotonically increasing	integer

Name	Description	Calculation	Type
writeLatencyUsec	The average time, in microseconds, to complete write operations to a volume in the last 500 milliseconds.	Point in time	integer
writeLatencyUsecTotal	The total time spent performing write operations to the volume.	Monotonically increasing	integer
writeOps	The total cumulative write operations to the volume since the creation of the volume.	Monotonically increasing	integer
writeOpsLastSample	The total number of write operations during the last sample period.	Point in time	integer
zeroBlocks	The total number of empty 4KiB blocks without data after the last round of garbage collection operation has completed.	Point in time	integer

Common methods

Common methods are methods used to retrieve information about the storage cluster, the API itself, or ongoing API operations.

GetAPI

You can use the `GetAPI` method to get a list of all the API methods and supported API endpoints that can be used in the system.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
<version>	A list of all supported API methods for this software version, where <version> is the current software version this system is running.	string array
currentVersion	The current version of the storage cluster software.	string
supportedVersions	A list of all API endpoints supported by the system.	string array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetAPI",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "10.3": [
      "AbortSnapMirrorRelationship",
      "AddAccount",
      "AddClusterAdmin",
      "AddDrives",
      "AddInitiatorsToVolumeAccessGroup",
      "AddLdapClusterAdmin",
      "AddNodes",
      "AddVirtualNetwork",
      "AddVolumesToVolumeAccessGroup",

```

```

"BreakSnapMirrorRelationship",
"BreakSnapMirrorVolume",
"CancelClone",
"CancelGroupClone",
"ClearClusterFaults",
"CloneMultipleVolumes",
"CloneVolume",
"CompleteClusterPairing",
"CompleteVolumePairing",
"CopyVolume",
"CreateBackupTarget",
"CreateClusterSupportBundle",
"CreateGroupSnapshot",
"CreateInitiators",
"CreateQoSPolicy",
"CreateSchedule",
"CreateSnapMirrorEndpoint",
"CreateSnapMirrorEndpointUnmanaged",
"CreateSnapMirrorRelationship",
"CreateSnapMirrorVolume",
"CreateSnapshot",
"CreateStorageContainer",
"CreateSupportBundle",
"CreateVolume",
"CreateVolumeAccessGroup",
"DeleteAllSupportBundles",
"DeleteGroupSnapshot",
"DeleteInitiators",
"DeleteQoSPolicy",
"DeleteSnapMirrorEndpoints",
"DeleteSnapMirrorRelationships",
"DeleteSnapshot",
"DeleteStorageContainers",
"DeleteVolume",
"DeleteVolumeAccessGroup",
"DeleteVolumes",
"DisableAutoip",
"DisableBmcColdReset",
"DisableClusterSsh",
"DisableEncryptionAtRest",
"DisableLdapAuthentication",
"DisableSnmp",
"EnableAutoip",
"EnableBmcColdReset",
"EnableClusterSsh",
"EnableEncryptionAtRest",
"EnableFeature",
"EnableLdapAuthentication",
"EnableSnmp",
"GetAccountByID",
"GetAccountByName",
"GetAccountEfficiency",
"GetAsyncResult",
"GetBackupTarget",
"GetClusterCapacity",
"GetClusterConfig",
"GetClusterFullThreshold",
"GetClusterHardwareInfo",
"GetClusterInfo",
"GetClusterMasterNodeID",
"GetClusterSshInfo",
"GetClusterState",
"GetClusterStats",
"GetClusterStructure",
"GetClusterVersionInfo",
"GetCompleteStats",
"GetConfig",
"GetCurrentClusterAdmin",
"GetDefaultQoS",
"GetDriveHardwareInfo",
"GetDriveStats",

```

```

"GetFeatureStatus",
"GetFipsReport",
"GetHardwareConfig",
"GetHardwareInfo",
"GetIpmiConfig",
"GetIpmiInfo",
"GetLdapConfiguration",
"GetLimits",
"GetLoginBanner",
"GetLoginSessionInfo",
"GetNetworkConfig",
"GetNetworkInterface",
"GetNodeHardwareInfo",
"GetNodeStats",
"GetNtpInfo",
"GetNvramInfo",
"GetOntapVersionInfo",
"GetOrigin",
"GetPendingOperation",
"GetQoSPolicy",
"GetRawStats",
"GetRemoteLoggingHosts",
"GetSSLCertificate",
"GetSchedule",
"GetSnapMirrorClusterIdentity",
"GetSnmpACL",
"GetSnmpInfo",
"GetSnmpState",
"GetSnmpTrapInfo",
"GetStorageContainerEfficiency",
"GetSystemStatus",
"GetVirtualVolumeCount",
"GetVolumeAccessGroupEfficiency",
"GetVolumeAccessGroupLunAssignments",
"GetVolumeCount",
"GetVolumeEfficiency",
"GetVolumeStats",
"InitializeSnapMirrorRelationship",
"ListAccounts",
"ListActiveNodes",
"ListActivePairedVolumes",
"ListActiveVolumes",
"ListAllNodes",
"ListAsyncResults",
"ListBackupTargets",
"ListBulkVolumeJobs",
"ListClusterAdmins",
"ListClusterFaults",
"ListClusterPairs",
"ListDeletedVolumes",
"ListDriveHardware",
"ListDriveStats",
"ListDrives",
"ListEvents",
"ListFibreChannelPortInfo",
"ListFibreChannelSessions",
"ListGroupSnapshots",
"ListISCSISessions",
"ListInitiators",
"ListNetworkInterfaces",
"ListNodeFibreChannelPortInfo",
"ListNodeStats",
"ListPendingActiveNodes",
"ListPendingNodes",
"ListProtocolEndpoints",
"ListQoS Policies",
"ListSchedules",
"ListServices",
"ListSnapMirrorAggregates",
"ListSnapMirrorEndpoints",
"ListSnapMirrorLuns",

```

```

"ListSnapMirrorNetworkInterfaces",
"ListSnapMirrorNodes",
"ListSnapMirrorPolicies",
"ListSnapMirrorRelationships",
"ListSnapMirrorSchedules",
"ListSnapMirrorVolumes",
"ListSnapMirrorVservers",
"ListSnapshots",
"ListStorageContainers",
"ListSyncJobs",
"ListTests",
"ListUtilities",
"ListVirtualNetworks",
"ListVirtualVolumeBindings",
"ListVirtualVolumeHosts",
"ListVirtualVolumeTasks",
"ListVirtualVolumes",
"ListVolumeAccessGroups",
"ListVolumeStats",
"ListVolumeStatsByAccount",
"ListVolumeStatsByVirtualVolume",
"ListVolumeStatsByVolume",
"ListVolumeStatsByVolumeAccessGroup",
"ListVolumes",
"ListVolumesForAccount",
"ModifyAccount",
"ModifyBackupTarget",
"ModifyClusterAdmin",
"ModifyClusterFullThreshold",
"ModifyGroupSnapshot",
"ModifyInitiators",
"ModifyQoSPolicy",
"ModifySchedule",
"ModifySnapMirrorEndpoint",
"ModifySnapMirrorEndpointUnmanaged",
"ModifySnapMirrorRelationship",
"ModifySnapshot",
"ModifyStorageContainer",
"ModifyVirtualNetwork",
"ModifyVolume",
"ModifyVolumeAccessGroup",
"ModifyVolumeAccessGroupLunAssignments",
"ModifyVolumePair",
"ModifyVolumes",
"PurgeDeletedVolume",
"PurgeDeletedVolumes",
"QuiesceSnapMirrorRelationship",
"RemoveAccount",
"RemoveBackupTarget",
"RemoveClusterAdmin",
"RemoveClusterPair",
"RemoveDrives",
"RemoveInitiatorsFromVolumeAccessGroup",
"RemoveNodes",
"RemoveSSLCertificate",
"RemoveVirtualNetwork",
"RemoveVolumePair",
"RemoveVolumesFromVolumeAccessGroup",
"ResetDrives",
"ResetNode",
"RestartNetworking",
"RestartServices",
"RestoreDeletedVolume",
"ResumeSnapMirrorRelationship",
"ResyncSnapMirrorRelationship",
"RollbackToGroupSnapshot",
"RollbackToSnapshot",
"SecureEraseDrives",
"SetClusterConfig",
"SetClusterStructure",
"SetConfig",

```

```

        "SetDefaultQoS",
        "SetLoginBanner",
        "SetLoginSessionInfo",
        "SetNetworkConfig",
        "SetNtpInfo",
        "SetRemoteLoggingHosts",
        "SetSSLCertificate",
        "SetSnmpACL",
        "SetSnmpInfo",
        "SetSnmpTrapInfo",
        "Shutdown",
        "SnmpSendTestTraps",
        "StartBulkVolumeRead",
        "StartBulkVolumeWrite",
        "StartClusterPairing",
        "StartVolumePairing",
        "TestConnectEnsemble",
        "TestConnectMvip",
        "TestConnectSvip",
        "TestDrives",
        "TestHardwareConfig",
        "TestLdapAuthentication",
        "TestLocalConnectivity",
        "TestLocateCluster",
        "TestNetworkConfig",
        "TestPing",
        "TestRemoteConnectivity",
        "UpdateBulkVolumeStatus",
        "UpdateSnapMirrorRelationship"
    ],
    "currentVersion": "10.3",
    "supportedVersions": [
        "1.0",
        "2.0",
        "3.0",
        "4.0",
        "5.0",
        "5.1",
        "6.0",
        "7.0",
        "7.1",
        "7.2",
        "7.3",
        "7.4",
        "8.0",
        "8.1",
        "8.2",
        "8.3",
        "8.4",
        "8.5",
        "8.6",
        "8.7",
        "9.0",
        "9.1",
        "9.2",
        "9.3",
        "9.4",
        "9.5",
        "10.0",
        "10.1",
        "10.2",
        "10.3"
    ]
}
}

```

GetAsyncResult

You can use `GetAsyncResult` to retrieve the result of asynchronous method calls. Some method calls require some time to run, and might not be finished when the system sends the initial response. To obtain the status or result of the method call, use `GetAsyncResult` to poll the `asyncHandle` value returned by the method.

`GetAsyncResult` returns the overall status of the operation (in progress, completed, or error) in a standard fashion, but the actual data returned for the operation depends on the original method call and the return data is documented with each method.

If the `keepResult` parameter is missing or false, the `asyncHandle` becomes inactive when the result is returned, and later attempts to query that `asyncHandle` return an error. You can keep the `asyncHandle` active for future queries by setting the `keepResult` parameter to `true`.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>asyncHandle</code>	A value that was returned from the original asynchronous method call.	integer	None	Yes
<code>keepResult</code>	If true, <code>GetAsyncResult</code> does not remove the asynchronous result upon returning it, enabling future queries to that <code>asyncHandle</code> .	boolean	false	No

Return values

This method has the following return values:

Name	Description	Type
<code>status</code>	Status of the asynchronous method call. Possible values: <ul style="list-style-type: none"><code>running</code>: The method is still running.<code>complete</code>: The method is complete and the result or error is available.	string
<code>result</code>	If the asynchronous method successfully completed, this is the result of the asynchronous operation. If the asynchronous operation failed, this member is not present.	string
<code>error</code>	If the status is complete and the asynchronous method failed, this member includes the error details. If the asynchronous operation succeeded, this member is not present.	string

Name	Description	Type
resultType	The type of operation the asynchronous method call is or was performing.	string
details	If the status is running, this member includes information relevant to the method's current operation. If the asynchronous method is not running, this member is not present.	JSON Object
createTime	The time that the asynchronous method was called, in UTC+0 format.	ISO 8601 date string
lastUpdateTime	The time that the asynchronous method's status was last updated, in UTC+0 format.	ISO 8601 date string

Note: The return value of `GetAsyncResult` is essentially a nested version of the standard JSON response with an additional status field.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetAsyncResult",
  "params": {
    "asyncHandle" : 389
  },
  "id" : 1
}
```

Response example: method error

This method returns a response similar to the following example:

```
{
  "error": {
    "code": 500,
    "message": "DBClient operation requested on a non-existent path at [/asyncresults/1]",
    "name": "xDBNoSuchPath"
  },
  "id": 1
}
```

If "response" were the JSON response object from the `GetAsyncResult` call, then "response.error" would correspond to an error with the `GetAsyncResult` method itself (such as querying a non-existent `asyncHandle`).

Response example: asynchronous task error

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "createTime": "2016-01-01T02:05:53Z",
    "error": {
      "bvID": 1,
      "message": "Bulk volume job failed",
      "name": "xBulkVolumeScriptFailure",
      "volumeID": 34
    }
  }
}
```

```

    },
    "lastUpdateTime": "2016-01-21T02:06:56Z",
    "resultType": "BulkVolume",
    "status": "complete"
  }
}

```

The “response.result.error” would correspond to an error result from the original method call.

Response example: asynchronous task success

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "createTime": "2016-01-01T22:29:18Z",
    "lastUpdateTime": "2016-01-01T22:45:51Z",
    "result": {
      "cloneID": 25,
      "message": "Clone complete.",
      "volumeID": 47
    },
    "resultType": "Clone",
    "status": "complete"
  }
}

```

The “response.result.result” is the return value for the original method call if the call completed successfully.

GetCompleteStats

NetApp engineering uses the `GetCompleteStats` API method to test new features. The data returned from `GetCompleteStats` is not documented, changes frequently, and is not guaranteed to be accurate. You should not use `GetCompleteStats` for collecting performance data or any other management integration with a storage cluster running Element software.

Use the following supported API methods to retrieve statistical information:

- [*GetVolumeStats*](#)
- [*GetClusterStats*](#)
- [*GetNodeStats*](#)
- [*GetDriveStats*](#)

GetLimits

You can use the `GetLimits` method to get the limit values set by the API. These values might change between releases of Element, but do not change without an update to the system. Knowing the limit values set by the API can be useful when writing API scripts for user-facing tools.

Note: The `GetLimits` method returns the limits for the current software version regardless of the API endpoint version used to pass the method.

Parameters

This method has no input parameters.

Return values

This method returns a JSON object with name-value pairs containing the API limits.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetLimits",
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "accountCountMax": 5000,
    "accountNameLengthMax": 64,
    "accountNameLengthMin": 1,
    "backupTargetNameLengthMax": 64,
    "backupTargetNameLengthMin": 1,
    "bulkVolumeJobsPerNodeMax": 8,
    "bulkVolumeJobsPerVolumeMax": 2,
    "cloneJobsPerNodeMax": 8,
    "cloneJobsPerVirtualVolumeMax": 8,
    "cloneJobsPerVolumeMax": 2,
    "clusterAdminAccountMax": 5000,
    "clusterAdminInfoNameLengthMax": 1024,
    "clusterAdminInfoNameLengthMin": 1,
    "clusterPairsCountMax": 4,
    "fibreChannelVolumeAccessMax": 16384,
    "initiatorAliasLengthMax": 224,
    "initiatorCountMax": 10000,
    "initiatorNameLengthMax": 224,
    "initiatorsPerVolumeAccessGroupCountMax": 128,
    "iscsiSessionsFromFibreChannelNodesMax": 4096,
    "qosPolicyCountMax": 500,
    "qosPolicyNameLengthMax": 64,
    "qosPolicyNameLengthMin": 1,
    "scheduleNameLengthMax": 244,
    "secretLengthMax": 16,
    "secretLengthMin": 12,
    "snapMirrorEndpointIPAddressesCountMax": 64,
    "snapMirrorEndpointsCountMax": 4,
    "snapMirrorLabelLengthMax": 31,
    "snapMirrorObjectAttributeValueInfoCountMax": 9900000,
    "snapshotNameLengthMax": 255,
    "snapshotsPerVolumeMax": 32,
    "virtualVolumeCountMax": 4000,
    "virtualVolumesPerAccountCountMax": 10000,
    "volumeAccessGroupCountMax": 1000,
    "volumeAccessGroupLunMax": 16383,
    "volumeAccessGroupNameLengthMax": 64,
    "volumeAccessGroupNameLengthMin": 1,
    "volumeAccessGroupsPerInitiatorCountMax": 1,
    "volumeAccessGroupsPerVolumeCountMax": 64,
    "volumeBurstIOPSMMax": 200000,
    "volumeBurstIOPSMin": 100,
    "volumeCountMax": 2000,
    "volumeMaxIOPSMMax": 200000,
    "volumeMaxIOPSMin": 100,
    "volumeMinIOPSMMax": 15000,
    "volumeMinIOPSMin": 50,
    "volumeNameLengthMax": 64,
```

```

        "volumeNameLengthMin": 1,
        "volumeSizeMax": 8796093022208,
        "volumeSizeMin": 1000000000,
        "volumesPerAccountCountMax": 2000,
        "volumesPerGroupSnapshotMax": 32,
        "volumesPerVolumeAccessGroupCountMax": 2000
    }
}

```

GetOrigin

You can use the `GetOrigin` method to get the origination certificate for where the node was built.

Note: This method returns "null" if there is no origination certification.

Parameters

This method has no input parameters.

Return value

This method returns vendor origination certification information.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetOrigin",
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "integrator": "SolidFire",
  "<signature>": {
    "pubkey": [public key info],
    "version": 1,
    "data": [signature info]
  },
  "contract-id": "none",
  "location": "Boulder, CO",
  "organization": "Engineering",
  "type": "element-x"
}
]
}

```

GetRawStats

NetApp engineering uses the `GetRawStats` API method to test new features. The data returned from `GetRawStats` is not documented, changes frequently, and is not guaranteed to be accurate. You should not use `GetRawStats` for collecting performance data or any other management integration with a storage cluster running Element software.

Use the following supported API methods to retrieve statistical information:

- [GetVolumeStats](#)
- [GetClusterStats](#)
- [GetNodeStats](#)
- [GetDriveStats](#)

ListAsyncResults

You can use `ListAsyncResults` to list the results of all currently running and completed asynchronous methods on the system. Querying asynchronous results with `ListAsyncResults` does not cause completed `asyncHandles` to expire; you can use `GetAsyncResult` to query any of the `asyncHandles` returned by `ListAsyncResults`.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>asyncResultTypes</code>	<p>An optional list of types of results. You can use this list to restrict the results to only these types of operations. Possible values:</p> <ul style="list-style-type: none"> • <code>DriveAdd</code>: Operations involving the system adding a drive to the cluster. • <code>BulkVolume</code>: Copy operations between volumes, such as backups or restores. • <code>Clone</code>: Volume cloning operations. • <code>DriveRemoval</code>: Operations involving the system copying data from a drive in preparation to remove it from the cluster. • <code>RtFiPendingNode</code>: Operations involving the system installing compatible software on a node before adding it to the cluster. 	string array	None	No

Return value

This method has the following return value:

Name	Description	Type
asyncHandles	An array of serialized asynchronous method results.	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListAsyncResults",
  "params": {
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "asyncHandles": [
      {
        "asyncResultID": 47,
        "completed": true,
        "createTime": "2016-01-01T22:29:19Z",
        "data": {
          "cloneID": 26,
          "message": "Clone complete.",
          "volumeID": 48
        },
        "lastUpdateTime": "2016-01-01T22:45:43Z",
        "resultType": "Clone",
        "success": true
      },
      ...
    ]
  }
}
```

Related references

[GetAsyncResult](#) on page 94

Account methods

Account methods enable you to add, remove, view, and modify account and security information.

AddAccount

You can use `AddAccount` to add a new account to the system. You can also use this method to create new volumes under the new account as the account is created. The CHAP settings you specify for the account apply to all volumes owned by the account.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>username</code>	The unique username for this account. (Must be 1 to 64 characters in length).	string	None	Yes
<code>initiatorSecret</code>	The CHAP secret to use for the initiator. This secret must be 12 to 16 characters in length and should be impenetrable. The initiator CHAP secret must be unique and cannot be the same as the target CHAP secret. If not specified, a random secret is created.	string	None	No
<code>targetSecret</code>	The CHAP secret to use for the target (mutual CHAP authentication). This secret must be 12 to 16 characters in length and should be impenetrable. The target CHAP secret must be unique and cannot be the same as the initiator CHAP secret. If not specified, a random secret is created.	string	None	No
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object	None	No

Return value

This method has the following return value:

Name	Description	Type
account	An object containing information about the newly created account.	<i>account</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "AddAccount",
  "params": {
    "username" : "bobsmith",
    "initiatorSecret" : "168[#5A757ru268)",
    "targetSecret" : "tlt&lt;,8TUYa7bC",
    "attributes" : {
      "billingcode" : 2345
    }
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "account": {
      "accountID": 90,
      "attributes": {
        "billingcode": 2345
      },
      "initiatorSecret": "168[#5A757ru268)",
      "status": "active",
      "storageContainerID": "00000000-0000-0000-0000-000000000000",
      "targetSecret": "tlt&lt;,8TUYa7bC",
      "username": "bobsmith",
      "volumes": []
    },
    "accountID": 90
  }
}
```

GetAccountByID

You can use `GetAccountByID` to get details about a specific account, given its `accountID`.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
accountID	Specifies the account for which details are gathered.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
account	Account details.	<i>account</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetAccountByID",
  "params": {
    "accountID" : 3
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "account" : {
      "accountID" : 3,
      "attributes" : {},
      "initiatorSecret" : "initiatorsecret",
      "status" : "active",
      "targetSecret" : "initiatorsecret",
      "username" : "account3",
      "volumes" : [
        14,
        15,
        16
      ]
    }
  }
}
```

GetAccountByName

You can use `GetAccountByName` to get details about a specific account, given its username.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
username	Username for the account.	string	None	Yes

Return value

This method has the following return value:

Name	Description	Type
account	Account details.	<i>account</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetAccountByName",
  "params": {
    "username" : "jimmyd"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "account" : {
      "accountID" : 3,
      "attributes" : {},
      "initiatorSecret" : "initiatorsecret",
      "status" : "active",
      "targetSecret" : "initiatorsecret",
      "username" : "jimmyd",
      "volumes" : [
        14,
        15,
        16
      ]
    }
  }
}
```

GetAccountEfficiency

You can use `GetAccountEfficiency` to get efficiency statistics about a volume account. This method returns efficiency information only for the account you give as a parameter.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
accountID	Specifies the volume account for which efficiency statistics are returned.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
compression	The amount of space saved by data compression for all volumes in the account. Stated as a ratio where a value of "1" means data has been stored with no compression.	float
deduplication	The amount of space saved by not duplicating data for all volumes in the account. Stated as a ratio.	float
missingVolumes	The volumes that could not be queried for efficiency data. Missing volumes can be caused by the Garbage Collection (GC) cycle being less than an hour old, temporary loss of network connectivity, or restarted services since the GC cycle.	integer array
thinProvisioning	The ratio of space used to the amount of space allocated for storing data. Stated as a ratio.	float
timestamp	The last time efficiency data was collected after Garbage Collection (GC), in UTC+0 format.	ISO 8601 date string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetAccountEfficiency",
  "params": {
    "accountID": 3
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "compression": 2.020468042933262,
    "deduplication": 2.042488619119879,
    "missingVolumes": [],
    "thinProvisioning": 1.010087163391013,
    "timestamp": "2014-03-10T14:06:02Z"
  }
}
```

ListAccounts

You can use `ListAccounts` to get the entire list of accounts, with optional paging support.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>includeStorageContainers</code>	Virtual volume storage containers are included in the response by default. To exclude storage containers, set to <code>false</code> .	boolean	<code>true</code>	No
<code>startAccountID</code>	Starting <code>accountID</code> to return. If no account exists with this <code>accountID</code> , the next account by <code>accountID</code> order is used as the start of the list. To page through the list, pass the <code>accountID</code> of the last account in the previous response + 1.	integer	None	No
<code>limit</code>	Maximum number of account objects to return.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>accounts</code>	The list of accounts.	account array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListAccounts",
  "params": {
    "startAccountID" : 0,
    "limit" : 1000
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "result" : {
    "accounts" : [
      {
        "accountID" : 25,
        "username" : "jimmyd",
        "status" : "active",
        "initiatorSecret" : "168[#5A757ru268)",
        "targetSecret" : "168[#5A757ru268)",
        "attributes" : {},
        "volumes" : [6,7,20]
      },
      {
        "accountID" : 26,
        "username" : "jamesw",
        "status" : "active",
        "initiatorSecret" : "initiatorsecret",
        "targetSecret" : "targetsecret",
        "attributes" : {
          "billingcode" : "1234R"
        },
        "volumes" : [23,64]
      }
    ],
    "id" : 1
  }
}
```

ModifyAccount

You can use the `ModifyAccount` method to modify an existing account.

When you lock an account, any existing connections from that account are immediately terminated. When you change an account's CHAP settings, any existing connections remain active, and the new CHAP settings are used on subsequent connections or reconnections. To clear an account's attributes, specify {} for the attributes parameter.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
accountID	AccountID for the account to modify.	integer	None	Yes
status	Status for the account: active: Account is active and connections are allowed. locked: Account is locked and connections are refused.	string	None	No

Name	Description	Type	Default value	Required
initiatorSecret	The CHAP secret to use for the initiator. This secret must be 12-16 characters in length and should be impenetrable. The initiator CHAP secret must be unique and cannot be the same as the target CHAP secret.	string	None	No
targetSecret	The CHAP secret to use for the target (mutual CHAP authentication). This secret must be 12-16 characters in length and should be impenetrable. The target CHAP secret must be unique and cannot be the same as the initiator CHAP secret.	string	None	No
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
username	Used to change the username associated with the account. (Must be 1 to 64 characters in length).	string	None	No

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example. In this example, the attributes are cleared by specifying {} for them:

```
{
  "method": "ModifyAccount",
  "params": {
    "accountID" : 25,
    "status"    : "locked",
    "attributes" : {}
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
```

```
"result" : { }
}
```

RemoveAccount

You can use the `RemoveAccount` method to remove an existing account. You must delete and purge all volumes associated with the account using `DeleteVolume` before you can remove the account. If volumes on the account are still pending deletion, you cannot use `RemoveAccount` to remove the account.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
accountID	The ID of the account to remove.	integer	None	Yes

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example.

```
{
  "method": "RemoveAccount",
  "params": {
    "accountID" : 25
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : { }
}
```

Related references

[DeleteVolume](#) on page 346

Administrator API methods

You can use administrator API methods to create, modify, view, and remove storage cluster administrators and assign levels of access and privileges for those with access to a storage cluster.

AddClusterAdmin

You can use the `AddClusterAdmin` method to add a new cluster admin account. A cluster admin can manage the cluster via the API and management tools. Cluster admins are completely separate and unrelated to standard tenant accounts.

Each cluster admin can be restricted to a subset of the API. You should use multiple cluster admin accounts for different users and applications. As a best practice, give each cluster admin the minimal permissions necessary; this reduces the potential impact of credential compromise.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>access</code>	Controls which methods the cluster admin can use.	string array	None	Yes
<code>acceptEula</code>	Accept the End User License Agreement. Set to <code>true</code> to add a cluster administrator account to the system. If omitted or set to <code>false</code> , the method call fails.	boolean	None	Yes
<code>attributes</code>	List of name/value pairs in JSON object format.	JSON object	None	No
<code>password</code>	Password used to authenticate this cluster admin.	string	None	Yes

Name	Description	Type	Default value	Required
username	Unique username for this cluster admin. Must be between 1 and 1024 characters in length.	string	None	Yes

Return value

This method has the following return value:

Name	Description	Type
clusterAdminID	ClusterAdminID for the newly created cluster admin.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "AddClusterAdmin",
  "params": {
    "username": "joeadmin",
    "password": "68!5Aru268)$",
    "attributes": {},
    "acceptEula": true,
    "access": ["volumes", "reporting", "read"]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterAdminID": 2
  }
}
```

Related references

[Access control](#) on page 468

GetCurrentClusterAdmin

You can use the `GetCurrentClusterAdmin` method to return information for the current primary Cluster Admin. The primary Cluster Admin was created when the cluster was created.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
clusterAdmin	Information about the cluster admin.	<i>clusterAdmin</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetCurrentClusterAdmin",
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterAdmin": {
      "access": [
        "administrator"
      ],
      "attributes": null,
      "authMethod": "Cluster",
      "clusterAdminID": 1,
      "username": "admin"
    }
  }
}
```

GetLoginBanner

You can use the `GetLoginBanner` method to get the currently active Terms of Use banner that users see when they log in to the Element web interface.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
banner	The current text of the Terms of Use banner. This value can contain text even when the banner is disabled.	string

Name	Description	Type
enabled	<p>The status of the Terms of Use banner. Possible values:</p> <ul style="list-style-type: none"> <code>true</code>: The Terms of Use banner is displayed upon web interface login. <code>false</code>: The Terms of Use banner is not displayed upon web interface login. 	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "id": 3411,
  "method": "GetLoginBanner",
  "params": {}
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 3411,
  "result": {
    "loginBanner": {
      "banner": "Welcome to NetApp!",
      "enabled": false
    }
  }
}
```

ListClusterAdmins

You can use the `ListClusterAdmins` method to return the list of all cluster administrators for the cluster.

There can be several cluster administrator accounts with different levels of permissions. There can be only one primary cluster administrator in the system. The primary Cluster Admin is the administrator that was created when the cluster was created. LDAP administrators can also be created when setting up an LDAP system on the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
clusterAdmins	Information about all cluster and LDAP administrators that exist for a cluster.	<i>clusterAdmin</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListClusterAdmins",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id":1,
  "result":{
    "clusterAdmins":[
      {
        "access":[
          "administrator"
        ],
        "attributes":null,
        "authMethod":"Cluster",
        "clusterAdminID":1,
        "username":"admin"
      },
      {
        "access":[
          "read",
          "administrator"
        ],
        "attributes":{
        },
        "authMethod":"Ldap",
        "clusterAdminID":7,
        "username":"john.smith"
      },
      {
        "access":[
          "read",
          "administrator"
        ],
        "attributes":{
        },
        "authMethod":"Ldap",
        "clusterAdminID":6,
        "username":"cn=admin1
jones,ou=ptusers,c=prodtest,dc=solidfire,dc=net"
      }
    ]
  }
}
```

ModifyClusterAdmin

You can use the `ModifyClusterAdmin` method to change the settings for a cluster admin or LDAP cluster admin. You cannot change access for the administrator cluster admin account.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
access	Controls which methods this cluster admin can use.	string array	None	No
attributes	List of Name/Value pairs in JSON object format.	JSON object	None	No
clusterAdminID	ClusterAdminID for the cluster admin or LDAP cluster admin to modify.	integer	None	Yes
password	Password used to authenticate this cluster admin.	string	None	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyClusterAdmin",
  "params": {
    "clusterAdminID" : 2,
    "password"       : "7925Brc429a"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1
  "result" : { }
}
```

Related references

[Access control](#) on page 468

RemoveClusterAdmin

You can use the `RemoveClusterAdmin` method to remove a Cluster Admin. You cannot remove the "admin" Cluster Admin account.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
clusterAdminID	ClusterAdminID for the Cluster Admin to remove.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveClusterAdmin",
  "params": {
    "clusterAdminID" : 2
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1
  "result" : { }
}
```

SetLoginBanner

You can use the `SetLoginBanner` method to configure the Terms of Use banner that users see when they log in to the Element web interface.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
banner	The desired text of the Terms of Use banner. The maximum length allowed is 4,096 characters.	string	None	No
enabled	The status of the Terms of Use banner. Possible values: <ul style="list-style-type: none"> <code>true</code>: The Terms of Use banner is displayed upon web interface login. <code>false</code>: The Terms of Use banner is not displayed upon web interface login. 	boolean	None	No

Return values

This method has the following return values:

Name	Description	Type
banner	The current text of the Terms of Use banner. This value can contain text even when the banner is disabled.	string
enabled	The status of the Terms of Use banner. Possible values: <ul style="list-style-type: none">• <code>true</code>: The Terms of Use banner is displayed upon web interface login.• <code>false</code>: The Terms of Use banner is not displayed upon web interface login.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "id": 3920,
  "method": "SetLoginBanner",
  "params": {
    "banner": "Welcome to NetApp!",
    "enabled": true
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 3920,
  "result": {
    "loginBanner": {
      "banner": "Welcome to NetApp!",
      "enabled": true
    }
  }
}
```

Cluster API methods

Element software cluster API methods enable you to manage the configuration and topology of the storage cluster and the nodes that belong to a storage cluster.

Some cluster API methods operate on nodes that are part of a cluster, or have been configured to join a cluster. You can add nodes to a new cluster or to an existing cluster. Nodes that are ready to be added to a cluster are in a "pending" state, which means they have been configured but not yet added to the cluster.

AddNodes

You can use the `AddNodes` method to add one or more new nodes to a cluster.

When a node that is not configured starts up for the first time, you are prompted to configure the node. Once you configure the node, it is registered as a "pending node" with the cluster. Storage clusters running Element software automatically image a node to the version on the cluster. When you add a pending node, the method response includes an `asyncHandle` value that you can use with the `GetAsyncResult` method to query the status of the automatic imaging process.

The process of adding a Fibre Channel node is the same as adding Element iSCSI storage nodes to a cluster. Fibre Channel nodes are registered in the system with a `NodeID`. When they become accessible, they are put in a "pending node" status. The `ListAllNodes` method will return the `pendingNodeID` for iSCSI nodes as well as any Fibre Channel nodes that are available to add to the cluster.

When you add a node to a cluster that you have configured for virtual networking, the system requires a sufficient number of virtual storage IP addresses to allocate a virtual IP to the new node. If there are no virtual IP addresses available for the new node, the `AddNode` operation fails. Use the `ModifyVirtualNetwork` method to add more storage IP addresses to your virtual network.

Once you add a node, any drives on the node are made available and you can add them using the `AddDrives` method to increase the storage capacity of the cluster.

Note: It may take several seconds after adding a new node for it to start up and register its drives as available.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>pendingNodes</code>	Pending <code>NodeIDs</code> for the nodes to be added. You can obtain the list of pending nodes using the <code>ListPendingNodes</code> method.	integer array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
nodes	An array of objects mapping the previous "pendingNodeID" to the "nodeID". When you add a pending node that is running an incompatible software version, this array includes an asyncHandle value that you can use with the <code>GetAsyncResult</code> method to query the status of the automatic imaging process.	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "AddNodes",
  "params": {
    "pendingNodes" : [1]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  id: null,
  result: {
    autoInstall: true,
    nodes: [
      {
        activeNodeKey: "giAm2ep1hA",
        assignedNodeID: 6,
        asyncHandle: 3,
        cip: "10.10.5.106",
        mip: "192.168.133.106",
        pendingNodeID: 2,
        platformInfo: {
          chassisType: "R620",
          cpuModel: "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
          nodeMemoryGB: 72,
          nodeType: "SF3010"
        },
        sip: "10.10.5.106",
        softwareVersion: "9.0.0.1077"
      }
    ]
  }
}
```

Related references

[AddDrives](#) on page 168

[GetAsyncResult](#) on page 94

[ListAllNodes](#) on page 141

[ModifyVirtualNetwork](#) on page 317

ClearClusterFaults

You can use the `ClearClusterFaults` method to clear information about both current and previously detected faults. Both resolved and unresolved faults can be cleared.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>faultTypes</code>	Determines the types of faults to clear. Possible values: <ul style="list-style-type: none"><code>current</code>: Faults that are detected currently and have not been resolved.<code>resolved</code>: Faults that were previously detected and resolved.<code>all</code>: Both current and resolved faults. The fault status can be determined by the “resolved” field of the fault object.	string	resolved	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ClearClusterFaults",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```


CreateClusterInterfacePreference

The `CreateClusterInterfacePreference` method enables systems integrated with storage clusters running Element software to create and store arbitrary information on the storage cluster. This method is for internal use.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
name	The name of the cluster interface preference.	string	None	Yes
value	The value of the cluster interface preference.	string	None	Yes

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateClusterInterfacePreference",
  "params": {
    "name": "prefname",
    "value": "testvalue"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

DeleteClusterInterfacePreference

The `DeleteClusterInterfacePreference` method enables systems integrated with storage clusters running Element software to delete an existing cluster interface preference. This method is for internal use.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
name	The name of the cluster interface preference to delete.	string	None	Yes

Return values

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteClusterInterfacePreference",
  "params": {
    "name": "prefname"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

DisableEncryptionAtRest

You can use the `DisableEncryptionAtRest` method to remove the encryption that was previously applied to the cluster using the `EnableEncryptionAtRest` method. This disable method is asynchronous and returns a response before encryption is disabled. You can use the `GetClusterInfo` method to poll the system to see when the process has completed.

Parameters

This method has no input parameters.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DisableEncryptionAtRest",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

Related references

[GetClusterInfo](#) on page 131

EnableEncryptionAtRest

You can use the `EnableEncryptionAtRest` method to enable the Advanced Encryption Standard (AES) 256-bit encryption at rest on the cluster so that the cluster can manage the encryption key used for the drives on each node. This feature is not enabled by default.

When you enable Encryption at Rest, the cluster automatically manages encryption keys internally for the drives on each node in the cluster. Nodes do not store the keys to unlock drives and the keys are never passed over the network. Two nodes participating in a cluster are required to access the key to disable encryption on a drive. The encryption management does not affect performance or efficiency on the cluster. If an encryption-enabled drive or node is removed from the cluster with the API, Encryption at Rest is disabled and the data is not secure erased. Data can be secure erased using the `SecureEraseDrives` API method.

Note: If you have a node type with a model number ending in "-NE", the `EnableEncryptionAtRest` method call will fail with a response of "Encryption not allowed. Cluster detected non-encryptable node".

Note: You should only enable or disable encryption when the cluster is running and in a healthy state. You can enable or disable encryption at your discretion and as often as you need.

Note: This process is asynchronous and returns a response before encryption is enabled. You can use the `GetClusterInfo` method to poll the system to see when the process has completed.

Parameters

This method has no input parameters.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "EnableEncryptionAtRest",
  "params": {},
  "id": 1
}
```

Response examples

This method returns a response similar to the following example from the `EnableEncryptionAtRest` method. There is no result to report.

```
{
  "id": 1,
  "result": {}
}
```

While Encryption At Rest is being enabled on a cluster, `GetClusterInfo` returns a result describing the state of Encryption at Rest ("encryptionAtRestState") as "enabling". After Encryption At Rest is fully enabled, the returned state changes to "enabled".

```
{
  "id": 1,
  "result": {
    "clusterInfo": {
      "attributes": { },
      "encryptionAtRestState": "enabling",
      "ensemble": [
        "10.10.5.94",
        "10.10.5.107",
        "10.10.5.108"
      ],
      "mvip": "192.168.138.209",
      "mvipNodeID": 1,
      "name": "Marshall",
      "repCount": 2,
      "svip": "10.10.7.209",
      "svipNodeID": 1,
      "uniqueID": "91dt"
    }
  }
}
```

Related references

[SecureEraseDrives](#) on page 175

[GetClusterInfo](#) on page 131

EnableFeature

You can use the `EnableFeature` method to enable cluster features that are disabled by default.

Parameter

This method has the following input parameter.

Note: For systems running Element software 11.x, enabling virtual volumes before or after setting protection domain monitoring causes the cluster protection domains feature to function only at node level.

Name	Description	Type	Default value	Required
feature	<p>Enable a cluster feature. Possible values:</p> <ul style="list-style-type: none"> <code>vvols</code>: Enable the Element software VVols cluster feature. <code>SnapMirror</code>: Enable the SnapMirror replication cluster feature. <code>fips</code>: Enable FIPS 140-2 certified encryption for HTTPS communications. 	string	None	Yes

Return value

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "EnableFeature",
  "params": {
    "feature" : "vvols"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

GetClusterCapacity

You can use the `GetClusterCapacity` to return high-level capacity measurements for an entire storage cluster. This method returns fields that you can use to calculate the efficiency rates shown in the Element web UI. You can use the efficiency calculations in scripts to return the efficiency rates for thin provisioning, deduplication, compression, and overall efficiency.

Efficiency calculations

Use the following equations to calculate thin provisioning, deduplication, and compression. These equations apply to Element 8.2 and later.

- $\text{thinProvisioningFactor} = (\text{nonZeroBlocks} + \text{zeroBlocks}) / \text{nonZeroBlocks}$

- $\text{deDuplicationFactor} = (\text{nonZeroBlocks} + \text{snapshotNonZeroBlocks}) / \text{uniqueBlocks}$
- $\text{compressionFactor} = (\text{uniqueBlocks} * 4096) / (\text{uniqueBlocksUsedSpace} * 0.93)$

Overall efficiency rate calculation

Use the following equation to calculate overall cluster efficiency using the results of the thin provisioning, deduplication, and compression efficiency calculations.

- $\text{efficiencyFactor} = \text{thinProvisioningFactor} * \text{deDuplicationFactor} * \text{compressionFactor}$

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
clusterCapacity	Capacity measurements for the storage cluster.	<i>clusterCapacity</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterCapacity",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterCapacity": {
      "activeBlockSpace": 236015557096,
      "activeSessions": 20,
      "averageIOPS": 0,
      "clusterRecentIOSize": 0,
      "currentIOPS": 0,
      "maxIOPS": 150000,
      "maxOverProvisionableSpace": 259189767127040,
      "maxProvisionedSpace": 51837953425408,
      "maxUsedMetadataSpace": 404984011161,
      "maxUsedSpace": 12002762096640,
      "nonZeroBlocks": 310080350,
      "peakActiveSessions": 20,
      "peakIOPS": 0,
      "provisionedSpace": 1357931085824,
      "snapshotNonZeroBlocks": 0,
      "timestamp": "2016-10-17T21:24:36Z",
      "totalOps": 1027407650,
      "uniqueBlocks": 108180156,
      "uniqueBlocksUsedSpace": 244572686901,
      "usedMetadataSpace": 8745762816,
      "usedMetadataSpaceInSnapshots": 8745762816,
      "usedSpace": 244572686901,
    }
  }
}
```

```

    "zeroBlocks": 352971938
  }
}

```

GetClusterFullThreshold

You can use the `GetClusterFullThreshold` method to view the stages set for cluster fullness levels. This method returns all fullness metrics for the cluster.

Note: When a cluster reaches the Error stage of block cluster fullness, the maximum IOPS on all volumes are reduced linearly to the volume minimum IOPS as the cluster approaches the Critical stage. This helps prevent the cluster from reaching the Critical stage of block cluster fullness.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
blockFullness	<p>The current computed level of block fullness of the cluster.</p> <ul style="list-style-type: none"> <code>stage1Happy</code>: No alerts or error conditions. Corresponds to the Healthy state in the web UI. <code>stage2Aware</code>: No alerts or error conditions. Corresponds to the Healthy state in the web UI. <code>stage3Low</code>: Your system cannot provide redundant data protection from two non-simultaneous node failures. Corresponds to the Warning state in the web UI. You can configure this level in the web UI (by default, the system triggers this alert at a capacity of 3% below the Error state). <code>stage4Critical</code>: The system is not capable of providing redundant data protection from a single node failure. No new volumes or clones can be created. Corresponds to the Error state in the Element UI. <code>stage5CompletelyConsumed</code>: Completely consumed. The cluster is read-only and iSCSI connections are maintained, but all writes are suspended. Corresponds to the Critical state in the Element UI. 	string
fullness	Reflects the highest level of fullness between "blockFullness" and "metadataFullness".	string

Name	Description	Type
maxMetadataOverProvisionFactor	A value representative of the number of times metadata space can be over provisioned relative to the amount of space available. For example, if there was enough metadata space to store 100 TiB of volumes and this number was set to 5, then 500 TiB worth of volumes could be created.	integer
metadataFullness	<p>The current computed level of metadata fullness of the cluster.</p> <ul style="list-style-type: none"> stage1Happy: No alerts or error conditions. Corresponds to the Healthy state in the web UI. stage2Aware: No alerts or error conditions. Corresponds to the Healthy state in the web UI. stage3Low: Your system cannot provide redundant data protection from two non-simultaneous node failures. Corresponds to the Warning state in the web UI. You can configure this level in the web UI (by default, the system triggers this alert at a capacity of 3% below the Error state). stage4Critical: The system is not capable of providing redundant data protection from a single node failure. No new volumes or clones can be created. Corresponds to the Error state in the Element UI. stage5CompletelyConsumed: Completely consumed. The cluster is read-only and iSCSI connections are maintained, but all writes are suspended. Corresponds to the Critical state in the Element UI. 	string
sliceReserveUsedThresholdPct	Error condition. A system alert is triggered if the reserved slice utilization is greater than the sliceReserveUsedThresholdPct value returned.	integer
stage2AwareThreshold	Awareness condition. The value that is set for "Stage 2" cluster threshold level.	integer
stage2BlockThresholdBytes	Number of bytes being used by the cluster at which a stage2 condition will exist.	integer
stage3BlockThresholdBytes	Number of bytes being used by the cluster at which a stage3 condition will exist.	integer
stage3BlockThresholdPercent	Percent value set for stage3. At this percent full, a warning is posted in the Alerts log.	integer
stage3LowThreshold	Error condition. The threshold at which a system alert is created due to low capacity on a cluster.	integer

Name	Description	Type
stage4BlockThresholdBytes	Number of bytes being used by the cluster at which a stage4 condition will exist.	integer
stage4CriticalThreshold	Error condition. The threshold at which a system alert is created to warn about critically low capacity on a cluster.	integer
stage5BlockThresholdBytes	The number of bytes being used by the cluster at which a stage5 condition will exist.	integer
sumTotalClusterBytes	Physical capacity of the cluster, measured in bytes.	integer
sumTotalMetadataClusterBytes	Total amount of space that can be used to store metadata.	integer
sumUsedClusterBytes	Number of bytes used on the cluster.	integer
sumUserMetadataClusterBytes	Amount of space used on volume drives to store metadata.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method" : "GetClusterFullThreshold",
  "params" : {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id":1,
  "result":{
    "blockFullness":"stage1Happy",
    "fullness":"stage3Low",
    "maxMetadataOverProvisionFactor":5,
    "metadataFullness":"stage3Low",
    "sliceReserveUsedThresholdPct":5,
    "stage2AwareThreshold":3,
    "stage2BlockThresholdBytes":2640607661261,
    "stage3BlockThresholdBytes":8281905846682,
    "stage3BlockThresholdPercent":5,
    "stage3LowThreshold":2,
    "stage4BlockThresholdBytes":8641988709581,
    "stage4CriticalThreshold":1,
    "stage5BlockThresholdBytes":12002762096640,
    "sumTotalClusterBytes":12002762096640,
    "sumTotalMetadataClusterBytes":404849531289,
    "sumUsedClusterBytes":45553617581,
    "sumUsedMetadataClusterBytes":31703113728
  }
}
```

Related references

[ModifyClusterFullThreshold](#) on page 154

GetClusterHardwareInfo

You can use the `GetClusterHardwareInfo` method to retrieve the hardware status and information for all Fibre Channel nodes, iSCSI nodes and drives in the cluster. This generally includes manufacturers, vendors, versions, and other associated hardware identification information.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>type</code>	<p>Include only one of the following types of hardware information in the response. Possible values:</p> <ul style="list-style-type: none"><code>drives</code>: Lists only drive information in the response.<code>nodes</code>: Lists only node information in the response.<code>all</code>: Includes both drive and node information in the response. <p>If this parameter is omitted, a type of <code>all</code> is assumed.</p>	string	<code>all</code>	No

Return value

This method has the following return value:

Name	Description	Type
<code>clusterHardwareInfo</code>	Hardware information for all nodes and drives in the cluster. Each object in this output is labeled with the <code>nodeID</code> of the given node.	<i>hardwareInfo</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterHardwareInfo",
  "params": {
    "type": "all"
  },
  "id": 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[GetClusterHardwareInfo](#) on page 473

GetClusterInfo

You can use the `GetClusterInfo` method to return configuration information about the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
clusterInfo	Cluster information.	clusterInfo

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterInfo",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterInfo": {
      "attributes": {},
      "encryptionAtRestState": "disabled",
      "ensemble": [
        "10.10.21.23",
        "10.10.21.24",
        "10.10.21.25"
      ],
      "mvip": "10.10.1.57",
      "mvipInterface": "Bond1G",
      "mvipNodeID": 2,
      "mvipVlanTag": "120",
      "name": "Hulk",
      "repCount": 2,
      "svip": "10.10.21.57",
      "svipInterface": "Bond10G",
      "svipNodeID": 2,
      "svipVlanTag": "0",
      "uniqueID": "17nx",
      "uuid": "8d385a91-9acf-4371-8939-b29e085191fd"
    }
  }
}
```

```
}
}
```

GetClusterInterfacePreference

The `GetClusterInterfacePreference` method enables systems integrated with storage clusters running Element software to get information about an existing cluster interface preference. This method is for internal use.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
name	The name of the cluster interface preference.	string	None	Yes

Return value

This method has the following return value:

Name	Description	Type
preference	The name and value of the requested cluster interface preference.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterInterfacePreference",
  "params": {
    "name": "prefname"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "preference": {
      "name": "prefname",
      "value": "testvalue"
    }
  }
}
```

GetClusterMasterNodeID

You can use the `GetClusterMasterNodeID` method to retrieve the ID of the node that performs cluster-wide administration tasks and holds the storage virtual IP address (SVIP) and management virtual IP address (MVIP).

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
nodeID	ID of the master node.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterMasterNodeID",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1
  "result": {
    "nodeID": 1
  }
}
```

GetClusterStats

You can use the `GetClusterStats` method to retrieve high-level activity measurements for the cluster. Values returned are cumulative from the creation of the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
clusterStats	Cluster activity information.	<i>clusterStats</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterStats",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterStats": {
      "actualIOPS": 9376,
      "averageIOPSize": 4198,
      "clientQueueDepth": 8,
      "clusterUtilization": 0.09998933225870132,
      "latencyUsec": 52,
      "normalizedIOPS": 15000,
      "readBytes": 31949074432,
      "readBytesLastSample": 30883840,
      "readLatencyUsec": 27,
      "readLatencyUsecTotal": 182269319,
      "readOps": 1383161,
      "readOpsLastSample": 3770,
      "samplePeriodMsec": 500,
      "servicesCount": 3,
      "servicesTotal": 3,
      "timestamp": "2017-09-09T21:15:39.809332Z",
      "unalignedReads": 0,
      "unalignedWrites": 0,
      "writeBytes": 8002002944,
      "writeBytesLastSample": 7520256,
      "writeLatencyUsec": 156,
      "writeLatencyUsecTotal": 231848965,
      "writeOps": 346383,
      "writeOpsLastSample": 918
    }
  }
}
```

GetClusterVersionInfo

You can use the `GetClusterVersionInfo` method to retrieve information about the Element software version running on each node in the cluster. This method also returns information about nodes that are currently in the process of upgrading software.

Cluster version info object members

This method has the following object members:

Name	Description	Type
nodeID	ID of the node.	integer
nodeInternalRevision	Internal software version of the node.	string
nodeVersion	Software version of the node.	string

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
clusterAPIVersion	The current API version on the cluster.	string
clusterVersion	Version of Element software currently running on the cluster.	string
clusterVersionInfo	List of nodes in the cluster with version information for each node.	JSON object array
pendingClusterVersion	If present, this is the version that the cluster software is currently being upgraded or reverted to.	string
softwareVersionInfo	<p>The state of an upgrade. Object members:</p> <ul style="list-style-type: none"> <code>currentVersion</code>: The current software version on a node. <code>nodeID</code>: ID of the node being upgraded from <code>currentVersion</code> to <code>pendingVersion</code>. This field is 0 (zero) if there is no upgrade in progress. <code>packageName</code>: Name of the software package being installed. <code>pendingVersion</code>: The version of the software being installed. <code>startTime</code>: The date and time the installation was started, in UTC+0 format. 	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterVersionInfo",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
```

```

"result": {
  "clusterAPIVersion": "6.0",
  "clusterVersion": "6.1382",
  "clusterVersionInfo": [
    {
      "nodeID": 1,
      "nodeInternalRevision": "BuildType=Release Element=carbon
Release=carbon ReleaseShort=carbon Version=6.1382 sfdev=6.28
Repository=dev Revision=061511ble7fb BuildDate=2014-05-28T18:26:45MDT",
      "nodeVersion": "6.1382"
    },
    {
      "nodeID": 2,
      "nodeInternalRevision": "BuildType=Release Element=carbon
Release=carbon ReleaseShort=carbon Version=6.1382 sfdev=6.28
Repository=dev Revision=061511ble7fb BuildDate=2014-05-28T18:26:45MDT",
      "nodeVersion": "6.1382"
    },
    {
      "nodeID": 3,
      "nodeInternalRevision": "BuildType=Release Element=carbon
Release=carbon ReleaseShort=carbon Version=6.1382 sfdev=6.28
Repository=dev Revision=061511ble7fb BuildDate=2014-05-28T18:26:45MDT",
      "nodeVersion": "6.1382"
    },
    {
      "nodeID": 4,
      "nodeInternalRevision": "BuildType=Release Element=carbon
Release=carbon ReleaseShort=carbon Version=6.1382 sfdev=6.28
Repository=dev Revision=061511ble7fb BuildDate=2014-05-28T18:26:45MDT",
      "nodeVersion": "6.1382"
    }
  ],
  "softwareVersionInfo": {
    "currentVersion": "6.1382",
    "nodeID": 0,
    "packageName": "",
    "pendingVersion": "6.1382",
    "startTime": ""
  }
}

```

GetFeatureStatus

You can use the `GetFeatureStatus` method to retrieve the status of a cluster feature.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
feature	<p>The status of a cluster feature. If no value is provided, the system returns a status of all features. Possible values:</p> <ul style="list-style-type: none"> <code>vvols</code>: Retrieve status for the VVols cluster feature. <code>SnapMirror</code>: Retrieve status for the SnapMirror replication cluster feature. <code>fips</code>: Retrieve status for the FIPS 140-2 encryption feature. 	string	None	No

Return value

This method has the following return value:

Name	Description	Type
features	<p>An array of feature objects indicating the feature name and its status. Object members:</p> <ul style="list-style-type: none"> <code>feature</code>: (string) The name of the feature. <code>enabled</code>: (boolean) Whether the feature is enabled or not. 	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetFeatureStatus",
  "params": {
    "feature" : "vvols"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "features": [
      {
        "enabled": true,
        "feature": "Vvols"
      }
    ]
  }
}
```

GetLoginSessionInfo

You can use the `GetLoginSessionInfo` method to return the period of time a login authentication session is valid for both login shells and the TUI.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
loginSessionInfo	<p>An object containing the authentication expiration period. Possible objects returned:</p> <ul style="list-style-type: none"> timeout: The time, in minutes, when this session will timeout and expire. Formatted in H:mm:ss. For example: 1:30:00, 20:00, 5:00. All leading zeros and colons are removed regardless of the format the timeout was entered. 	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetLoginSessionInfo",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : {
    "loginSessionInfo" : {
```

```

    "timeout" : "30:00"
  }
}

```

GetNodeHardwareInfo

You can use the `GetNodeHardwareInfo` method to return all the hardware information and status for the node specified. This generally includes manufacturers, vendors, versions, and other associated hardware identification information.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
nodeID	The ID of the node for which hardware information is being requested. Information about a Fibre Channel node is returned if a Fibre Channel node is specified.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
nodeHardwareInfo	Hardware information for the specified nodeID. Each object in this output is labeled with the nodeID of the given node.	hardwareInfo

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetNodeHardwareInfo",
  "params": {
    "nodeID": 1
  },
  "id": 1
}

```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[GetNodeHardwareInfo \(output for Fibre Channel nodes\)](#) on page 505

[GetNodeHardwareInfo \(output for iSCSI\)](#) on page 504

GetNodeStats

You can use the `GetNodeStats` method to retrieve the high-level activity measurements for a single node.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
nodeID	Specifies the ID of the node for which statistics will be returned.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
nodeStats	Node activity information.	<i>nodeStats</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetNodeStats",
  "params": {
    "nodeID": 5
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "nodeStats" : {
      "cBytesIn" : 9725856460404,
      "cBytesOut" : 16730049266858,
      "cpu" : 98,
      "mBytesIn" : 50808519,
      "mBytesOut" : 52040158,
      "networkUtilizationCluster" : 84,
      "networkUtilizationStorage" : 0,
      "sBytesIn" : 9725856460404,
      "sBytesOut" : 16730049266858,
      "timestamp" : "2012-05-16T19:14:37.167521Z",
      "usedMemory" : 41195708000
    }
  }
}
```

ListActiveNodes

You can use the `ListActiveNodes` method to return the list of currently active nodes that are in the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
nodes	List of active nodes in the cluster.	<i>node</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListActiveNodes",
  "params": {},
  "id" : 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[ListActiveNodes](#) on page 516

ListAllNodes

You can use the `ListAllNodes` method to list active and pending nodes in the cluster.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
nodes	List of objects describing active nodes in the cluster.	<i>node</i>
pendingActiveNodes	List of objects describing pending active nodes for the cluster.	<i>pendingActiveNode</i> array

Name	Description	Type
pendingNodes	List of objects describing pending nodes for the cluster.	<i>pendingNode</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListAllNodes",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nodes": [
      {
        "associatedFServiceID": 0,
        "associatedMasterServiceID": 1,
        "attributes": {},
        "chassisName": "CT5TV12",
        "cip": "10.1.1.1",
        "cipi": "Bond10G",
        "fibreChannelTargetPortGroup": null,
        "mip": "10.1.1.1",
        "mipi": "Bond10G",
        "name": "NLBP0704",
        "nodeID": 1,
        "nodeSlot": "",
        "platformInfo": {
          "chassisType": "R620",
          "cpuModel": "Intel",
          "nodeMemoryGB": 72,
          "nodeType": "SF3010",
          "platformConfigVersion": "0.0.0.0"
        },
        "sip": "10.1.1.1",
        "sipi": "Bond10G",
        "softwareVersion": "11.0",
        "uuid": "4C4C4544-0054",
        "virtualNetworks": []
      }
    ],
    "pendingActiveNodes": [],
    "pendingNodes": []
  }
}
```

ListClusterFaults

You can use the `ListClusterFaults` method to list information about any faults detected on the cluster. With this method, you can list both current faults as well as faults that have been resolved. The system caches faults every 30 seconds.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>bestPractices</code>	Include faults triggered by sub-optimal system configuration. Possible values: <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean	None	No
<code>faultTypes</code>	Determines the types of faults returned. Possible values: <ul style="list-style-type: none"> <code>current</code>: List active, unresolved faults. <code>resolved</code>: List faults that were previously detected and resolved. <code>all</code>: List both current and resolved faults. You can see the fault status in the “resolved” member of the <code>fault</code> object. 	string	<code>all</code>	No

Return value

This method has the following return value:

Name	Description	Type
<code>faults</code>	An object describing the requested cluster faults.	<i>fault</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListClusterFaults",
  "params": {
    "faultTypes": "current",
    "bestPractices": true
  },
}
```

```

    "id": 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "faults": [
      {
        "clusterFaultID": 1,
        "code": "notUsingLACPBondMode",
        "data": null,
        "date": "2016-04-26T14:57:04.275286Z",
        "details": "Bond1G interfaces found not using LACP bond mode.
Nodes not set to LACP bond mode: {1,2,4,5}",
        "driveID": 0,
        "driveIDs": [],
        "nodeHardwareFaultID": 0,
        "nodeID": 0,
        "resolved": false,
        "resolvedDate": "",
        "serviceID": 0,
        "severity": "bestPractice",
        "type": "cluster"
      },
      {
        "clusterFaultID": 9,
        "code": "disconnectedClusterPair",
        "data": null,
        "date": "2016-04-26T20:40:08.736597Z",
        "details": "One of the clusters in a pair may have become
misconfigured or disconnected. Remove the local pairing and retry
pairing the clusters. Disconnected Cluster Pairs: []. Misconfigured
Cluster Pairs: [3]",
        "driveID": 0,
        "driveIDs": [],
        "nodeHardwareFaultID": 0,
        "nodeID": 0,
        "resolved": false,
        "resolvedDate": "",
        "serviceID": 0,
        "severity": "warning",
        "type": "cluster"
      }
    ]
  }
}

```

ListClusterInterfacePreferences

The `ListClusterInterfacePreference` method enables systems integrated with storage clusters running Element software to list the existing cluster interface preferences stored on the system. This method is for internal use.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
preferences	A list of cluster interface objects currently stored on the storage cluster, each containing the name and value of the preference.	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListClusterInterfacePreferences",
  "params": {
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "preferences": [
      {
        "name": "prefname",
        "value": "testvalue"
      }
    ]
  }
}
```

ListEvents

You can use the `ListEvents` method to list events detected on the cluster, sorted from oldest to newest.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
driveID	Specifies that only events with this drive ID will be returned.	integer	0	No
endEventID	Identifies the end of a range of event IDs to return.	integer	(unlimited)	No

Name	Description	Type	Default value	Required
endPublishTime	Specifies that only events published earlier than this time will be returned.	string	0	No
endReportTime	Specifies that only events reported earlier than this time will be returned.	string	0	No
eventType	Specifies the type of events to return. See event for possible event types.	string	0	No
maxEvents	Specifies the maximum number of events to return.	integer	(unlimited)	No
nodeID	Specifies that only events with this node ID will be returned.	integer		
serviceID	Specifies that only events with this service ID will be returned.			
startEventID	Identifies the beginning of a range of events to return.	integer	0	No
startPublishTime	Specifies that only events published after this time will be returned.	string	0	No
startReportTime	Specifies that only events reported after this time will be returned.	string	0	No

Return value

This method has the following return value:

Name	Description	Type
events	List of events.	event array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListEvents",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id":1,
  "result":{
    "events":[
      {
        "details":
        {
          "paramGCGeneration":1431550800,
          "paramServiceID":2
        },
        "driveID":0,
        "eventID":2131,
        "eventInfoType":"gcEvent",
        "message":"GC Cluster Coordination Complete",
        "nodeID":0,
        "serviceID":2,
        "severity":0,
        "timeOfPublish":"2015-05-13T21:00:02.361354Z",
        "timeOfReport":"2015-05-13T21:00:02.361269Z"
      },{
        "details":
        {
          "eligibleBS":
[5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,24,25,26,27,28,29,30,31,40,41,42
,43,44,45,46,47,52,53,54,55,56,57,58,59,60],
          "generation":1431550800,
          "participatingSS":[23,35,39,51]
        },
        "driveID":0,
        "eventID":2130,
        "eventInfoType":"gcEvent",
        "message":"GCStarted",
        "nodeID":0,
        "serviceID":2,
        "severity":0,
        "timeOfPublish":"2015-05-13T21:00:02.354128Z",
        "timeOfReport":"2015-05-13T21:00:02.353894Z"
      },{
        "details":"","
        "driveID":0,
        "eventID":2129,
        "eventInfoType":"tSEvent",
        "message":"return code:2 t:41286 tt:41286 qcc:1 qd:1 qc:1 vrc:
1 tt:2 ct:Write etl:524288",
        "nodeID":0,
        "serviceID":0,
        "severity":0,
        "timeOfPublish":"2015-05-13T20:45:21.586483Z",
        "timeOfReport":"2015-05-13T20:45:21.586311Z"
      }
    ]
  }
}
```

ListNodeStats

You can use the `ListNodeStats` method to view the high-level activity measurements for all storage nodes in a storage cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
nodeStats	Storage node activity information.	<i>nodeStats</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListNodeStats",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nodeStats": {
      "nodes": [
        {
          "cBytesIn": 46480366124,
          "cBytesOut": 46601523187,
          "cpu": 0,
          "mBytesIn": 59934129,
          "mBytesOut": 41620976,
          "networkUtilizationCluster": 0,
          "networkUtilizationStorage": 0,
          "nodeID": 1,
          "sBytesIn": 46480366124,
          "sBytesOut": 46601523187,
          "timestamp": 1895558254814,
          "usedMemory": 31608135680
        }
      ]
    }
  }
}
```

ListISCSISessions

You can use the `ListISCSISessions` method to list iSCSI connection information for volumes in the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
sessions	Information about each iSCSI session.	session

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListISCSISessions",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "sessions": [
      {
        "accountID": 1,
        "accountName": "account1",
        "createTime": "2017-04-11T03:39:32.030291Z",
        "driveID": 23,
        "driveIDs": [23],
        "initiator": null,
        "initiatorIP": "10.1.1.1:37138",
        "initiatorName": "iqn.2010-01.net.solidfire.eng:c",
        "initiatorPortName": "iqn.2010-01.net.solidfire.eng:c,i,
0x23d86000",
        "initiatorSessionID": 9622126592,
        "msSinceLastIscsiPDU": 243,
        "msSinceLastScsiCommand": 141535021,
        "nodeID": 3,
        "serviceID": 6,
        "sessionID": 25769804943,
        "targetIP": "10.1.1.2:3260",
        "targetName": "iqn.2010-01.com.solidfire:a7sd.3",
        "targetPortName": "iqn.2010-01.com.solidfire:a7sd.3,t,0x1",
        "virtualNetworkID": 0,
        "volumeID": 3,
        "volumeInstance": 140327214758656
      }
    ]
  }
}
```

```
}
}
```

ListServices

You can use the `ListServices` method to list services information for nodes, drives, current software, and other services that are running on the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
services	Services that are running on drives and nodes.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListServices",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
"id": 1,
"result": {
  "services": [
    {
      "drive": {
        "assignedService": 22,
        "asyncResultIDs": [],
        "attributes": {},
        "capacity": 300069052416,
        "customerSliceFileCapacity": 0,
        "driveID": 5,
        "driveStatus": "assigned",
        "driveType": "block",
        "failCount": 0,
        "nodeID": 4,
        "reservedSliceFileCapacity": 0,
        "serial": "scsi-SATA_INTEL_SSDSC2",
        "slot": 3
      },
      "drives": [
        {
          "assignedService": 22,
          "asyncResultIDs": [],
          "attributes": {},
          "capacity": 300069052416,
          "customerSliceFileCapacity": 0,
          "driveID": 5,
          "driveStatus": "assigned",
```

```

        "driveType": "Block",
        "failCount": 0,
        "nodeID": 4,
        "reservedSliceFileCapacity": 0,
        "serial": "scsi-SATA_INTEL_SSDSC2",
        "slot": 3
    },
    ],
    "node": {
        "associatedFServiceID": 0,
        "associatedMasterServiceID": 1,
        "attributes": {},
        "cip": "10.117.63.18",
        "cipi": "Bond10G",
        "fibreChannelTargetPortGroup": null,
        "mip": "10.117.61.18",
        "mipi": "Bond1G",
        "name": "node4",
        "nodeID": 4,
        "nodeSlot": "",
        "platformInfo": {
            "chassisType": "R620",
            "cpuModel": "Intel(R) Xeon(R) CPU",
            "nodeMemoryGB": 72,
            "nodeType": "SF3010",
            "platformConfigVersion": "10.0"
        },
        "sip": "10.117.63.18",
        "sipi": "Bond10G",
        "softwareVersion": "10.0",
        "uuid": "4C4C4544-0053",
        "virtualNetworks": []
    },
    "service": {
        "associatedBV": 0,
        "associatedTS": 0,
        "associatedVS": 0,
        "asyncResultIDs": [
            1
        ],
        "driveID": 5,
        "driveIDs": [
            5
        ],
        "firstTimeStartup": true,
        "ipcPort": 4008,
        "iscsiPort": 0,
        "nodeID": 4,
        "serviceID": 22,
        "serviceType": "block",
        "startedDriveIDs": [],
        "status": "healthy"
    }
}
]
}

```

ListPendingNodes

You can use the `ListPendingNodes` method to list the pending storage nodes in the system. Pending nodes are storage nodes that are running and configured to join the storage cluster but have not yet been added using the `AddNodes` API method.

IPv4 and IPv6 management addresses

Note that `ListPendingNodes` does not list pending nodes that have different address types for the management IP address (MIP) and management virtual IP address (MVIP). For example, if a pending

node has an IPv6 MVIP and an IPv4 MIP, `ListPendingNodes` will not include the node as part of the result.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
pendingNodes	List of pending nodes in the cluster.	<i>pendingNode</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListPendingNodes",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 3,
  "result": {
    "pendingNodes": [
      {
        "assignedNodeID": 0,
        "cip": "10.26.65.101",
        "cipi": "Bond10G",
        "compatible": true,
        "mip": "172.26.65.101",
        "mipi": "Bond1G",
        "name": "VWC-EN101",
        "pendingNodeID": 1,
        "platformInfo": {
          "chassisType": "R620",
          "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
          "nodeMemoryGB": 72,
          "nodeType": "SF3010"
        },
        "sip": "10.26.65.101",
        "sipi": "Bond10G",
        "softwareVersion": "9.0.0.1554",
        "uuid": "4C4C4544-0048-4410-8056-C7C04F395931"
      }
    ]
  }
}
```

Related references

[AddNodes](#) on page 118

ListPendingActiveNodes

You can use the `ListPendingActiveNodes` method to list nodes in the cluster that are in the `PendingActive` state, between pending and active states. Nodes in this state are being returned to the factory image.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
<code>pendingActiveNodes</code>	List of objects detailing information about all <code>PendingActive</code> nodes in the system.	<i>pendingActiveNode</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListPendingActiveNodes",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  id: null,
  result: {
    pendingActiveNodes: [
      {
        activeNodeKey: "5rPHP3lTAO",
        assignedNodeID: 5,
        asyncHandle: 2,
        cip: "10.10.5.106",
        mip: "192.168.133.106",
        pendingNodeID: 1,
        platformInfo: {
          chassisType: "R620",
          cpuModel: "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
          nodeMemoryGB: 72,
          nodeType: "SF3010"
        },
        sip: "10.10.5.106",
        softwareVersion: "9.0.0.1077"
      }
    ]
  }
}
```

ModifyClusterFullThreshold

You can use the `ModifyClusterFullThreshold` method to change the level at which the system generates an event when the storage cluster approaches a certain capacity utilization. You can use the threshold setting to indicate the acceptable amount of utilized block storage before the system generates a warning.

For example, if you want to be alerted when the system reaches 3% below the "Error" level block storage utilization, enter a value of "3" for the `stage3BlockThresholdPercent` parameter. If this level is reached, the system sends an alert to the Event Log in the Cluster Management Console.

Parameters

This method has the following input parameters:

Note: At least one parameter must be selected.

Name	Description	Type	Default value	Required
<code>stage2AwareThreshold</code>	The number of nodes of capacity remaining in the cluster before the system triggers a capacity notification.	integer	None	No
<code>stage3BlockThresholdPercent</code>	The percentage of block storage utilization below the "Error" threshold that causes the system to trigger a cluster "Warning" alert.	integer	None	No

Name	Description	Type	Default value	Required
maxMetadataOverProvisionFactor	A value representative of the number of times metadata space can be over provisioned relative to the amount of space available. For example, if there was enough metadata space to store 100 TiB of volumes and this number was set to 5, then 500 TiB worth of volumes could be created.	integer	5	No

Return values

This method has the following return values:

Name	Description	Type
blockFullness	<p>The current computed level of block fullness of the cluster.</p> <ul style="list-style-type: none"> stage1Happy: No alerts or error conditions. Corresponds to the Healthy state in the web UI. stage2Aware: No alerts or error conditions. Corresponds to the Healthy state in the web UI. stage3Low: Your system cannot provide redundant data protection from two non-simultaneous node failures. Corresponds to the Warning state in the web UI. You can configure this level in the web UI (by default, the system triggers this alert at a capacity of 3% below the Error state). stage4Critical: The system is not capable of providing redundant data protection from a single node failure. No new volumes or clones can be created. Corresponds to the Error state in the Element UI. stage5CompletelyConsumed: Completely consumed. The cluster is read-only and iSCSI connections are maintained, but all writes are suspended. Corresponds to the Critical state in the Element UI. 	string
fullness	Reflects the highest level of fullness between "blockFullness" and "metadataFullness".	string
maxMetadataOverProvisionFactor	A value representative of the number of times metadata space can be over provisioned relative to the amount of space available. For example, if there was enough metadata space to store 100 TiB of volumes and this number was set to 5, then 500 TiB worth of volumes could be created.	integer

Name	Description	Type
metadataFullness	<p>The current computed level of metadata fullness of the cluster.</p> <ul style="list-style-type: none"> stage1Happy: No alerts or error conditions. Corresponds to the Healthy state in the web UI. stage2Aware: No alerts or error conditions. Corresponds to the Healthy state in the web UI. stage3Low: Your system cannot provide redundant data protection from two non-simultaneous node failures. Corresponds to the Warning state in the web UI. You can configure this level in the web UI (by default, the system triggers this alert at a capacity of 3% below the Error state). stage4Critical: The system is not capable of providing redundant data protection from a single node failure. No new volumes or clones can be created. Corresponds to the Error state in the Element UI. stage5CompletelyConsumed: Completely consumed. The cluster is read-only and iSCSI connections are maintained, but all writes are suspended. Corresponds to the Critical state in the Element UI. 	string
sliceReserveUsedThresholdPct	Error condition. A system alert is triggered if the reserved slice utilization is greater than the sliceReserveUsedThresholdPct value returned.	integer
stage2AwareThreshold	Awareness condition. The value that is set for "Stage 2" cluster threshold level.	integer
stage2BlockThresholdBytes	Number of bytes being used by the cluster at which a stage2 condition will exist.	integer
stage3BlockThresholdBytes	Number of bytes being used by the cluster at which a stage3 condition will exist.	integer
stage3BlockThresholdPercent	Percent value set for stage3. At this percent full, a warning is posted in the Alerts log.	integer
stage3LowThreshold	Error condition. The threshold at which a system alert is created due to low capacity on a cluster.	integer
stage4BlockThresholdBytes	Number of bytes being used by the cluster at which a stage4 condition will exist.	integer

Name	Description	Type
stage4CriticalThreshold	Error condition. The threshold at which a system alert is created to warn about critically low capacity on a cluster.	integer
stage5BlockThresholdBytes	Number of bytes being used by the cluster at which a stage5 condition will exist.	integer
sumTotalClusterBytes	Physical capacity of the cluster, measured in bytes.	integer
sumTotalMetadataClusterBytes	Total amount of space that can be used to store metadata.	integer
sumUsedClusterBytes	Number of bytes used on the cluster.	integer
sumUserMetadataClusterBytes	Amount of space used on volume drives to store metadata.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method" : "ModifyClusterFullThreshold",
  "params" : {
    "stage3BlockThresholdPercent" : 3
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "blockFullness": "stage1Happy",
    "fullness": "stage3Low",
    "maxMetadataOverProvisionFactor": 5,
    "metadataFullness": "stage3Low",
    "sliceReserveUsedThresholdPct": 5,
    "stage2AwareThreshold": 3,
    "stage2BlockThresholdBytes": 2640607661261,
    "stage3BlockThresholdBytes": 8281905846682,
    "stage3BlockThresholdPercent": 3,
    "stage3LowThreshold": 2,
    "stage4BlockThresholdBytes": 8641988709581,
    "stage4CriticalThreshold": 1,
    "stage5BlockThresholdBytes": 12002762096640,
    "sumTotalClusterBytes": 12002762096640,
    "sumTotalMetadataClusterBytes": 404849531289,
    "sumUsedClusterBytes": 45553617581,
    "sumUsedMetadataClusterBytes": 31703113728
  }
}
```

ModifyClusterInterfacePreference

The `ModifyClusterInterfacePreference` method enables systems integrated with storage clusters running Element software to change an existing cluster interface preference. This method is for internal use.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
name	The name of the cluster interface preference to modify.	string	None	Yes
value	The new value of the cluster interface preference.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyClusterInterfacePreference",
  "params": {
    "name": "testname",
    "value": "newvalue"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

RemoveNodes

You can use `RemoveNodes` to remove one or more nodes that should no longer participate in the cluster.

Before removing a node, you must remove all drives the node contains using the `RemoveDrives` method. You cannot remove a node until the `RemoveDrives` process has completed and all data has

been migrated away from the node. After you remove a node, it registers itself as a pending node. You can add the node again or shut it down (shutting the node down removes it from the Pending Node list).

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
nodes	List of NodeIDs for the nodes to be removed.	integer array	None	Yes

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveNodes",
  "params": {
    "nodes" : [3,4,5]
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1
  "result" : {},
}
```

SetLoginSessionInfo

You can use the `SetLoginSessionInfo` method to set the period of time that a login authentication for a session is valid. After the login period elapses without activity on the system, the authentication expires. New login credentials are required for continued access to the cluster after the login period has elapsed.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
timeout	Cluster authentication expiration period. Formatted in HH:mm:ss. For example: 01:30:00, 00:90:00, and 00:00:5400 can all be used to equal a 90 minute timeout period.	string	30 minutes	Yes

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetLoginSessionInfo",
  "params": {
    "timeout" : "01:30:00"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

Shutdown

You can use the `Shutdown` method to restart or shutdown the nodes in a cluster. You can shut down a single node, multiple nodes, or all of the nodes in the cluster using this method.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
nodes	List of NodeIDs for the nodes to be restarted or shut down.	integer array	None	Yes

Name	Description	Type	Default value	Required
option	Action to take for the cluster. Possible values: <ul style="list-style-type: none"> restart: Restarts the cluster. halt: Performs a full power-off. 	string	restart	No

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "Shutdown",
  "params": {
    "nodes": [
      2,
      3,
      4
    ],
    "option": "halt"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "failed": [],
    "successful": [
      6
    ]
  }
}
```

Cluster creation API Methods

You can use these API methods to create a storage cluster. All of these methods need to be used against the API endpoint on a single node.

CheckProposedCluster

You can use the `CheckProposedCluster` method to test a set of storage nodes before creating a storage cluster with them to identify possible errors or faults that would occur from the attempt, such as unbalanced mixed node capabilities.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
nodes	A list of storage IP addresses of the initial set of storage nodes making up the storage cluster.	string array	None	Yes
force	Set to <code>true</code> to run on all storage nodes in the storage cluster.	boolean	None	No

Return values

This method has the following return values:

Name	Description	Type
proposedClusterValid	Indicates whether or not the proposed storage nodes would make up a valid storage cluster. Possible values: <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean
proposedClusterErrors	Errors that would occur if a storage cluster was created using the proposed storage nodes.	string array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CheckProposedCluster",
  "params": {
    "nodes": [
      "192.168.1.11",
```

```

        "192.168.1.12",
        "192.168.1.13",
        "192.168.1.14"
    ],
    "id": 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "proposedClusterValid": true,
    "proposedClusterErrors": [ ]
  }
}

```

CreateCluster

You can use the `CreateCluster` method to initialize the node in a cluster that has ownership of the "mvip" and "svip" addresses. Each new cluster is initialized using the management IP (MIP) of the first node in the cluster. This method also automatically adds all the nodes being configured into the cluster. You only need to use this method once each time a new cluster is initialized.

Note: After you run the [GetBootStrapConfig](#) method to get the IP addresses for the rest of the nodes that you want to include in the cluster, you can run the `CreateCluster` method against the master node for the cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
acceptEula	Indicate your acceptance of the End User License Agreement when creating this cluster. To accept the EULA, set this parameter to <code>true</code> .	boolean	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON Object	None	No
mvip	Floating (virtual) IP address for the cluster on the management network.	string	None	Yes
nodes	CIP/SIP addresses of the initial set of nodes making up the cluster. This node's IP must be in the list.	string array	None	Yes
password	Initial password for the cluster admin account.	string	None	Yes

Name	Description	Type	Default value	Required
repCount	Number of replicas of each piece of data to store in the cluster. Valid value is "2".	integer	2	Yes
svip	Floating (virtual) IP address for the cluster on the storage (iSCSI) network.	string	None	Yes
username	User name for the cluster admin.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateCluster",
  "params": {
    "acceptEula": true,
    "mvip": "10.0.3.1",
    "svip": "10.0.4.1",
    "repCount": 2,
    "username": "Admin1",
    "password": "9R7ka4rEPa2uREtE",
    "attributes": {
      "clusteraccountnumber": "axdf323456"
    },
    "nodes": [
      "10.0.2.1",
      "10.0.2.2",
      "10.0.2.3",
      "10.0.2.4"
    ]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

Related references

[GetBootstrapConfig](#) on page 166

GetBootstrapConfig

You can use the `GetBootstrapConfig` method to get cluster and node information from the bootstrap configuration file. Use this API method on an individual node before it has been joined with a cluster. The information this method returns is used in the cluster configuration interface when you create a cluster.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
clusterName	Name of the cluster.	string
nodeName	Name of the node.	string
nodes	<p>List of information about each node that is actively waiting to join the cluster. Possible values:</p> <ul style="list-style-type: none"> <code>chassisType</code>: (string) Hardware platform of the node. <code>cip</code>: (string) Cluster IP address of the node. <code>compatible</code>: (boolean) Indicates if the node is compatible with the node the API call was executed against. <code>hostname</code>: (string) Host name of the node. <code>mip</code>: (string) The IPv4 management IP address of the node. <code>mipV6</code>: (string) The IPv6 management IP address of the node. <code>nodeType</code>: (string) Model name of the node. <code>version</code>: (string) Version of software currently installed on the node. 	JSON object array
version	Version of Element software currently installed on the node that was called by this API method.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetBootstrapConfig",

```

```

    "params": {},
    "id" : 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id":1,
  "result":{
    "clusterName":"testname",
    "nodeName":"testnode",
    "nodes":[
      {
        "chassisType":"R630",
        "cip":"10.117.115.16",
        "compatible":true,
        "hostname":"NLABP1132",
        "mip":"10.117.114.16",
        "mipV6":"fd20:8b1e:b256:45a::16",
        "nodeType":"SF2405",
        "role":"Storage",
        "version":"11.0"
      },
      {
        "chassisType":"R630",
        "cip":"10.117.115.17",
        "compatible":true,
        "hostname":"NLABP1133",
        "mip":"10.117.114.17",
        "mipV6":"fd20:8b1e:b256:45a::17",
        "nodeType":"SF2405",
        "role":"Storage",
        "version":"11.0"
      },
      {
        "chassisType":"R630",
        "cip":"10.117.115.18",
        "compatible":true,
        "hostname":"NLABP1134",
        "mip":"10.117.114.18",
        "mipV6":"fd20:8b1e:b256:45a::18",
        "nodeType":"SF2405",
        "role":"Storage",
        "version":"11.0"
      }
    ],
    "version":"11.0"
  }
}

```

Related references

[CreateCluster](#) on page 164

Drive API methods

You can use drive API methods to add and manage drives that are available to a storage cluster. When you add a storage node to the storage cluster or install new drives in an existing storage node, the drives are available to be added to the storage cluster.

AddDrives

You can use the `AddDrives` method to add one or more available drives to the cluster, enabling the drives to host a portion of the data for the cluster.

When you add a storage node to the cluster or install new drives in an existing node, the new drives are marked as available and must be added via `AddDrives` before they can be utilized. Use the [ListDrives](#) method to display drives that are available to be added. When you add a drive, the system automatically determines the type of drive it should be.

The method is asynchronous and returns as soon as the processes for rebalancing the drives in the cluster are started. However, it might take more time for the data in the cluster to be rebalanced using the newly added drives; the rebalancing continues even after the `AddDrives` method call is complete. You can use the [GetAsyncResult](#) method to query the method's returned `asyncHandle`. After the `AddDrives` method returns, you can use the [ListSyncJobs](#) method to see the progress of the rebalancing of data with the new drives.

Note: When you add multiple drives, it is more efficient to add them in a single `AddDrives` method call rather than multiple individual methods with a single drive each. This reduces the amount of data balancing that must occur to stabilize the storage load on the cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
drives	Information about each drive to be added to the cluster. Possible values: <ul style="list-style-type: none"> <code>driveID</code>: The ID of the drive to add (integer). <code>type</code>: The type of drive to add (string). Valid values are "slice", "block", or "volume". If omitted, the system assigns the correct type. 	JSON object array	None	Yes (type is optional)

Return value

This method has the following return value:

Name	Description	Type
asyncHandle	Handle value used to obtain the operation result.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "id": 1,
  "method": "AddDrives",
  "params": {
    "drives": [
      {
        "driveID": 1,
        "type": "slice"
      },
      {
        "driveID": 2,
        "type": "block"
      },
      {
        "driveID": 3,
        "type": "block"
      }
    ]
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "asyncHandle": 1
  }
}
```

Related references

[GetAsyncResult](#) on page 94

[ListDrives](#) on page 172

[ListSyncJobs](#) on page 366

GetDriveHardwareInfo

You can use the `GetDriveHardwareInfo` method to get all the hardware information for the given drive. This generally includes manufacturers, vendors, versions, and other associated hardware identification information.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
driveID	ID of the drive for the request.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
result	Returned hardware information for the specified driveID.	hardwareInfo

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetDriveHardwareInfo",
  "params": {
    "driveID": 5
  },
  "id" : 100
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 100,
  "result" : {
    "driveHardwareInfo" : {
      "description" : "ATA Drive",
      "dev" : "8:80",
      "devpath" : "/devices/pci0000:40/0000:40:01.0/0000:41:00.0/host6/
port-6:0/expander-6:0/port-6:0:4/end_device-6:0:4/target6:0:4/6:0:4:0/
block/sdf",
      "driveSecurityAtMaximum" : false,
      "driveSecurityFrozen" : false,
      "driveSecurityLocked" : false,
      "logicalname" : "/dev/sdf",
      "product" : "INTEL SSDSA2CW300G3",
      "securityFeatureEnabled" : false,
      "securityFeatureSupported" : true,
      "serial" : "CVPR121400NT300EGN",
      "size" : "300069052416",
      "uuid" : "7e1fd5b9-5acc-8991-e2ac-c48f813a3884",
      "version" : "4PC10362"
    }
  }
}
```

Related references

[ListDrives](#) on page 172

GetDriveStats

You can use the `GetDriveStats` method to get high-level activity measurements for a single drive. Values are cumulative from the addition of the drive to the cluster. Some values are specific to block drives. Statistical data is returned for either block or metadata drive types when you run this method.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
driveID	ID of the drive for the request.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
driveStats	Drive activity information for the specified driveID.	<i>driveStats</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetDriveStats",
  "params": {
    "driveID": 3
  },
  "id" : 1
}
```

Response example (block drive)

This method returns a response similar to the following example for a block drive:

```
{
  "id": 1,
  "result": {
    "driveStats": {
      "driveID": 10,
      "failedDieCount": 0,
      "lifeRemainingPercent": 99,
      "lifetimeReadBytes": 26471661830144,
      "lifetimeWriteBytes": 13863852441600,
      "powerOnHours": 33684,
      "readBytes": 10600432105,
      "readOps": 5101025,
      "reallocatedSectors": 0,
      "reserveCapacityPercent": 100,
      "timestamp": "2016-10-17T20:23:45.456834Z",
      "totalCapacity": 300069052416,
      "usedCapacity": 6112226545,
      "usedMemory": 114503680,
      "writeBytes": 53559500896,
      "writeOps": 25773919
    }
  }
}
```

Response example (volume metadata drive)

This method returns a response similar to the following example for a volume metadata drive:

```
{
  "id": 1,
  "result": {
    "driveStats": {
      "activeSessions": 8,

```

```

    "driveID": 12,
    "failedDieCount": 0,
    "lifeRemainingPercent": 100,
    "lifetimeReadBytes": 2308544921600,
    "lifetimeWriteBytes": 1120986464256,
    "powerOnHours": 16316,
    "readBytes": 1060152152064,
    "readOps": 258826209,
    "reallocatedSectors": 0,
    "reserveCapacityPercent": 100,
    "timestamp": "2016-10-17T20:34:52.456130Z",
    "totalCapacity": 134994670387,
    "usedCapacity": null,
    "usedMemory": 22173577216,
    "writeBytes": 353346510848,
    "writeOps": 86266238
  }
}

```

Related references

[ListDrives](#) on page 172

ListDrives

You can use the `ListDrives` method to list the drives that exist in the active nodes of the cluster. This method returns drives that have been added as volume metadata or block drives as well as drives that have not been added and are available.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
drives	List of drives in the cluster.	drive array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListDrives",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {
    "drives" : [
      {
        "attributes" : {},

```

```

        "capacity" : 299917139968,
        "driveID" : 35,
        "nodeID" : 5,
        "serial" : "scsi-SATA_INTEL_SSDSA2CW6CVPR141502R3600FGN-part2",
        "slot" : 0,
        "status" : "active",
        "type" : "volume"
    },
    {
        "attributes" : {},
        "capacity" : 600127266816,
        "driveID" : 36,
        "nodeID" : 5,
        "serial" : "scsi-SATA_INTEL_SSDSA2CW6CVPR1415037R600FGN",
        "slot" : 6,
        "status" : "active",
        "type" : "block"
    }
  ]
}

```

ListDriveStats

You can use the `ListDriveStats` method to list high-level activity measurements for multiple drives in the cluster. By default, this method returns statistics for all drives in the cluster, and these measurements are cumulative from the addition of the drive to the cluster. Some values this method returns are specific to block drives, and some are specific to metadata drives.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
drives	List of drive IDs (<code>driveID</code>) for which to return drive statistics. If you omit this parameter, measurements for all drives are returned.	integer array	None	No

Return values

This method has the following return values:

Name	Description	Type
driveStats	List of drive activity information for each drive.	<i>driveStats</i> array
errors	This list contains the <code>driveID</code> and associated error message. It is always present, and empty if there are no errors.	JSON object array

Request example

Requests for this method are similar to the following example:

```

{
  "id": 1,
  "method": "ListDriveStats",
  "params": {

```

```

    "drives": [22, 23]
  }
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "driveStats": [
      {
        "driveID": 22,
        "failedDieCount": 0,
        "lifeRemainingPercent": 84,
        "lifetimeReadBytes": 30171004403712,
        "lifetimeWriteBytes": 103464755527680,
        "powerOnHours": 17736,
        "readBytes": 14656542,
        "readOps": 3624,
        "reallocatedSectors": 0,
        "reserveCapacityPercent": 100,
        "timestamp": "2016-03-01T00:19:24.782735Z",
        "totalCapacity": 300069052416,
        "usedCapacity": 1783735635,
        "usedMemory": 879165440,
        "writeBytes": 2462169894,
        "writeOps": 608802
      }
    ],
    "errors": [
      {
        "driveID": 23,
        "exception": {
          "message": "xStatCheckpointDoesNotExist",
          "name": "xStatCheckpointDoesNotExist"
        }
      }
    ]
  }
}

```

Related references

[GetDriveStats](#) on page 170

RemoveDrives

You can use the `RemoveDrives` method to proactively remove drives that are part of the cluster. You might use this method when reducing cluster capacity or preparing to replace drives nearing the end of their service life. Any data on the drives is removed and migrated to other drives in the cluster before the drive is removed from the cluster.

`RemoveDrives` is an asynchronous method. Depending on the total capacity of the drives being removed, it might take several minutes to migrate all of the data.

When removing multiple drives, use a single `RemoveDrives` method call rather than multiple individual methods with a single drive each. This reduces the amount of data balancing that must occur to evenly stabilize the storage load on the cluster.

You can also remove drives with a "failed" status using `RemoveDrives`. When you remove a drive with a "failed" status, the drive is not returned to an "available" or "active" status. The drive is unavailable for use in the cluster.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
drives	List of driveIDs to remove from the cluster.	integer array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
asyncHandle	Handle value used to obtain the operation result.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveDrives",
  "params": {
    "drives" : [3, 4, 5]
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : {
    "asyncHandle": 1
  }
}
```

Related references

[GetAsyncResult](#) on page 94

[ListDrives](#) on page 172

SecureEraseDrives

You can use the `SecureEraseDrives` method to remove any residual data from drives that have a status of "available". You might use this method when replacing a drive nearing the end of its service life that contained sensitive data. This method uses a Security Erase Unit command to write a predetermined pattern to the drive and resets the encryption key on the drive. This asynchronous method might take several minutes to complete.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
drives	List of drive IDs to secure erase.	integer array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
asyncHandle	Handle value used to obtain the operation result.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SecureEraseDrives",
  "params": {
    "drives" : [3, 4, 5]
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1
  "result" : {
    "asyncHandle" : 1
  }
}
```

Related references

[GetAsyncResult](#) on page 94

[ListDrives](#) on page 172

Fibre Channel API methods

You can use Fibre Channel API methods to add, modify, or remove Fibre Channel node members of a storage cluster.

GetVolumeAccessGroupLunAssignments

You can use the `GetVolumeAccessGroupLunAssignments` method to retrieve details on LUN mappings of a specified volume access group.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>volumeAccessGroupID</code>	A unique volume access group ID used to return information.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
<code>volumeAccessGroupLunAssignments</code>	A list of all physical Fibre Channel ports, or a port for a single node.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetVolumeAccessGroupLunAssignments",
  "params": {
    "volumeAccessGroupID": 5
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "volumeAccessGroupLunAssignments" : {
      "volumeAccessGroupID" : 5,
      "lunAssignments" : [
        { "volumeID" : 5, "lun" : 0 },
        { "volumeID" : 6, "lun" : 1 },
        { "volumeID" : 7, "lun" : 2 },
        { "volumeID" : 8, "lun" : 3 }
      ]
    }
  }
}
```

```

    ],
    "deletedLunAssignments" : [
      { "volumeID" : 44, "lun" : 44 }
    ]
  }
}
}

```

ListFibreChannelPortInfo

You can use the `ListFibreChannelPortInfo` method to list information about the Fibre Channel ports.

This API method is intended for use on individual nodes; a userid and password are required for access to individual Fibre Channel nodes. However, this method can be used on the cluster if the `force` parameter is set to `true`. When used on the cluster, all Fibre Channel interfaces are listed.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>force</code>	Set to <code>true</code> to run on all nodes in the cluster.	boolean	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>fibreChannelPorts</code>	A list of all physical Fibre Channel ports, or a port for a single node.	<i>fibreChannelPort</i> array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListFibreChannelPortInfo",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "fibreChannelPortInfo": {
      "5": {
        "result": {
          "fibreChannelPorts": [
            {
              "firmware": "7.04.00 (d0d5)",
              "hbaPort": 1,

```

```

        "model": "QLE2672",
        "nPortID": "0xc70084",
        "pciSlot": 3,
        "serial": "BFE1335E03500",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:0a"
    },
    {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 2,
        "model": "QLE2672",
        "nPortID": "0x0600a4",
        "pciSlot": 3,
        "serial": "BFE1335E03500",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:9c:71:01",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:0b"
    },
    {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 1,
        "model": "QLE2672",
        "nPortID": "0xc70044",
        "pciSlot": 2,
        "serial": "BFE1335E04029",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:08"
    },
    {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 2,
        "model": "QLE2672",
        "nPortID": "0x060044",
        "pciSlot": 2,
        "serial": "BFE1335E04029",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:9c:71:01",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:09"
    }
]
}
}
"6": {
    "result": {
        "fibreChannelPorts": [
            {
                "firmware": "7.04.00 (d0d5)",
                "hbaPort": 1,
                "model": "QLE2672",
                "nPortID": "0x060084",
                "pciSlot": 3,
                "serial": "BFE1335E04217",
                "speed": "8 Gbit",
                "state": "Online",
                "switchWwn": "20:01:00:2a:6a:9c:71:01",
                "wwnn": "5f:47:ac:c8:3c:e4:95:00",
                "wwpn": "5f:47:ac:c0:3c:e4:95:02"
            },
            {
                "firmware": "7.04.00 (d0d5)",
                "hbaPort": 2,

```

```
"model": "QLE2672",
"nPortID": "0xc700a4",
"pciSlot": 3,
"serial": "BFE1335E04217",
"speed": "8 Gbit",
"state": "Online",
"switchWwn": "20:01:00:2a:6a:98:a3:41",
"wwnn": "5f:47:ac:c8:3c:e4:95:00",
"wwpn": "5f:47:ac:c0:3c:e4:95:03"
},
{
    "firmware": "7.04.00 (d0d5)",
    "hbaPort": 1,
    "model": "QLE2672",
    "nPortID": "0xc70064",
    "pciSlot": 2,
    "serial": "BFE1341E09515",
    "speed": "8 Gbit",
    "state": "Online",
    "switchWwn": "20:01:00:2a:6a:98:a3:41",
    "wwnn": "5f:47:ac:c8:3c:e4:95:00",
    "wwpn": "5f:47:ac:c0:3c:e4:95:00"
},
{
    "firmware": "7.04.00 (d0d5)",
    "hbaPort": 2,
    "model": "QLE2672",
    "nPortID": "0x060064",
    "pciSlot": 2,
    "serial": "BFE1341E09515",
    "speed": "8 Gbit",
    "state": "Online",
    "switchWwn": "20:01:00:2a:6a:9c:71:01",
    "wwnn": "5f:47:ac:c8:3c:e4:95:00",
    "wwpn": "5f:47:ac:c0:3c:e4:95:01"
}
]
}
```

ListFibreChannelSessions

You can use the `ListFibreChannelSessions` method to list information about the Fibre Channel sessions on a cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
sessions	A list of objects describing active Fibre Channel sessions on the cluster.	<i>session</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListFibreChannelSessions",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "sessions" : [
      {
        "initiatorWWPN" : "21:00:00:0e:1e:14:af:40",
        "nodeID" : 5,
        "serviceID" : 21,
        "targetWWPN": "5f:47:ac:c0:00:00:00:10",
        "volumeAccessGroupID": 7
      },
      {
        "initiatorWWPN" : "21:00:00:0e:1e:14:af:40",
        "nodeID" : 1,
        "serviceID" : 22,
        "targetWWPN": "5f:47:ac:c0:00:00:00:11",
        "volumeAccessGroupID": 7
      }
    ]
  }
}
```

ListNodeFibreChannelPortInfo

You can use the `ListNodeFibreChannelPortInfo` method to list information about the Fibre Channel ports on a node.

This API method is intended for use on individual nodes; a userid and password are required for access to individual Fibre Channel nodes. When used on the cluster, all Fibre Channel interfaces are listed.

Parameter

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
fibreChannelPorts	A list of all physical Fibre Channel ports, or a port for a single node.	<i>fibreChannelPort</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListNodeFibreChannelPortInfo",
  "params": {
    "nodeID": 5,
    "force": true
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "fibreChannelPorts": [
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 1,
        "model": "QLE2672",
        "nPortID": "0xc7002c",
        "pciSlot": 3,
        "serial": "BFE1335E03500",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:35:54:02:00",
        "wwpn": "5f:47:ac:c0:35:54:02:02"
      },
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 2,
        "model": "QLE2672",
        "nPortID": "0x06002d",
        "pciSlot": 3,
        "serial": "BFE1335E03500",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:9c:71:01",
        "wwnn": "5f:47:ac:c8:35:54:02:00",
        "wwpn": "5f:47:ac:c0:35:54:02:03"
      },
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 1,
        "model": "QLE2672",
        "nPortID": "0xc7002a",
        "pciSlot": 2,
        "serial": "BFE1335E04029",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:35:54:02:00",
        "wwpn": "5f:47:ac:c0:35:54:02:00"
      },
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 2,
        "model": "QLE2672",
        "nPortID": "0x06002a",
        "pciSlot": 2,
        "serial": "BFE1335E04029",
        "speed": "8 Gbit",
        "state": "Online",

```

```

        "switchWwn": "20:01:00:2a:6a:9c:71:01",
        "wwnn": "5f:47:ac:c8:35:54:02:00",
        "wwpn": "5f:47:ac:c0:35:54:02:01"
    }
}
}

```

ModifyVolumeAccessGroupLunAssignments

You can use the `ModifyVolumeAccessGroupLunAssignments` method to define custom LUN assignments for specific volumes.

This method changes only LUN values set on the `lunAssignments` parameter in the volume access group. All other LUN assignments remain unchanged.

LUN assignment values must be unique for volumes in a volume access group. You cannot define duplicate LUN values within a volume access group. However, you can use the same LUN values again in different volume access groups.

Note: Valid LUN values are 0 through 16383. The system generates an exception if you pass a LUN value outside of this range. None of the specified LUN assignments are modified if there is an exception.

Caution: If you change a LUN assignment for a volume with active I/O, the I/O can be disrupted. You should change the server configuration before changing volume LUN assignments.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>volumeAccessGroupID</code>	Unique volume access group ID for which the LUN assignments will be modified.	integer	None	Yes
<code>lunAssignments</code>	The volume IDs with new assigned LUN values.	integer array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
<code>volumeAccessGroupLunAssignments</code>	An object containing details of the modified volume access group LUN assignments.	JSON object

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ModifyVolumeAccessGroupLunAssignments",

```

```

    "params": {
      "volumeAccessGroupID" : 218,
      "lunAssignments" : [
        { "volumeID" : 832, "lun" : 0 },
        { "volumeID" : 834, "lun" : 1 }
      ],
      "id" : 1
    }
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "volumeAccessGroupLunAssignments": {
      "deletedLunAssignments": [],
      "lunAssignments": [
        {
          "lun": 0,
          "volumeID": 832
        },
        {
          "lun": 1,
          "volumeID": 834
        }
      ]
    },
    "volumeAccessGroupID": 218
  }
}

```


LDAP API methods

You can use the Lightweight Directory Access Protocol (LDAP) to authenticate access to Element storage. The LDAP API methods described in this section enable you to configure LDAP access to the storage cluster.

AddLdapClusterAdmin

You can use the `AddLdapClusterAdmin` to add a new LDAP cluster administrator user. An LDAP cluster administrator can manage the cluster using the API and management tools. LDAP cluster admin accounts are completely separate and unrelated to standard tenant accounts.

You can also use this method to add an LDAP group that has been defined in Active Directory®. The access level that is given to the group is passed to the individual users in the LDAP group.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>access</code>	Controls which methods this cluster admin can use.	string array	None	Yes
<code>acceptEula</code>	Accept the End User License Agreement. Set to <code>true</code> to add a cluster administrator account to the system. If omitted or set to <code>false</code> , the method call fails.	boolean	None	Yes
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object	None	No
<code>username</code>	The distinguished user name for the new LDAP cluster admin.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "AddLdapClusterAdmin",
  "params": {
    "username": "cn=mike jones,ou=ptusers,dc=prodtest,dc=solidfire,dc=net",
    "access": ["administrator", "read"]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

Related references

[Access control](#) on page 468

EnableLdapAuthentication

You can use the `EnableLdapAuthentication` method to configure an LDAP directory connection for LDAP authentication to a cluster. Users that are members of the LDAP directory can then log in to the storage system using their LDAP credentials.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
authType	Identifies which user authentication method to use. Possible values: <ul style="list-style-type: none"> • DirectBind • SearchAndBind 	string	SearchAndBind	No
groupSearchBaseDN	The base DN of the tree to start the group subtree search.	string	None	No
groupSearchType	Controls the default group search filter used. Possible values: <ul style="list-style-type: none"> • NoGroups: No group support. • ActiveDirectory: Nested membership of all of a user's active directory groups. • MemberDN: MemberDN style groups (single level). 	string	ActiveDirectory	No

Name	Description	Type	Default value	Required
serverURIs	A comma-separated list of LDAP server URIs. For example, "ldap://1.2.3.4" and ldaps://1.2.3.4:123".	string array	None	Yes
userSearchBaseDN	The base DN of the tree to start the subtree search. This parameter is required when using an authType of SearchAndBind.	string	None	No
searchBindDN	A fully qualified DN to log in with to perform an LDAP search for the user. The DN requires read access to the LDAP directory. This parameter is required when using an authType of SearchAndBind.	string	None	Yes
searchBindPassword	The password for the searchBindDN account used for searching. This parameter is required when using an authType of SearchAndBind.	string	None	Yes
userSearchFilter	The LDAP search filter to use when querying the LDAP server. The string should have the placeholder text "%USERNAME%" which is replaced with the username of the authenticating user. For example, (&(objectClass=person)(sAMAccountName=%USERNAME%)) will use the sAMAccountName field in Active Directory to match the username entered at cluster login. This parameter is required when using an authType of SearchAndBind.	string	None	Yes

Name	Description	Type	Default value	Required
userDNTemplate	A string template used to define a pattern for constructing a full user distinguished name (DN). The string should have the placeholder text "%USERNAME%" which is replaced with the username of the authenticating user. This parameter is required when using an authType of DirectBind.	string	None	Yes
groupSearchCustomFilter	For use with the CustomFilter search type, an LDAP filter to use to return the DN's of a user's groups. The string can have placeholder text of %USERNAME% and %USERDN% to be replaced with their username and full userDN as needed.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "EnableLdapAuthentication",
  "params": {
    "authType": "SearchAndBind",
    "groupSearchBaseDN": "dc=prodtest,dc=solidfire,dc=net",
    "groupSearchType": "ActiveDirectory",
    "searchBindDN": "SFReadOnly@prodtest.solidfire.net",
    "searchBindPassword": "zsw@#edcASD12",
    "sslCert": "",
    "userSearchBaseDN": "dc=prodtest,dc=solidfire,dc=net",
    "userSearchFilter": "(&(objectClass=person)(sAMAccountName=%USERNAME%))",
    "serverURIs": [
      "ldaps://111.22.333.444",
      "ldap://555.66.777.888"
    ]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
  }
}
```

DisableLdapAuthentication

You can use the `DisableLdapAuthentication` method to disable LDAP authentication and remove all LDAP configuration settings. This method does not remove any configured cluster admin accounts for users or groups. After LDAP authentication has been disabled, cluster admins that are configured to use LDAP authentication can no longer access the cluster.

Parameters

This method has no input parameters.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DisableLdapAuthentication",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

GetLdapConfiguration

You can use the `GetLdapConfiguration` method to get the currently active LDAP configuration on the cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value.

Name	Description	Type
ldapConfiguration	<p>List of the current LDAP configuration settings. This API call does not return the plain text of the search account password.</p> <p>Note: If LDAP authentication is currently disabled, all the returned settings are empty with the exception of "authType", and "groupSearchType" which are set to "SearchAndBind" and "ActiveDirectory" respectively.</p>	<i>ldapConfiguration</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetLdapConfiguration",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "ldapConfiguration": {
      "authType": "SearchAndBind",
      "enabled": true,
      "groupSearchBaseDN": "dc=prodtest,dc=solidfire,dc=net",
      "groupSearchCustomFilter": "",
      "groupSearchType": "ActiveDirectory",
      "searchBindDN": "SFReadOnly@prodtest.solidfire.net",
      "serverURIs": [
        "ldaps://111.22.333.444",
        "ldap://555.66.777.888"
      ],
      "userDNTemplate": "",
      "userSearchBaseDN": "dc=prodtest,dc=solidfire,dc=net",
      "userSearchFilter": "(&(objectClass=person)(sAMAccountName=%USERNAME%))"
    }
  }
}
```

TestLdapAuthentication

You can use the `TestLdapAuthentication` method to validate the currently enabled LDAP authentication settings. If the configuration is correct, the API call returns the group membership of the tested user.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
username	The username to be tested.	string	None	Yes
password	The password for the username to be tested.	string	None	Yes
ldapConfiguration	An ldapConfiguration object to be tested. If you provide this parameter, the system tests the provided configuration even if LDAP authentication is currently disabled.	<i>ldapConfiguration</i>	None	No

Return values

This method has the following return values:

Name	Description	Type
groups	List of LDAP groups that include the tested user as a member.	array
userDN	The tested user's full LDAP distinguished name.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestLdapAuthentication",
  "params": {
    "username": "admin1",
    "password": "admin1PASS"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "groups": [
      "CN=StorageMgmt,OU=PTUsers,DC=prodtest,DC=solidfire,DC=net"
    ],
    "userDN": "CN=Admin1 Jones,OU=PTUsers,DC=prodtest,DC=solidfire,DC=net"
  }
}
```

Node API methods

You can use node API methods to configure individual nodes. These methods operate on single nodes that need to be configured, are configured but not yet participating in a cluster, or are actively participating in a cluster. Node API methods enable you to view and modify settings for individual nodes and the cluster network used to communicate with the node. You must run these methods against individual nodes; you cannot run per-node API methods against the address of the cluster.

CheckProposedNodeAdditions

You can use the `CheckProposedNodeAdditions` method to test a set of storage nodes to see if you can add them to a storage cluster without errors or best practice violations.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>nodes</code>	A list of storage IP addresses of storage nodes that are ready to be added to a storage cluster.	string array	None	Yes

Return values

This method has the following return values:

Name	Description	Type
<code>proposedClusterValid</code>	Indicates whether or not the proposed storage nodes would make up a valid storage cluster. Possible values: <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean
<code>proposedClusterErrors</code>	Errors that would occur if a storage cluster was created using the proposed storage nodes.	string array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CheckProposedNodeAdditions",
  "params": {
    "nodes": [
      "192.168.1.11",
      "192.168.1.12",
```



```

        "192.168.1.13",
        "192.168.1.14"
    ],
    "id": 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "proposedClusterValid": true,
    "proposedClusterErrors": [ ]
  }
}

```

CreateClusterSupportBundle

You can use the `CreateClusterSupportBundle` on the management node to gather support bundles from all nodes in a cluster. When a bundle is created, it is stored on the node as a `.tar.gz` file. You can only run this method on a management node; it does not work when run on a storage node.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>allowIncomplete</code>	Allows the script to continue to run if bundles cannot be gathered from one or more of the nodes.	boolean	None	No
<code>bundleName</code>	Unique name for each support bundle created. If no name is provided, then "supportbundle" and the node name are used as the file name	string	None	No
<code>extraArgs</code>	This parameter is fed to the <code>sf_make_support_bundle</code> script. This parameter should be used only at the request of NetApp Support.	string	None	No
<code>mvip</code>	The MVIP of the cluster. Bundles are gathered from all nodes in the cluster. This parameter is required if the <code>nodes</code> parameter is not specified.	string	None	Yes

Name	Description	Type	Default value	Required
nodes	The IP addresses of the nodes from which to gather bundles. Use either <code>nodes</code> or <code>mvip</code> , but not both, to specify the nodes from which to gather bundles. This parameter is required if <code>mvip</code> is not specified.	string array	None	Yes
password	The cluster admin password. Note: This password is visible as text when entered.	string	None	Yes
username	The cluster admin user name.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateClusterSupportBundle",
  "params": {
    "bundlename": "clusterbundle",
    "mvip": "132.119.120.100"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "bundleName": "clusterbundle",
      "extraArgs": "",
      "files": [
        "/tmp/supportbundles/clusterbundle.cl-4SD5.tar"
      ],
      "output": "timeout -s KILL 1790s /usr/local/bin/sfclustersupportbundle --quiet --name=\"clusterbundle\" --target-directory=\"/tmp/solidfire-dtemp.MM7f0m\" --user=\"admin\" --pass=\"admin\" --mvip=132.119.120.100",
      "duration": "00:00:24.938127",
      "result": "Passed"
    }
  }
}
```

CreateSupportBundle

You can use the `CreateSupportBundle` to create a support bundle file under the node's directory. After creation, the bundle is stored on the node as a tar.gz file.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>bundleName</code>	Unique name for the support bundle. If no name is provided, then "supportbundle" and the node name are used as the file name.	string	None	No
<code>extraArgs</code>	This parameter is passed to the <code>sf_make_support_bundle</code> script. This parameter should be used only at the request of NetApp Support.	string	None	No
<code>timeoutSec</code>	The number of seconds the support bundle script runs.	integer	1500	No

Return values

This method has the following return values:

Name	Description	Type
<code>details</code>	The details of the support bundle. Possible values: <ul style="list-style-type: none"> <code>bundleName</code>: The name specified in the <code>CreateSupportBundle</code> API method. If no name was specified, "supportbundle" is used. <code>extraArgs</code>: The arguments passed with this method. <code>files</code>: A list of the support bundle files that the system created. <code>output</code>: The command line output from the script that created the support bundle. <code>timeoutSec</code>: The number of seconds the support bundle script runs before stopping. <code>url</code>: URL to the support bundle created. 	JSON object
<code>duration</code>	The time used to create the support bundle in the format: HH:MM:SS.ssssss.	string
<code>result</code>	The success or failure of the support bundle operation.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateSupportBundle",
  "params": {}
},
{id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "bundleName": "supportbundle",
      "extraArgs": "",
      "files": [
        "supportbundle.SF-D220.tar.gz"
      ],
      "output": "timeout -s KILL 1500s /sf/scripts/sf_make_support_bundle
--quiet /tmp/solidfire-dtemp.bYRag7/supportbundle timeout -s KILL 1500s
pigz --verbose --fast \" /tmp/solidfire-dtemp.bYRag7/supportbundle.*.tar
\" /tmp/solidfire-dtemp.bYRag7/supportbundle.SF-D220.tar to /tmp/
solidfire-dtemp.bYRag7/supportbundle.SF-D220.tar.gz Moved '/tmp/
solidfire-dtemp.bYRag7/supportbundle.SF-D220.tar.gz' to /tmp/
supportbundles",
      "timeoutSec": 1500,
      "url": [
        "https://192.168.130.155:442/config/supportbundles/
supportbundle.SF-D220.tar.gz"
      ]
    },
    "duration": "00:00:21.166692",
    "result": "Passed"
  }
}
```

DeleteAllSupportBundles

You can use the DeleteAllSupportBundles method to delete all support bundles generated with the CreateSupportBundle API method.

Parameters

This method has no input parameters.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteAllSupportBundles",
  "params": {}
},
```

```
{
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

DisableSsh

You can use the `DisableSsh` method to disable the SSH service for a single storage node. This method does not affect the cluster-wide SSH service timeout duration.

Parameter

This method has no input parameter.

Return value

This method has the following return value:

Name	Description	Type
enabled	The status of the SSH service for this node.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DisableSsh",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {"enabled": false}
}
```

EnableSsh

You can use the `EnableSsh` method to enable the SSH service for a single node. This method does not affect the cluster-wide SSH timeout duration, and does not exempt the node from having SSH disabled by the global SSH timeout.

Parameter

This method has no input parameter.

Return value

This method has the following return value:

Name	Description	Type
enabled	The status of the SSH service for this node.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method": "EnableSsh",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {"enabled": true}
}
```

GetClusterConfig

You can use the `GetClusterConfig` API method to return information about the cluster configuration the node uses to communicate with its cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
cluster	Cluster configuration information the node uses to communicate with the cluster.	<i>cluster</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterConfig",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "cluster": {
      "cipi": "Bond10G",
      "cluster": "ClusterName",
      "ensemble": [
        "1:10.30.65.139",
        "2:10.30.65.140",
        "3:10.30.65.141"
      ],
      "mipi": "Bond1G",
      "name": "xxx-en142",
      "nodeID": 4,
      "pendingNodeID": 0,
      "role": "Storage",
      "sipi": "Bond10G",
      "state": "Active",
      "version": "9.1.0"
    }
  }
}
```

GetClusterState

You can use the `GetClusterState` API method to indicate if a node is part of a cluster or not.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
cluster	Name of the cluster.	string
state	<ul style="list-style-type: none"> Available: Node has not been configured with a cluster name. Pending: Node is pending for a specific named cluster and can be added. Active: Node is an active member of a cluster and may not be added to another cluster. 	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterState",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" :
    "cluster" : "Cluster101"
    "state" : "Active"
}
```

GetConfig

You can use the `GetConfig` API method to get all configuration information for a node. This API method includes the same information available in both the `GetClusterConfig` and `GetNetworkConfig` API methods.

Parameters

This method has no input parameters.

Return values

This method has the following return value:

Name	Description	Type
config	<p>The configuration details of the cluster. This object contains:</p> <ul style="list-style-type: none"> <i>cluster</i>: Cluster information that identifies how the storage node communicates with the storage cluster it is associated with. <i>network (all interfaces)</i>: Network connection types and current settings for each network interface of the node. 	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetConfig",
  "params": {},
  "id" : 1
}
```


Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[GetClusterConfig](#) on page 198

[GetNetworkConfig](#) on page 211

[GetConfig](#) on page 472

GetDriveConfig

You can use the `GetDriveConfig` method to get drive information for expected slice and block drive counts as well as the number of slices and block drives that are currently connected to the node.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
driveConfig	Information on the drives that are connected to the node.	drive

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetDriveConfig",
  "params": {},
  "id" : 1
}
```

Response example

Responses for this method are similar to the following example. Due to length, the response contains information for one drive of one storage node only.

```
{
  "id": 1,
  "result": {
    "driveConfig": {
      "drives": [
        {
          "canonicalName": "sda",
          "connected": true,
          "dev": 2052,
          "devPath": "/dev/sdimm0p4",
          "driveType": "Slice",
          "name": "scsi-SATA_VRFSD3400GNCVMT205581853-part4",
          "path": "/dev/sda4",
          "pathLink": "/dev/sdimm0p4",
          "product": "VRFSD3400GNCVMTKS1",
          "scsiCompatId": "scsi-SATA_VRFSD3400GNCVMT205581853-part4",

```

```

        "scsiState": "Running",
        "securityAtMaximum": false,
        "securityEnabled": false,
        "securityFrozen": true,
        "securityLocked": false,
        "securitySupported": true,
        "serial": "205581853",
        "size": 299988156416,
        "slot": -1,
        "uuid":
"9d4b198b-5ff9-4f7c-04fc-3bc4e2f38974",
        "vendor": "Viking",
        "version": "612ABBF0"
    }
  ],
  "numBlockActual": 10,
  "numBlockExpected": 10,
  "numSliceActual": 1,
  "numSliceExpected": 1,
  "numTotalActual": 11,
  "numTotalExpected": 11
}
}
}

```

GetHardwareConfig

You can use the `GetHardwareConfig` method to get the hardware configuration information for a node.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
hardwareConfig	List of hardware information and current settings.	JSON object

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetHardwareConfig",
  "params": {},
  "id" : 1
}

```

Response example

Responses for this method are similar to the following example.

```

{
  "id": 1,
  "result": {
    "hardwareConfig": {
      "biosRevision": "1.0",
      "biosVendor": [

```

```

        "NetApp",
        "SolidFire"
    ],
    "biosVersion": "1.1.2",
    "blockDriveSizeBytes": 300069052416,
    "blockDrives": [
        "/dev/slot0",
        "/dev/slot1",
        "/dev/slot2",
        "/dev/slot3",
        "/dev/slot4",
        "/dev/slot5",
        "/dev/slot6",
        "/dev/slot7",
        "/dev/slot8",
        "/dev/slot9"
    ],
    "blockServiceFormat": "Standard",
    "bmcFirmwareRevision": "1.6",
    "bmcIpmiVersion": "2.0",
    "chassisType": "R620",
    "cpuCores": 6,
    "cpuCoresEnabled": 6,
    "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
    "cpuThreads": 12,
    "driveSizeBytesInternal": 400088457216,
    "fibreChannelFirmwareRevision": "",
    "fibreChannelModel": "",
    "fibreChannelPorts": {},
    "idracVersion": "1.06.06",
    "ignoreFirmware": [],
    "memoryGB": 72,
    "memoryMhz": 1333,
    "networkDriver": [
        "bnx2x"
    ],
    "nicPortMap": {
        "PortA": "eth2",
        "PortB": "eth3",
        "PortC": "eth0",
        "PortD": "eth1"
    },
    "nodeType": "SF3010",
    "numCpu": 2,
    "numDrives": 10,
    "numDrivesInternal": 1,
    "nvramTempMonitorEnable": false,
    "rootDrive": "/dev/sdimm0",
    "scsiBusExternalDriver": "mpt3sas",
    "scsiBusInternalDriver": "ahci",
    "sliceDriveSizeBytes": 299988156416,
    "sliceDrives": [
        "/dev/sdimm0p4"
    ],
    "slotOffset": 0,
    "solidfireDefaults": {
        "bufferCacheGB": 12,
        "configuredIops": 50000,
        "cpuDmaLatency": -1,
        "driveWriteThroughputMBPerSleep": 10,
        "maxDriveWriteThroughputMBPerSec": 175,
        "maxIncomingSliceSyncs": 10,
        "postCallbackThreadCount": 8,
        "sCacheFileCapacity": 100000000,
        "sliceFileLogFileCapacity": 5000000000
    }
}
}
}
}

```

GetHardwareInfo

You can use the `GetHardwareInfo` method to get hardware information and status for a single node. Hardware information generally includes manufacturers, vendors, versions, drives, and other associated identification information.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>force</code>	Set this "force" parameter to <code>true</code> to run on all nodes in the cluster.	boolean	false	No

Return value

This method has the following return value:

Name	Description	Type
<code>hardwareInfo</code>	Hardware information for the node.	<i>hardwareInfo</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetHardwareInfo",
  "params": {
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "hardwareInfo": {
      "bus": {
        "core_DMI:0200": {
          "description": "Motherboard",
          "physid": "0",
          "product": "0A47AA",
          "serial": "..AB123456C12354.",
          "version": "C07"
        }
      }
    },
    "driveHardware": [
      {
        "canonicalName": "sdh",
        "connected": true,
        "dev": 2160,
        "devPath": "/dev/disk/by-path/pci-0000:41:00.0-
```

```

sas-0x500056b37789abf0-lun-0",
  "driveType": "Block",
  "lifeRemainingPercent": 92,
  "lifetimeReadBytes": 175436696911872,
  "lifetimeWriteBytes": 81941097349120,
  "name": "scsi-SATA_INTEL_SSDSC2BB3BTWL12345686300AAA",
  "path": "/dev/sdh",
  "pathLink": "/dev/disk/by-path/pci-0000:41:00.0-
sas-0x500056b37789abf0-lun-0",
  "powerOnHours": 17246,
  "product": "INTEL SSDAA2AA300A4",
  "reallocatedSectors": 0,
  "reserveCapacityPercent": 100,
  "scsiCompatId": "scsi-SATA_INTEL_SSDSC2BB3BTWL12345686300AAA",
  "scsiState": "Running",
  "securityAtMaximum": false,
  "securityEnabled": false,
  "securityFrozen": false,
  "securityLocked": false,
  "securitySupported": true,
  "serial": "AAAA33710886300AAA",
  "size": 300069052416,
  "slot": 1,
  "smartSsdWriteCapable": false,
  "uuid": "aea178b9-c336-6bab-a61d-87b615e8120c",
  "vendor": "Intel",
  "version": "D2010370"
},
...
]
}
}
}

```

GetIpmiConfig

You can use the `GetIpmiConfig` method to retrieve hardware sensor information from sensors that are in your node.

Parameter

This method has the following input parameter:

Name	Description	Type
<code>chassisType</code>	Used to display information for each node chassis type. Possible values: <ul style="list-style-type: none"> <code>all</code>: returns sensor information for each chassis type. <code>{chassis type}</code>: returns sensor information for a specified chassis type. 	string

Return values

This method has the following return values:

Name	Description	Type
<code>sensorName</code>	Name of the sensor that has been found.	string

Name	Description	Type
uniqueSensorID	Unique identifier for the sensor.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetIpmiConfig",
  "params": {
    "chassisType": "all"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nodes": [
      {
        "nodeID": 1,
        "result": {
          "ipmiConfig": {
            "C220M4": [
              {
                "sensorName": "Fan1A RPM",
                "uniqueSensorID": "29.1:0xf"
              },
              {
                "sensorName": "Fan1B RPM",
                "uniqueSensorID": "29.1:0x10"
              },
              {
                "sensorName": "Fan2A RPM",
                "uniqueSensorID": "29.2:0x11"
              },
              {
                "sensorName": "Fan2B RPM",
                "uniqueSensorID": "29.2:0x12"
              },
              {
                "sensorName": "Fan3A RPM",
                "uniqueSensorID": "29.3:0x13"
              },
              {
                "sensorName": "Fan3B RPM",
                "uniqueSensorID": "29.3:0x14"
              },
              {
                "sensorName": "Fan4A RPM",
                "uniqueSensorID": "29.4:0x15"
              },
              {
                "sensorName": "Fan4B RPM",
                "uniqueSensorID": "29.4:0x16"
              },
              {
                "sensorName": "Fan5A RPM",
                "uniqueSensorID": "29.5:0x17"
              },
            ]
          }
        }
      }
    ]
  }
}
```

```

    {
      "sensorName": "Fan5B RPM",
      "uniqueSensorID": "29.5:0x18"
    },
    {
      "sensorName": "Fan6A RPM",
      "uniqueSensorID": "29.6:0x19"
    },
    {
      "sensorName": "Fan6B RPM",
      "uniqueSensorID": "29.6:0x1a"
    },
    {
      "sensorName": "Exhaust Temp",
      "uniqueSensorID": "7.1:0x1"
    },
    {
      "sensorName": "Inlet Temp",
      "uniqueSensorID": "7.1:0x4"
    },
    {
      "sensorName": "PS1",
      "uniqueSensorID": "10.1:0x26"
    },
    {
      "sensorName": "PS2",
      "uniqueSensorID": "10.2:0x2c"
    }
  ],
  "R620": [
    {
      "sensorName": "Fan1A RPM",
      "uniqueSensorID": "7.1:0x30"
    },
    {
      "sensorName": "Fan1B RPM",
      "uniqueSensorID": "7.1:0x31"
    },
    {
      "sensorName": "Fan2A RPM",
      "uniqueSensorID": "7.1:0x32"
    },
    {
      "sensorName": "Fan2B RPM",
      "uniqueSensorID": "7.1:0x33"
    },
    {
      "sensorName": "Fan3A RPM",
      "uniqueSensorID": "7.1:0x34"
    },
    {
      "sensorName": "Fan3B RPM",
      "uniqueSensorID": "7.1:0x35"
    },
    {
      "sensorName": "Fan4A RPM",
      "uniqueSensorID": "7.1:0x36"
    },
    {
      "sensorName": "Fan4B RPM",
      "uniqueSensorID": "7.1:0x37"
    },
    {
      "sensorName": "Fan5A RPM",
      "uniqueSensorID": "7.1:0x38"
    },
    {
      "sensorName": "Fan5B RPM",
      "uniqueSensorID": "7.1:0x39"
    },
  ],

```

```

        "sensorName": "Fan6A RPM",
        "uniqueSensorID": "7.1:0x3a"
      },
      {
        "sensorName": "Fan6B RPM",
        "uniqueSensorID": "7.1:0x3b"
      },
      {
        "sensorName": "Fan7A RPM",
        "uniqueSensorID": "7.1:0x3c"
      },
      {
        "sensorName": "Fan7B RPM",
        "uniqueSensorID": "7.1:0x3d"
      },
      {
        "sensorName": "Exhaust Temp",
        "uniqueSensorID": "7.1:0x1"
      },
      {
        "sensorName": "Inlet Temp",
        "uniqueSensorID": "7.1:0x4"
      },
      {
        "sensorName": "PS1",
        "uniqueSensorID": "10.1:0x62"
      },
      {
        "sensorName": "PS2",
        "uniqueSensorID": "10.2:0x63"
      }
    ],
  }

```

GetIpmlInfo

You can use the `GetIpmlInfo` method to display a detailed reporting of sensors (objects) for node fans, intake and exhaust temperatures, and power supplies that are monitored by the system.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
sensors	Detailed information from each sensor within a node.	JSON object array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetIpmlInfo",
  "params": {},
  "id" : 1
}

```


Response example


Due to the length of the returned response for this API method, portions of the response have been intentionally eliminated from this document. What is included are the portions of the hardware information that the system monitors in order to ensure the node is running at optimum performance.

```
{
  "id": 1,
  "result": {
    "nodes": [
      {
        "nodeID": 1,
        "result": {
          "ipmiInfo": {
            "sensors": [
              {
                "entityID": "7.1 (System Board)",
                "sensorID": "0x72",
                "sensorName": "SEL",
                "sensorType": "Event Logging Disabled",
                "uniqueSensorID": "7.1:0x72"
              },
              {
                "assertionsEnabled": [
                  "General Chassis intrusion"
                ],
                "deassertionsEnabled": [
                  "General Chassis intrusion"
                ],
                "entityID": "7.1 (System Board)",
                "sensorID": "0x73",
                "sensorName": "Intrusion",
                "sensorType": "Physical Security",
                "uniqueSensorID": "7.1:0x73"
              },
              {THIS ENTIRE SECTION IS REPEATED FOR EACH FAN IN THE
SYSTEM
                "assertionEvents": [],
                "assertionsEnabled": [],
                "deassertionsEnabled": [],
                "entityID": "7.1 (System Board)",
                "eventMessageControl": "Per-threshold",
                "lowerCritical": "720.000",
                "lowerNonCritical": "840.000",
                "maximumSensorRange": "Unspecified",
                "minimumSensorRange": "Unspecified",
                "negativeHysteresis": "600.000",
                "nominalReading": "10080.000",
                "normalMaximum": "23640.000",
                "normalMinimum": "16680.000",
                "positiveHysteresis": "600.000",
                "readableThresholds": "lcr lnc",
                "sensorID": "0x30",
                "sensorName": "Fan1A RPM",
                "sensorReading": "4440 (+/- 120) RPM",
                "sensorType": "Fan",
                "settableThresholds": "",
                "status": "ok",
                "thresholdReadMask": "lcr lnc",
                "uniqueSensorID": "7.1:0x30"
              },
              .
              .
              .
              {THIS ENTIRE SECTION IS REPEATED FOR THE EXHAUST
TEMPERATURE OF EACH NODE
                "assertionEvents": [],
                "assertionsEnabled": [],
                "entityID": "7.1 (System Board)",
                "eventMessageControl": "Per-threshold",
```

```

        "lowerCritical": "3.000",
        "lowerNonCritical": "8.000",
        "maximumSensorRange": "Unspecified",
        "minimumSensorRange": "Unspecified",
        "negativeHysteresis": "1.000",
        "nominalReading": "23.000",
        "normalMaximum": "69.000",
        "normalMinimum": "11.000",
        "positiveHysteresis": "1.000",
        "readableThresholds": "lcr lnc unc ucr",
        "sensorID": "0x1",
        "sensorName": "Exhaust Temp",
        "sensorReading": "44 (+/- 1) degrees C",
        "sensorType": "Temperature",
        "settableThresholds": "",
        "status": "ok",
        "uniqueSensorID": "7.1:0x1",
        "upperCritical": "75.000",
        "upperNonCritical": "70.000"
    },
    {THIS ENTIRE SECTION IS REPEATED FOR THE INLET
TEMPERATURE OF EACH NODE
        "assertionEvents": [],
        "assertionsEnabled": [],
        "deassertionsEnabled": [],
        "entityID": "7.1 (System Board)",
        "eventMessageControl": "Per-threshold",
        "lowerCritical": "-7.000",
        "lowerNonCritical": "3.000",
        "maximumSensorRange": "Unspecified",
        "minimumSensorRange": "Unspecified",
        "negativeHysteresis": "1.000",
        "nominalReading": "23.000",
        "normalMaximum": "69.000",
        "normalMinimum": "11.000",
        "positiveHysteresis": "1.000",
        "readableThresholds": "lcr lnc unc ucr",
        "sensorID": "0x4",
        "sensorName": "Inlet Temp",
        "sensorReading": "20 (+/- 1) degrees C",
        "sensorType": "Temperature",
        "settableThresholds": "lcr lnc unc ucr",
        "status": "ok",
        "thresholdReadMask": "lcr lnc unc ucr",
        "uniqueSensorID": "7.1:0x4",
        "upperCritical": "47.000",
        "upperNonCritical": "42.000"
    },
    {THIS ENTIRE SECTION IS REPEATED FOR EACH POWER SUPPLY
ON EACH NODE
        "assertionEvents": [],
        "assertionsEnabled": [],
        "entityID": "10.2 (Power Supply)",
        "eventMessageControl": "Per-threshold",
        "maximumSensorRange": "Unspecified",
        "minimumSensorRange": "Unspecified",
        "negativeHysteresis": "Unspecified",
        "nominalReading": "0.000",
        "normalMaximum": "0.000",
        "positiveHysteresis": "Unspecified",
        "readableThresholds": "No Thresholds",
        "sensorID": "0x6d",
        "sensorName": "Voltage 2",
        "sensorReading": "118 (+/- 0) Volts",
        "sensorType": "Voltage",
        "settableThresholds": "No Thresholds",
        "status": "ok",
        "uniqueSensorID": "10.2:0x6d"
    },
    .
    .

```



GetNetworkConfig

You can use the `GetNetworkConfig` method to display the network configuration information for a node.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
network	Network connection types and current settings for each network interface of the node.	<i>network (all interfaces)</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetNetworkConfig",
  "params": {},
  "id" : 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[GetNetworkConfig](#) on page 501

GetNetworkInterface

You can use the `GetNetworkInterface` method to get information about a network interface on a node.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
interface	The name of the interface to get information about for each node. Possible values: <ul style="list-style-type: none"> Bond1G Bond10G 	string	None	No
force	Set this parameter to true to run on all nodes in the cluster.	boolean	false	No

Return value

This method has the following return value:

Name	Description	Type
nodes	An array of objects describing the interface for each storage node in the storage cluster. Each object within the array contains the following items: <ul style="list-style-type: none"> nodeID: (integer) The ID of the storage node in the storage cluster the interface information applies to. result: (networkInterface) Interface configuration information for this storage node. 	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetNetworkInterface",
  "params": {
    "interface": "Bond1G",
    "force": true
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nodes": [
      {
        "nodeID": 1,
        "result": {
          "interface": {
            "address": "10.117.64.32",
            "addressV6": "::",
            "broadcast": "10.117.79.255",
            "macAddress": "90:b1:1c:42:e0:1e",
            "mtu": 1500,
            "name": "Bond1G",
```

```

        "namespace": false,
        "netmask": "255.255.240.0",
        "status": "UpAndRunning",
        "type": "BondMaster",
        "virtualNetworkTag": 0
    }
},
{
    "nodeID": 2,
    "result": {
        "interface": {
            "address": "10.117.64.35",
            "addressV6": ":",
            "broadcast": "10.117.79.255",
            "macAddress": "d4:ae:52:7a:ae:23",
            "mtu": 1500,
            "name": "Bond1G",
            "namespace": false,
            "netmask": "255.255.240.0",
            "status": "UpAndRunning",
            "type": "BondMaster",
            "virtualNetworkTag": 0
        }
    }
},
{
    "nodeID": 3,
    "result": {
        "interface": {
            "address": "10.117.64.39",
            "addressV6": ":",
            "broadcast": "10.117.79.255",
            "macAddress": "c8:1f:66:f0:9d:17",
            "mtu": 1500,
            "name": "Bond1G",
            "namespace": false,
            "netmask": "255.255.240.0",
            "status": "UpAndRunning",
            "type": "BondMaster",
            "virtualNetworkTag": 0
        }
    }
},
{
    "nodeID": 4,
    "result": {
        "interface": {
            "address": "10.117.64.107",
            "addressV6": ":",
            "broadcast": "10.117.79.255",
            "macAddress": "b8:ca:3a:f5:24:f8",
            "mtu": 1500,
            "name": "Bond1G",
            "namespace": false,
            "netmask": "255.255.240.0",
            "status": "UpAndRunning",
            "type": "BondMaster",
            "virtualNetworkTag": 0
        }
    }
}
]
}

```

GetPendingOperation

You can use the `GetPendingOperation` method to detect an operation on a node that is currently in progress. This method can also be used to report back when an operation has completed.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
pending	Possible values: <ul style="list-style-type: none"> <code>true</code>: The operation is still in progress. <code>false</code>: The operation is no longer in progress. 	boolean
operation	Name of operation that is in progress or has completed.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetPendingOperation",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "pendingOperation" : {
      "pending" : "true",
      "operation" : "TestDrivesInternal",
    }
  }
}
```

GetSshInfo

You can use the `GetSshInfo` method to query the status of the SSH service on a single node.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
result	The status of the SSH service for this node.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method" : "GetSshInfo",
  "params" : {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "enabled": false
  }
}
```

ListNetworkInterfaces

You can use the `ListNetworkInterfaces` method to list information about each network interface on a node. This API method is intended for use on individual nodes; user ID and password authentication is required for access to individual nodes. However, you can use this method on the cluster if the parameter `force` is given the value `true` in the method call. When the parameter is used on the cluster, all interfaces are listed.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
force	Possible values: <ul style="list-style-type: none"> <code>true</code>: Information about all network interfaces in the cluster is returned. <code>false</code>: No information is returned. 	boolean	None	No

Return value

This method has the following return value:

Name	Description	Type
interfaces	A list of configuration information for each network interface of the storage node (or entire storage cluster, if <code>force = true</code>).	<i>networkInterface</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListNetworkInterfaces",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nodes": [
      {
        "nodeID": 1,
        "result": {
          "interfaces": [
            {
              "address": "10.117.80.32",
              "addressV6": "::",
              "broadcast": "10.117.95.255",
              "macAddress": "90:b1:1c:42:e0:1a",
              "mtu": 9000,
              "name": "Bond10G",
              "namespace": false,
              "netmask": "255.255.240.0",
              "status": "UpAndRunning",
              "type": "BondMaster",
              "virtualNetworkTag": 0
            },
            {
              "address": "10.117.64.32",
              "addressV6": "::",
              "broadcast": "10.117.79.255",
              "macAddress": "90:b1:1c:42:e0:1e",
              "mtu": 1500,
              "name": "Bond1G",
              "namespace": false,
              "netmask": "255.255.240.0",
              "status": "UpAndRunning",
              "type": "BondMaster",
              "virtualNetworkTag": 0
            },
            {
              "address": "0.0.0.0",
              "addressV6": "::",
              "broadcast": "0.0.0.0",
              "macAddress": "90:b1:1c:42:e0:1a",
              "mtu": 9000,
              "name": "eth0",
              "namespace": false,
              "netmask": "0.0.0.0",
              "status": "UpAndRunning",
              "type": "BondSlave",
              "virtualNetworkTag": 0
            }
          ]
        }
      }
    ]
  }
}
```



```

{
  "address": "127.0.0.1",
  "addressV6": ":::",
  "broadcast": "0.0.0.0",
  "macAddress": "00:00:00:00:00:00",
  "mtu": 0,
  "name": "lo",
  "namespace": false,
  "netmask": "0.0.0.0",
  "status": "UpAndRunning",
  "type": "Loopback",
  "virtualNetworkTag": 0
}
]
}
}
}
}
}

```

ListDriveHardware

You can use the `ListDriveHardware` method to list all the drives connected to a node. When used on individual nodes, this method returns drive hardware information. When used on the cluster master node MVIP, this method returns information for all drives on all nodes.

Note: The "securitySupported": true line of the method response does not imply that the drives are capable of encryption; only that the security status can be queried. If you have a node type with a model number ending in "-NE", commands to enable security features on these drives will fail.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
driveHardware	Returned drive hardware information for the node.	JSON object array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListDriveHardware",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "driveHardware": [
      {

```

```

        "canonicalName": "sda",
        "connected": true,
        "dev": 2048,
        "devPath": "/dev/slot0",
        "driveType": "Slice",
        "lifeRemainingPercent": 98,
        "lifetimeReadBytes": 0,
        "lifetimeWriteBytes": 14012129542144,
        "name": "scsi-SATA_SAMSUNG_MZ7GE24S1M9NWAG501251",
        "path": "/dev/sda",
        "pathLink": "/dev/slot0",
        "powerOnHours": 15489,
        "product": "SAMSUNG MZ7GE240HMGR-00003",
        "reallocatedSectors": 0,
        "reserveCapacityPercent": 100,
        "scsiCompatId": "scsi-SATA_SAMSUNG_MZ7GE24S1M9NWAG501251",
        "scsiState": "Running",
        "securityAtMaximum": false,
        "securityEnabled": true,
        "securityFrozen": false,
        "securityLocked": false,
        "securitySupported": true,
        "serial": "S1M9NWAG501251",
        "size": 240057409536,
        "slot": 0,
        "uncorrectableErrors": 0,
        "uuid": "789aa05d-e49b-ff4f-f821-f60eed8e43bd",
        "vendor": "Samsung",
        "version": "EXT1303Q"
    }
  ]
}

```

Related references

[EnableEncryptionAtRest](#) on page 123

ListTests

You can use the `ListTests` method to list the tests that are available to run on a node.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
tests	List of tests that can be performed on the node.	string array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListTests",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "tests": [
      "TestConnectEnsemble",
      "TestConnectMvip",
      "TestConnectSvip",
      "TestDrives",
      "TestHardwareConfig",
      "TestLocateCluster",
      "TestPing",
      "TestLocalConnectivity",
      "TestRemoteConnectivity",
      "TestNetworkConfig"
    ]
  }
}
```

ListUtilities

You can use the `ListUtilities` method to list the operations that are available to run on a node.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
utilities	List of utilities currently available to run on the node.	string array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListUtilities",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "utilities": [
      "ResetDrives",
      "ResetNode",
      "RestartNetworking",
      "RestartServices",
      "CreateSupportBundle",
    ]
  }
}
```

```

        "DeleteAllSupportBundles",
        "CreateClusterSupportBundle"
    ]
}
}

```

ResetNode

You can use the `ResetNode` method to reset a node to the factory settings. All data, packages (software upgrades, etc), configurations, and log files are deleted from the node when you call this method. However, network settings for the node are preserved during this operation. Nodes that are participating in a cluster cannot be reset to the factory settings.

The `ResetNode` API can only be used on nodes that are in an "Available" state. It cannot be used on nodes that are "Active" in a cluster, or in a "Pending" state.

Caution: This method clears any customer data that is on the node.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
build	Used to specify the URL to a remote Element software image to which the node will be reset.	URL	None	No
force	Set to <code>true</code> to reset the node.	boolean	None	Yes
options	Used to enter specifications for running the reset operations. Details are provided by NetApp Support, if required.	JSON object	None	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ResetNode",
  "params": {
    "build" : file:///sf/rtfi/image/filesystem.squashfs
    "force" : true
  },
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```
{
  "id": null,
  "result": {
    "rtfiInfo": {
      "build": "file:///sf/rtfi/image/filesystem.squashfs",
      "generation": "9",
      "options": {
        "edebug": "",
        "sf_auto": "0",
        "sf_bond_mode": "ActivePassive",
        "sf_check_hardware": "0",
        "sf_disable_otpw": "0",
        "sf_fa_host": "",
        "sf_hostname": "SF-FA18",
        "sf_inplace": "1",
        "sf_inplace_die_action": "kexec",
        "sf_inplace_safe": "0",
        "sf_keep_cluster_config": "0",
        "sf_keep_data": "0",
        "sf_keep_hostname": "0",
        "sf_keep_network_config": "0",
        "sf_keep_paths": "\\\"/var/log/hardware.xml\\\"",
        "sf_max_archives": "5",
        "sf_nvram_size": "",
        "sf_oldroot": "",
        "sf_postinst_erase_root_drive": "0",
        "sf_root_drive": "",
        "sf_rtfi_cleanup_state": "",
        "sf_secure_erase": "1",
        "sf_secure_erase_retries": "5",
        "sf_slice_size": "",
        "sf_ssh_key": "1",
        "sf_ssh_root": "1",
        "sf_start_rtfi": "1",
        "sf_status_httpserver": "1",
        "sf_status_httpserver_stop_delay": "5m",
        "sf_status_inject_failure": "",
        "sf_status_json": "0",
        "sf_support_host": "sfsupport.solidfire.com",
        "sf_test_hardware": "0",
        "sf_upgrade": "0",
        "sf_upgrade_firmware": "0",
        "sf_upload_logs_url": ""
      },
      "statusUrlAll": "http://192.168.130.20/status/all.json",
      "statusUrlCurrent": "http://192.168.130.20/status/current.json"
    }
  }
}
```

ResetDrives

You can use the `ResetDrives` method to proactively initialize drives and remove all data currently residing on a drive. The drive can then be reused in an existing node or used in an upgraded node.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
drives	List of device names (not driveIDs) to reset.	string	None	Yes
force	Set to true to reset the drive.	boolean	None	Yes

Return value

This method has the following return value:

Name	Description	Type
details	Details of drives that are being reset.	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ResetDrives",
  "params": {
    "drives": "slot3",
    "force": true
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "drives": [
        {
          "drive": "slot3",
          "returnCode": 0,
          "stderr": " * Unlocking /dev/slot9 .[ ok ]\n * Setting master password /dev/slot9 .[ ok ]\n * Secure erasing /dev/slot9 (hdparm) [tries=0/1] .....[ ok ]",
          "stdout": ""
        }
      ]
    },
    "duration": "00:00:28.501269",
    "result": "Passed"
  }
}
```

RestartNetworking

You can use the `RestartNetworking` method to restart the networking services on a node.

Caution: This method restarts all networking services on a node, causing temporary loss of networking connectivity.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
force	Set to true to restart networking services on a node.	boolean	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RestartNetworking",
  "params": {
    "force" : true
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{ "id" : 1,
  "result" : {}
}
```

RestartServices

You can use the `RestartServices` method to restart the services on a node.

Caution: This method causes temporary node services interruption.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
force	Set to true to restart services on a node.	boolean	None	Yes
service	Service name to be restarted.	string	None	No
action	Action to perform on the service (start, stop, restart).	string	None	No

Return values

This method has the following return values:

Name	Description	Type
details	The output of the service restart procedure, including errors (if any).	JSON object
duration	The time, in seconds, it took to restart services to the node.	string
result	Results of the restart.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RestartServices",
  "params": {
    "force" : true
    "action" : restart,
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": "solidfire stop/waiting\nsolidfire start/running, process 7284\n",
    "duration": "00:00:02.541594",
    "result": "Passed"
  }
}
```

SetClusterConfig

You can use the `SetClusterConfig` method to set the configuration that a node uses to communicate with the cluster it is associated with. To display the current cluster interface settings for a node, run the `GetClusterConfig` API method.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
cluster	Configuration attributes that should be changed during this method call. Only the fields you want changed need to be added to this method as members in this parameter.	<i>cluster</i>	None	No

Return value

This method has the following return value:

Name	Description	Type
cluster	Configuration information the node uses to communicate with the cluster.	<i>cluster</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetClusterConfig",
  "params": {
    "cluster": {
      "name": "myhost",
      "mipi": "Bond10G"
    },
    "id" : 1
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "cluster" : {
      "cipi" : "Bond10G",
      "cluster" : "QoS",
      "ensemble" : [
        "1:10.10.10.5.42",
        "2:10.10.10.5.43",
        "3:10.10.10.5.44",
        "4:10.10.10.5.46",
        "5:10.10.10.5.47"
      ],
      "hostname" : "myhost",
      "mipi" : "Bond10G",
      "nodeID" : 1,
      "sipi" : "Bond10G",
      "state" : "Active"
    }
  }
}
```

SetConfig

You can use the `SetConfig` method to set the network and cluster information for the node. This method includes the same settings in a single API method that are available using both `SetClusterConfig` and `SetNetworkConfig` methods. Only the fields you want changed need to be included with this method.

Caution: Changing the bond-mode on a node can cause a temporary loss of network connectivity.

Parameter

This method has the following input parameters:

Name	Description	Type	Default value	Required
cluster	Cluster information that identifies how the storage node communicates with the storage cluster it is associated with.	<i>cluster</i>	None	No
network	Network connection types and current settings for each network interface of the node.	<i>network (all interfaces)</i>	None	No

Return value

This method has the following return value:

Name	Description	Type
config	<p>The new and current configuration for the node. This object contains:</p> <ul style="list-style-type: none"> <i>cluster</i>: Cluster information that identifies how the storage node communicates with the storage cluster it is associated with. <i>network (all interfaces)</i>: Network connection types and current settings for each network interface of the node. 	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetConfig",
  "params": {
    "cluster": {
      "name": "MyHostname"
    },
    "network": {
      "Bond10G": {
        "bond-mode": "ALB"
      }
    }
  }
}
```

Response example

The response from this method is the same as the return for the `GetConfig` method. All fields for the object display and updated values are seen when `SetConfig` is used.

Related references

[SetClusterConfig](#) on page 224

[SetNetworkConfig](#) on page 227

[GetConfig](#) on page 472

SetNetworkConfig

You can use the `SetNetworkConfig` method to set the network configuration for a node. To display the current network settings for a node, run the `GetNetworkConfig` API method.

Caution: Changing the `bond-mode` on a node can cause a temporary loss of network connectivity.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
network	An object containing node network settings to modify. You only need to add the fields you want changed to this method as attributes in this parameter.	<i>network (all interfaces)</i>	None	No

Return value

This method has the following return value:

Name	Description	Type
network	The new and current network configuration for the node.	<i>network (all interfaces)</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetNetworkConfig",
  "params": {
    "network": {
      "Bond10G": {
        "bond-mode": "ALB"
      },
      "Bond1G": {
        "netmask": "255.255.224.0"
      },
      "eth0": {
        "method": "bond"
      },
      "lo": {
        "method": "loopback"
      }
    }
  }
}
```

Response example

The response from this method is the same as the response from the `GetNetworkConfig` method. The method displays all members for each object and includes the new values for any changed members.

Related references

[GetNetworkConfig](#) on page 211

[GetNetworkConfig](#) on page 501

Shutdown

You can use the `Shutdown` method to restart or shutdown a node that has not yet been added to a cluster. To use this method, login in to the MIP for the pending node and enter the `shutdown` method with either the `restart` or `halt` options in the following table.

Caution: This method restarts all networking services on a node, causing temporary loss of networking connectivity.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>option</code>	Action to take for the node shutdown: <ul style="list-style-type: none"><code>restart</code>: Restarts the node.<code>halt</code>: Performs full power-off of the node.	string	None	Yes

Note: You need to use port 443 to access the API service on an individual node. See the following HTTPS API request example, replacing `<MIP>` with the management IP address of the individual node, and `<API version>` with the version of Element software running on the node:

```
https://<MIP>:443/json-rpc/<API version>/?method=Shutdown&option=halt
```

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "Shutdown",
  "params": {
    "option": "restart"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{ "id" : 1,
  "result" : {}
}
```

TestConnectEnsemble

You can use the `TestConnectEnsemble` method to verify connectivity with a specified database ensemble. By default it uses the ensemble for the cluster the node is associated with. Alternatively you can provide a different ensemble to test connectivity.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
ensemble	A comma-separated list of ensemble node cluster IP addresses for connectivity testing.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
details	<p>Objects returned:</p> <ul style="list-style-type: none"> <code>nodes</code>: (object) A list of each ensemble node in the test and the results of the tests. <code>duration</code>: (string) The time required to run the test. <code>result</code>: (string) The results of the entire test. 	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestConnectEnsemble",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "nodes": {
        "1:10.10.20.70": "Passed",
        "2:10.10.20.71": "Passed",
        "3:10.10.20.72": "Passed",
        "4:10.10.20.73": "Passed",
        "5:10.10.20.74": "Passed"
      }
    },
    "duration": "00:00:00:756072",
    "result": "Passed"
  }
}
```

TestConnectMvip

You can use the `TestConnectMvip` method to test the management connection to the storage cluster. The test pings the MVIP and executes a simple API method to verify connectivity.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
mvip	You can pass this value to test the management connection of a different MVIP. You do not need to use this value when testing the connection to the target cluster.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
details	<p>Information about the test operation (JSON object):</p> <ul style="list-style-type: none"> • connected: Indicates if the test could connect to the MVIP (boolean) • mvip: The MVIP tested against (string) • pingBytes: Details of the ping tests with 56 bytes and 1500 bytes (object) <ul style="list-style-type: none"> ◦ 56: Results of the 56 Byte ping test (JSON object): <ul style="list-style-type: none"> - individualResponseTimes: List of response times from each ensemble node (string array) - individualStatus: List of ping status from each ensemble node (boolean array) - responseTime: Average ping response time (string) - successful: Indicates if the ping test was successful (boolean) ◦ 1500: Results of the 1500 byte ping test (JSON object): <ul style="list-style-type: none"> - individualResponseTimes: List of response times from each ensemble node (string array) - individualStatus: List of ping status from each ensemble node (boolean array) - responseTime: Average ping response time (string) - successful: Whether the ping test was successful (boolean) ◦ duration: Length of time required to run the test (string) ◦ result: Result of the test as a whole (string) 	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestConnectMvip",
  "params": {
    "mvip" : "172.27.62.50"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "connected": true,
```

```

    "mvip": "172.27.62.50",
    "pingBytes": {
      "1500": {
        "individualResponseTimes": [
          "00:00:00.000250",
          "00:00:00.000206",
          "00:00:00.000200",
          "00:00:00.000199",
          "00:00:00.000199"
        ],
        "individualStatus": [
          true,
          true,
          true,
          true,
          true
        ],
        "responseTime": "00:00:00.000211",
        "successful": true
      },
      "56": {
        "individualResponseTimes": [
          "00:00:00.000217",
          "00:00:00.000122",
          "00:00:00.000117",
          "00:00:00.000119",
          "00:00:00.000121"
        ],
        "individualStatus": [
          true,
          true,
          true,
          true,
          true
        ],
        "responseTime": "00:00:00.000139",
        "successful": true
      }
    },
    "duration": "00:00:00.271244",
    "result": "Passed"
  }
}

```

TestConnectSvip

You can use the `TestConnectSvip` method to test the storage connection to the storage cluster. The test pings the SVIP using ICMP packets, and when successful, connects as an iSCSI initiator.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
svip	You can pass this value to test the management connection of a different SVIP. You do not need to use this value when testing the connection to the target cluster.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
details	<p>Information about the test operation (JSON object):</p> <ul style="list-style-type: none"> • connected: Indicates if the test could connect to the SVIP (boolean) • svip: The SVIP tested against (string) • pingBytes: Details of the ping tests with 56 bytes and 9000 bytes (object) <ul style="list-style-type: none"> ◦ 56: Results of the 56 byte ping test (JSON object): <ul style="list-style-type: none"> - individualResponseTimes: List of response times from each ensemble node (string array) - individualStatus: List of ping status from each ensemble node (boolean array) - responseTime: Average ping response time (string) - successful: Indicates if the ping test was successful (boolean) ◦ 9000: Results of the 9000 Byte ping test (JSON object): <ul style="list-style-type: none"> - individualResponseTimes: List of response times from each ensemble node (string array) - individualStatus: List of ping status from each ensemble node (boolean array) - responseTime: Average ping response time (string) - successful: Indicates if the ping test was successful (boolean) ◦ duration: Length of time required to run the test (string) ◦ result: Result of the test as a whole (string) 	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestConnectSvip",
  "params": {
    "svip": "172.27.62.50"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "connected": true,
      "pingBytes": {
        "56": {
          "individualResponseTimes": [
            "00:00:00.000152",
            "00:00:00.000132",
            "00:00:00.000119",
            "00:00:00.000114",
            "00:00:00.000112"
          ],
          "individualStatus": [
            true,
            true,
            true,
            true,
            true
          ],
          "responseTime": "00:00:00.000126",
          "successful": true
        },
        "9000": {
          "individualResponseTimes": [
            "00:00:00.000295",
            "00:00:00.000257",
            "00:00:00.000172",
            "00:00:00.000172",
            "00:00:00.000267"
          ],
          "individualStatus": [
            true,
            true,
            true,
            true,
            true
          ],
          "responseTime": "00:00:00.000233",
          "successful": true
        }
      },
      "svip": "172.27.62.50"
    },
    "duration": "00:00:00.421907",
    "result": "Passed"
  }
}
```

TestDrives

You can use the `TestDrives` method to run a hardware validation on all drives on the node. This method detects hardware failures on the drives and reports any in the results of the validation tests.

You can only use the `TestDrives` method on nodes that are not "Active" in a cluster.

Note: This test takes approximately 10 minutes.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
force	Set to true to test the drives on the node.	boolean	None	Yes
minutes	Specifies the number of minutes for the test to run.	integer	10	No

Return value

This method has the following return value:

Name	Description	Type
details	Information about the test operation success or failure.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestDrives",
  "params": {
    "force": true,
    "minutes" : 10
  },
  "id" : 1
}
```

Response example

This method returns a table containing test results for each drive in the node.

TestHardwareConfig

You can use the `TestHardwareConfig` method to perform hardware tests on a node. Test options include verifying hardware configurations, firmware versions, and that all drives are present.

Note: These test are not intended to detect hardware failures.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
clean	<p>Starts the hardware configuration test with a clean cache. Possible values:</p> <ul style="list-style-type: none"> • true: Deletes the cached test results file and reruns the tests. • false: Retrieves a cached test results. 	boolean	false	No
force	The force parameter must be included in this method to successfully reset the node.	boolean	None	Yes

Return value

This method has the following return value:

Name	Description	Type
details	Hardware configuration details.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestHardwareConfig",
  "params": {
    "force": true
  },
  "id" : 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[TestHardwareConfig](#) on page 524

TestLocateCluster

You can use the `TestLocateCluster` method to validate that the node can locate the cluster specified in the cluster configuration. The output validates that the cluster has been created and lists the nodes in the cluster ensemble.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
details	Information about the test operation success or failure.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestLocateCluster",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "details": {
      "complete": true,
      "ensemble": {
        "nodes": [
          {
            "IP": "10.10.5.94",
            "nodeID": 1
          },
          {
            "IP": "10.10.5.107",
            "nodeID": 2
          },
          {
            "IP": "10.10.5.108",
            "nodeID": 3
          }
        ]
      },
      "version": "5.749"
    },
    "duration": "0.0384478sec",
    "result": "Passed"
  }
}
```

TestLocalConnectivity

You can use the `TestLocalConnectivity` method to ping the Cluster IP (CIP) of each node in an active cluster.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
details	Individual ping response times for each node in the local, active cluster.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestLocalConnectivity",
  "params": {},
  "id": 1
}
```

Response example

Requests for this method are similar to the following example:

```
{
  "id": null,
  "result": {
    "details": {
      "10.26.86.17": {
        "individualResponseTimes": [
          "00:00:00.006868",
          "00:00:00.005933",
          "00:00:00.006655",
          "00:00:00.006584",
          "00:00:00.006334"
        ],
        "individualStatus": [
          true,
          true,
          true,
          true,
          true
        ],
        "responseTime": "00:00:00.006475",
        "successful": true
      },
      "10.26.86.18": {
        "individualResponseTimes": [
          "00:00:00.006201",
          "00:00:00.006187",
          "00:00:00.005990",
          "00:00:00.006029",
          "00:00:00.005917"
        ],

```

```

        individualStatus: [
            true,
            true,
            true,
            true,
            true
        ],
        "responseTime": "00:00:00.006065",
        "successful": true
    },
    "10.26.86.19": {
        individualResponseTimes: [
            "00:00:00.005988",
            "00:00:00.006948",
            "00:00:00.005981",
            "00:00:00.005964",
            "00:00:00.005942"
        ],
        individualStatus: [
            "true",
            "true",
            true,
            true,
            true
        ],
        responseTime: "00:00:00.006165",
        successful: true,
    },
    "10.26.86.20": {
        individualResponseTimes: [
            "00:00:00.005926",
            "00:00:00.006072",
            "00:00:00.005675",
            "00:00:00.009904",
            "00:00:00.006225"
        ],
        "individualStatus": [
            true,
            true,
            true,
            true,
            true
        ],
        responseTime: "00:00:00.006760",
        successful: true
    }
},
"duration": "00:00:00.595982",
"result": "Passed"
}
}

```

TestNetworkConfig

You can use the `TestNetworkConfig` method to test that the configured network settings match the network settings being used on the system.

When you configure a node with the `SetNetworkConfig` method, in the UI or TUI, the configuration is validated and stored. The `TestNetworkConfig` API test uses the stored configuration for post-validation logic. For example, in the event of a power outage or network failure, you can use this API method to ensure a node is running with the most currently stored network configuration. This validates that there are no errors in the configuration and that the current configuration is in use.

This test is designed to only show failures in the response output. If there are no errors, this test does not return any output. See the following response examples.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
details	Contains any errors found when validating the currently stored network settings with the running network configuration.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestNetworkConfig",
  "params": {},
  "id" : 1
}
```

Response example 1

If no errors are detected, then no responses are returned.

```
{
  "id" : 1,
  "result": {
    "details": {
      "network": {...}
    },
    "duration": "00:00:00.144514",
    "result": "Passed"
  }
}
```

Response example 2

Example of an MTU Mismatch.

```
{
  "id" : 1,
  "result": {
    "details" : {
      "error": {
        "message" : "Network configuration mismatch on Bond10G:
Incorrect MTU expectedMTU=[1500]  actualMTU=[9600]", name:
"xAssertionFailure"
      },
      "duration": "0.125213sec",
      "result": "Failed"
    }
  }
}
```


Response example 3

Example of a missing static route.

```
{
  "id": 1,
  "result": {
    "details" : {
      "error": {
        "message" : "Network configuration mismatch on Bond1G: Routing
table missing route=[192.168.137.2 via 192.168.159.254 dev Bond1G]",
        name: "xAssertionFailure"
      }
    },
    "duration" : "0.128547sec",
    "result" : "Failed"
  }
}
```

Related references

[SetNetworkConfig](#) on page 227

TestPing

You can use the `TestPing` method to test network connectivity to all nodes in the cluster on both 1G and 10G interfaces using ICMP packets. The test uses the appropriate MTU sizes for each packet based on the MTU settings in the network configuration.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
attempts	Specifies the number of times the system should repeat the test ping.	integer	5	No
hosts	Specifies a comma-separated list of addresses or hostnames of devices to ping.	string	The nodes in the cluster	No
totalTimeoutSec	Specifies the time in seconds the ping should wait for a system response before issuing the next ping attempt or ending the process.	integer	5	No

Name	Description	Type	Default value	Required
packetSize	Specifies the number of bytes to send in the ICMP packet that is sent to each IP. The number of bytes must be less than the maximum MTU specified in the network configuration.	integer	None	No
pingTimeoutMsec	Specifies the number of milliseconds to wait for each individual ping response.	integer	500 ms	No
prohibitFragmentation	Enables the DF (Do not Fragment) flag for the ICMP packets.	boolean	false	No

Return value

This method has the following return value:

Name	Description	Type
details	List of each IP the node was able to communicate with.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestPing",
  "params": {
    "totalTimeoutSec": 3,
    "attempts": 4,
    "hosts": "127.0.1.1"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "result": "Passed",
    "duration": "0.0193463sec",
    "details": {
      "127.0.1.1": {
        "successful": true,
        "responseTime": "00:00:00.000035",
        "individualStatus": [
          true,
          true,
          true,
          true
        ]
      }
    }
  }
}
```

```

    ],
    "individualResponseTimes": [
      "00:00:00.000043",
      "00:00:00.000020",
      "00:00:00.000052",
      "00:00:00.000023"
    ]
  }
},
{
  "id": 1
}

```

TestRemoteConnectivity

You can use `TestRemoteConnectivity` method to ping each node of the remote cluster and check the remote ensemble database connection. Clusters must be paired in order to return useful results with this method. If the remote database connection fails, the response from the system lists the exceptions.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
details	Individual ping response times for each node.	JSON object

Request example

Requests for this method are similar to the following example:

```

{
  "method": "TestRemoteConnectivity",
  "params": {
    "force": "true"
  },
  "id": 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": null,
  "result": {
    "details": {
      "1": {
        "details": {
          "10.26.86.17": {
            "individualResponseTimes": [
              "00:00:00.006868",
              "00:00:00.005933",
              "00:00:00.006655",
              "00:00:00.006584",
              "00:00:00.006334"
            ]
          }
        }
      }
    }
  }
}

```

```

    ],
    "individualStatus": [
        "true",
        "true",
        "true",
        "true",
        "true"
    ],
    "responseTime": "00:00:00.006475",
    "successful": true
},
"10.26.86.18": {
    "individualResponseTimes": [
        "00:00:00.006201",
        "00:00:00.006187",
        "00:00:00.005990",
        "00:00:00.006029",
        "00:00:00.005917"
    ],
    "individualStatus": [
        "true",
        "true",
        "true",
        "true",
        "true"
    ],
    "responseTime": "00:00:00.006065",
    "successful": true
},
"10.26.86.19": {
    "individualResponseTimes": [
        "00:00:00.005988",
        "00:00:00.006948",
        "00:00:00.005981",
        "00:00:00.005964",
        "00:00:00.005942"
    ],
    "individualStatus": [
        "true",
        "true",
        "true",
        "true",
        "true"
    ],
    "responseTime": "00:00:00.006165",
    "successful": true,
},
"10.26.86.20": {
    "individualResponseTimes": [
        "00:00:00.005926",
        "00:00:00.006072",
        "00:00:00.005675",
        "00:00:00.009904",
        "00:00:00.006225"
    ],
    "individualStatus": [
        "true",
        "true",
        "true",
        "true",
        "true"
    ],
    "responseTime": "00:00:00.006760",
    "successful": true
},
},
"successful": true
}
},
"duration": "00:00:00.595982",
"result": "Passed"

```

```
} }
```

Replication API methods

Replication API methods enable you to connect two clusters for continuous data protection (CDP). When you connect two clusters, active volumes within a cluster can be continuously replicated to a second cluster to provide data recovery. By pairing volumes for replication, you can protect your data from events that might render it inaccessible.

Cluster pairing order of operations

You must establish a connection between a pair of storage clusters running Element software before remote replication can be used.

Use the following set of API methods to establish a cluster connection:

- [*StartClusterPairing*](#):
This API method creates and returns a pairing key that is used to establish a cluster pair. The key is encoded and contains information that is used to establish communications between clusters. A single cluster can be paired with up to four other clusters. However, a new key must be generated for each cluster pairing. The [*StartClusterPairing*](#) method generates a new key each time the method is called. Use each unique key with the [*CompleteClusterPairing*](#) method to pair each additional cluster.

Note: For security reasons, the pairing key should not be sent to other users via email. The key contains a user name and password.
- [*CompleteClusterPairing*](#):
This method uses the pairing key created with the [*StartClusterPairing*](#) API method to create a cluster pair. Issue the [*CompleteClusterPairing*](#) API method with the `clusterPairingKey` parameter to the destination. The origination cluster is the cluster that created the key.

Related references

[*StartClusterPairing*](#) on page 254

[*CompleteClusterPairing*](#) on page 247

Volume pairing order of operations

You must create a cluster pair between two corresponding clusters before volumes can be paired.

Use the following set of API methods to establish a cluster connection:

- [*StartVolumePairing*](#):
This API method creates and returns a volume pairing key that is used to create a volume pair. The key contains information that is used to establish communications between volumes.
- [*CompleteVolumePairing*](#):
This method uses the pairing key created with the [*StartVolumePairing*](#) API method to create a volume pair. Issue the [*CompleteVolumePairing*](#) API method with the `volumeID` and `volumePairingKey` parameters to the destination volume.

Only one of the paired volumes can be identified as a replication target volume. Use the [*ModifyVolumePair*](#) API method to establish the direction of the volume's data replication by identifying which volume is the target. Data is replicated from the source volume to the target volume.

Related references

[StartVolumePairing](#) on page 255

[CompleteVolumePairing](#) on page 248

[ModifyVolumePair](#) on page 251

Supported modes of replication for paired clusters

The following modes of replication are supported on the paired clusters:

- Asynchronous replication of data: The data sent to the replication target volume is sent asynchronously. The system does not wait for an acknowledgment to be sent before writing data.
- Synchronous replication of data: The data sent to the replication target volume is sent synchronously. When the I/O operations sent from the host are acknowledged by the system, the system acknowledgment is sent back to the host and the data is sent to the replication target volume.
- Snapshots-only replication of data: Only volume snapshots are replicated to the target cluster.

CompleteClusterPairing

The `CompleteClusterPairing` method is the second step in the cluster pairing process. Use this method with the encoded key received from the `StartClusterPairing` method to complete the cluster pairing process.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>clusterPairingKey</code>	A string of characters that is returned from the StartClusterPairing API method.	string	None	Yes

Return value

This method has the following return value:

Name	Description	Type
<code>clusterPairID</code>	Unique identifier for the cluster pair.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CompleteClusterPairing",
  "params": {
    "clusterPairingKey" :
    "7b22636c7573746572506169724944223a312c22636c7573746572506169725555494422
    3a2231636561313336322d346338662d343631612d626537322d373435363661393533643
    266222c22636c7573746572556e697175654944223a2278736d36222c226d766970223a22
    3139322e3136382e3133392e313232222c226e616d65223a224175746f54657374322d633
    0755222c2270617373776f7264223a22695e59686f20492d64774d7d4c67614b222c2272
```

```
7063436f6e6e656374696f6e4944223a3931333134323634392c22757365726e616d65223
a225f5f53465f706169725f50597a796647704c7246564432444a42227d"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "clusterPairID" : 1
  }
}
```

Related references

[StartClusterPairing](#) on page 254

CompleteVolumePairing

You can use CompleteVolumePairing to complete the pairing of two volumes.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeID	The ID of volume that will complete the volume pair.	integer	None	Yes
volumePairingKey	The key returned from the StartVolumePairing API method.	string	None	Yes

Return value

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CompleteVolumePairing",
  "params": {
    "volumeID" : 12,
    "volumePairingKey" :
"7b22636c7573746572506169724944223a312c22636c7573746572506169725555494422
3a2231636561313336322d346338662d343631612d626537322d373435363661393533643
266222c22636c75737465725556e697175654944223a2278736d36222c226d766970223a22
3139322e3136382e3133392e313232222c226e616d65223a224175746f54657374322d633
0755222c2270617373776f7264223a22695e59686f20492d64774d7d4c67614b222c2272
7063436f6e6e656374696f6e4944223a3931333134323634392c22757365726e616d65223
a225f5f53465f706169725f50597a796647704c7246564432444a42227d"
  },
}
```



```
{
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

Related references

[Start VolumePairing](#) on page 255

ListClusterPairs

You can use the `ListClusterPairs` method to list all clusters that are paired with the current cluster. This method returns information about active and pending cluster pairings, such as statistics about the current pairing as well as the connectivity and latency (in milliseconds) of the cluster pairing.

Parameter

This method has no input parameter:

Return value

This method has the following return value:

Name	Description	Type
clusterPairs	Information about each paired cluster.	clusterPair array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListClusterPairs",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterPairs": [
      {
        "clusterName": "cluster2",
        "clusterPairID": 3,
        "clusterPairUUID": "9866fbeb-c2f8-4df3-beb9-58a5c4e49c9b",

```

```

        "clusterUUID": 5487,
        "latency": 1,
        "mvip": "172.1.1.5",
        "status": "Connected",
        "version": "8.0.0.1361"
      },
      {
        "clusterName": "cluster3",
        "clusterPairID": 2,
        "clusterPairUUID": "8132a699-ce82-41e0-b406-fb914f976042",
        "clusterUUID": 1383,
        "latency": 1,
        "mvip": "172.1.1.6",
        "status": "Connected",
        "version": "8.0.0.1361"
      }
    ]
  }
}

```

ListActivePairedVolumes

You can use the `ListActivePairedVolumes` method to list all of the active volumes paired with a volume. This method returns information about volumes with active and pending pairings.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
volumes	Volume information for the paired volumes.	<i>volumePair</i> array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListActivePairedVolumes",
  "params": {
  },
  "id" : 1
}

```

Response example

Responses for this method are similar to the following example:

```

{
  "id": 1,
  "result": {
    "volumes": [
      {
        "access": "readWrite",
        "accountID": 1,
        "attributes": {},
        "blockSize": 4096,
        "createTime": "2016-06-24T15:21:59Z",
        "deleteTime": "",

```

```

"enable512e": true,
"iqn": "iqn.2010-01.com.solidfire:0oto.bk.24",
"name": "BK",
"purgeTime": "",
"qos": {
  "burstIOPS": 15000,
  "burstTime": 60,
  "curve": {
    "4096": 100,
    "8192": 160,
    "16384": 270,
    "32768": 500,
    "65536": 1000,
    "131072": 1950,
    "262144": 3900,
    "524288": 7600,
    "1048576": 15000
  },
  "maxIOPS": 15000,
  "minIOPS": 50
},
"scsiEUIDeviceID": "306f746f00000018f47acc0100000000",
"scsiNAADeviceID": "6f47acc100000000306f746f00000018",
"sliceCount": 1,
"status": "active",
"totalSize": 10737418240,
"virtualVolumeID": null,
"volumeAccessGroups": [],
"volumeID": 24,
"volumePairs": [
  {
    "clusterPairID": 2,
    "remoteReplication": {
      "mode": "Async",
      "pauseLimit": 3145728000,
      "remoteServiceID": 14,
      "resumeDetails": "",
      "snapshotReplication": {
        "state": "Idle",
        "stateDetails": ""
      },
      "state": "Active",
      "stateDetails": ""
    },
    "remoteSliceID": 8,
    "remoteVolumeID": 8,
    "remoteVolumeName": "PairingDoc",
    "volumePairUUID": "229fcbf3-2d35-4625-865a-
d04bb9455cef"
  }
]
}

```

ModifyVolumePair

You can use the `ModifyVolumePair` method to pause or restart replication between a pair of volumes. This method is set on the source volume (the volume with read/write access).

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeID	Identification number of the volume to be modified.	integer	None	Yes
pausedManual	<p>Remote replication can be paused or restarted on the source (read/write) volume. Possible values:</p> <ul style="list-style-type: none"> • <code>true</code>: Pause volume replication. • <code>false</code>: Restart volume replication. <p>If no value is specified, no change in replication is performed.</p>	boolean	None	No
mode	<p>Volume replication mode. Possible values:</p> <ul style="list-style-type: none"> • <code>Async</code>: Writes are acknowledged when they complete locally. The cluster does not wait for writes to be replicated to the target cluster. • <code>Sync</code>: The source acknowledges the write when the data is stored locally and on the remote cluster. • <code>SnapshotsOnly</code>: Only snapshots created on the source cluster are replicated. Active writes from the source volume are not replicated. 	string	None	No

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyVolumePair",
  "params": {
    "pausedManual": false,
    "volumeID": 5,
    "mode": "sync"
  },
}
```

```
{
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

RemoveClusterPair

You can use the `RemoveClusterPair` method to close the open connections between two paired clusters.

Note: Before you remove a cluster pair, you must first remove all volume pairing to the clusters with the `RemoveVolumePair` API method.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
clusterPairID	Unique identifier used to pair two clusters.	integer	None	Yes

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveClusterPair",
  "params": {
    "clusterPairID": 1
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

RemoveVolumePair

You can use the `RemoveVolumePair` method to remove the remote pairing between two volumes. Use this method on both the source and target volumes that are paired together. When you remove the volume pairing information, data is no longer replicated to or from the volume.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	ID of the volume on which to stop the replication process.	integer	None	Yes

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveVolumePair",
  "params": {
    "volumeID": 5
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
  }
}
```

StartClusterPairing

You can use the `StartClusterPairing` method to create an encoded key from a cluster that is used to pair with another cluster. The key created from this API method is used in the `CompleteClusterPairing` method to establish a cluster pairing. You can pair a cluster with a maximum of four other clusters.

Parameter

This method has no input parameter.

Return values

This method has the following return values:

Name	Description	Type
clusterPairingKey	A string of characters that is used by the CompleteClusterPairing API method.	string
clusterPairID	Unique identifier for the cluster pair.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "StartClusterPairing",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterPairID": 1,
    "clusterPairingKey":
    "7b22636c7573746572506169724944223a312c22636c7573746572506169725555494422
    3a2231636561313336322d346338662d343631612d626537322d373435363661393533643
    266222c22636c7573746572556e697175654944223a2278736d36222c226d766970223a22
    3139322e3136382e3133392e313232222c226e616d65223a224175746f54657374322d633
    0755222c2270617373776f7264223a22695e59686f20492d64774d7d4c67614b222c2272
    7063436f6e6e656374696f6e4944223a3931333134323634392c22757365726e616d65223
    a225f5f53465f706169725f50597a796647704c7246564432444a42227d"
  }
}
```

Related references

[CompleteClusterPairing](#) on page 247

StartVolumePairing

You can use the `StartVolumePairing` method to create an encoded key from a volume that is used to pair with another volume. The key that this method creates is used in the `CompleteVolumePairing` method to establish a volume pairing.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
mode	<p>The mode of the volume on which to start the pairing process. The mode can only be set if the volume is the source volume. Possible values:</p> <ul style="list-style-type: none"> • Async: Writes are acknowledged when they complete locally. The cluster does not wait for writes to be replicated to the target cluster. (Default if no mode parameter specified.) • Sync: Source acknowledges write when the data is stored locally and on the remote cluster. • SnapshotsOnly: Only snapshots created on the source cluster are replicated. Active writes from the source volume are not replicated. 	string	None	No
volumeID	The ID of the volume on which to start the pairing process.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
volumePairingKey	A string of characters that is used by the Complete VolumePairing API method.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "StartVolumePairing",
  "params": {
    "mode": "Async",
    "volumeID" : 14
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "volumePairingKey" :
    "7b226d766970223a223139322e3136382e31333392e313232222c22766f6c756d65494422
    3a312c22766f6c756d654e616d65223a2254657374222c22766f6c756d65506169725554
    944223a2236393632346663622d323032652d343332352d613536392d6563396336353563
  }
}
```



```
37623561227d"  
  }  
}
```

Related references

[*Complete VolumePairing*](#) on page 248

SnapMirror API methods

SnapMirror API methods are used by the Element web UI for managing snapshots mirrored with remote ONTAP systems. These methods are meant for use by the Element web UI only. If you need API access to SnapMirror functionality, use the ONTAP APIs. Request and return examples are not provided for SnapMirror API methods.

AbortSnapMirrorRelationship

The Element software web UI uses the `AbortSnapMirrorRelationship` method to stop SnapMirror transfers that have started but are not yet complete.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>snapMirrorEndpointID</code>	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
<code>destinationVolume</code>	The destination volume in the SnapMirror relationship.	<i>snapMirrorVolumeInfo</i>	None	Yes
<code>clearCheckpoint</code>	Determines whether or not to clear the restart checkpoint. Possible values: <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean	false	No

Return values

This method has the following return values:

Name	Description	Type
<code>snapMirrorRelationship</code>	An object containing information about the aborted SnapMirror relationship.	<i>snapMirrorRelationship</i>

BreakSnapMirrorRelationship

The Element web UI uses the `BreakSnapMirrorRelationship` method to break a SnapMirror relationship. When a SnapMirror relationship is broken, the destination volume is made read-write and independent, and can then diverge from the source. You can reestablish the relationship with the

ResyncSnapMirrorRelationship API method. This method requires the ONTAP cluster to be available.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	snapMirrorVolumeInfo	None	Yes

Return values

This method has the following return values:

Name	Description	Type
snapMirrorRelationship	An object containing information about the broken SnapMirror relationship.	snapMirrorRelationship

Related references

[BreakSnapMirrorVolume](#) on page 259

BreakSnapMirrorVolume

The Element web UI uses the BreakSnapMirrorVolume method to break the SnapMirror relationship between an ONTAP source container and Element target volume. Breaking an Element SnapMirror volume is useful if an ONTAP system becomes unavailable while replicating data to an Element volume. This feature enables a storage administrator to take control of an Element SnapMirror volume, break its relationship with the remote ONTAP system, and revert the volume to a previous snapshot.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	The volume on which to perform the break operation. The volume access mode must be snapMirrorTarget.	integer	None	Yes
snapshotID	Roll back the volume to the snapshot identified by this ID. The default behavior is to roll back to the most recent snapshot.	integer	None	No

Name	Description	Type	Default value	Required
preserve	<p>Preserve any snapshots newer than the snapshot identified by snapshotID. Possible values:</p> <ul style="list-style-type: none"> • true: Preserve snapshots newer than snapshotID. • false: Do not preserve snapshots newer than snapshotID. <p>If false, any snapshots newer than snapshotID are deleted.</p>	boolean	false	No
access	<p>Resulting volume access mode. Possible values:</p> <ul style="list-style-type: none"> • readWrite • readOnly • locked 	string	readWrite	No

Return values

This method has no return values.

Related references

[BreakSnapMirrorRelationship](#) on page 258

CreateSnapMirrorEndpoint

The Element web UI uses the CreateSnapMirrorEndpoint method to create a relationship with a remote SnapMirror endpoint.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
managementIP	The management IP address of the remote SnapMirror endpoint.	string	None	Yes
username	The management user name for the ONTAP system.	string	None	Yes
password	The management password for the ONTAP system.	string	None	Yes

Return values

This method has the following return values:

Name	Description	Type
snapMirrorEndpoint	The newly created SnapMirror endpoint.	<i>snapMirrorEndpoint</i>

CreateSnapMirrorEndpointUnmanaged

The Element software storage system uses the `CreateSnapMirrorEndpointUnmanaged` method to enable remote, unmanaged SnapMirror endpoints to communicate with a Element storage cluster. Unmanaged endpoints cannot be administered using the Element SnapMirror APIs. They must be managed with ONTAP management software or APIs.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
clusterName	The name of the endpoint.	string	None	Yes
ipAddresses	The list of IP addresses for a cluster of ONTAP storage systems that should communicate with this Element storage cluster.	string array	None	Yes

Return values

This method has the following return values:

Name	Description	Type
snapMirrorEndpoint	The newly created SnapMirror endpoint.	<i>snapMirrorEndpoint</i>

CreateSnapMirrorRelationship

The Element web UI uses the `CreateSnapMirrorRelationship` method to create a SnapMirror extended data protection relationship between a source and destination endpoint.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
sourceVolume	The source volume in the relationship.	<i>snapMirrorVolumeInfo</i>	None	Yes

Name	Description	Type	Default value	Required
destinationVolume	The destination volume in the relationship.	snapMirrorVolumeInfo	None	Yes
relationshipType	The type of relationship. On storage systems running Element software, this value is always “extended_data_protection”.	string	None	No
policyName	Specifies the name of the ONTAP SnapMirror policy for the relationship. If not specified, the default policy name is MirrorLatest.	string	None	No
scheduleName	The name of the pre-existing cron schedule on the ONTAP system that is used to update the SnapMirror relationship. If no schedule is designated, snapMirror updates are not scheduled and must be updated manually.	string	None	No
maxTransferRate	Specifies the maximum data transfer rate between the volumes in kilobytes per second. The default value, 0, is unlimited and permits the SnapMirror relationship to fully utilize the available network bandwidth.	integer	None	No

Return values

This method has the following return values:

Name	Description	Type
snapMirrorRelationship	Information about the newly created SnapMirror relationship.	snapMirrorRelationship

CreateSnapMirrorVolume

The Element web UI uses the `CreateSnapMirrorVolume` method to create a volume on the remote ONTAP system.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>snapMirrorEndpointID</code>	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
<code>vserver</code>	The name of the Vserver.	string	None	Yes
<code>name</code>	The destination ONTAP volume name.	string	None	Yes
<code>type</code>	<p>The volume type. Possible values:</p> <ul style="list-style-type: none"> <code>rw</code>: Read-write volume <code>ls</code>: Load-sharing volume <code>dp</code>: Data protection volume <p>If no type is provided, the default type is <code>dp</code>.</p>	string	None	No
<code>aggregate</code>	The containing ONTAP aggregate in which to create the volume. You can use <code>ListSnapMirrorAggregates</code> to get information about available ONTAP aggregates.	string	None	Yes
<code>size</code>	The size of the volume in bytes.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
snapMirrorVolume	Information about a SnapMirror volume.	<i>snapMirrorVolume</i>

DeleteSnapMirrorEndpoints

The Element web UI uses `DeleteSnapMirrorEndpoints` to delete one or more SnapMirror endpoints from the system.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snapMirrorEndpointIDs	An array of IDs of SnapMirror endpoints to delete.	integer array	None	Yes

Return values

This method has no return values.

DeleteSnapMirrorRelationships

The Element web UI uses the `DeleteSnapMirrorRelationships` method to remove one or more SnapMirror relationships between a source and destination endpoint.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
destinationVolumes	The destination volume or volumes in the SnapMirror relationship.	<i>snapMirrorVolumeInfo</i> array	None	Yes

Return values

This method has the following return values:

Name	Description	Type
result	If the delete action succeeded, this object contains a success message. If the action failed, it contains an error message.	JSON object

GetOntapVersionInfo

The Element web UI uses `GetOntapVersionInfo` to get information about API version support from the ONTAP cluster in a SnapMirror relationship.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>snapMirrorEndpointID</code>	If provided, the system lists the version information from the endpoint with the specified <code>snapMirrorEndpointID</code> . If not provided, the system lists the version information of all known SnapMirror endpoints.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>ontapVersionInfo</code>	The software version information of the ONTAP endpoint.	<i>ontapVersionInfo</i> array

GetSnapMirrorClusterIdentity

The Element software web UI uses `GetSnapMirrorClusterIdentity` to get identity information about the ONTAP cluster.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>snapMirrorEndpointID</code>	If provided, the system lists the cluster identity of the endpoint with the specified <code>snapMirrorEndpointID</code> . If not provided, the system lists the cluster identity of all known SnapMirror endpoints.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorClusterIdentity	A list of cluster identities of SnapMirror endpoints.	<i>snapMirrorClusterIdentity</i> array

InitializeSnapMirrorRelationship

The Element software web UI uses the `InitializeSnapMirrorRelationship` method to initialize the destination volume in a SnapMirror relationship by performing an initial baseline transfer between clusters.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The ID of the remote ONTAP system.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	<i>snapMirrorVolumeInfo</i>	None	Yes
maxTransferRate	Specifies the maximum data transfer rate between the volumes in kilobytes per second. The default value, 0, is unlimited and permits the SnapMirror relationship to fully utilize the available network bandwidth.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationship	Information about the initialized SnapMirror relationship.	<i>snapMirrorRelationship</i>

ListSnapMirrorAggregates

The Element software web UI uses the `ListSnapMirrorAggregates` method to list all SnapMirror aggregates that are available on the remote ONTAP system. An aggregate describes a set of physical storage resources.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>snapMirrorEndpointID</code>	Return only the aggregates associated with the specified endpoint ID. If no endpoint ID is provided, the system lists aggregates from all known SnapMirror endpoints.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>snapMirrorAggregates</code>	A list of the aggregates available on the ONTAP storage system.	<i>snapMirrorAggregate</i> array

ListSnapMirrorEndpoints

The Element software web UI uses the `ListSnapMirrorEndpoints` method to list all SnapMirror endpoints that the Element storage cluster is communicating with.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>snapMirrorEndpointIDs</code>	Return only the objects associated with these IDs. If no IDs are provided or the array is empty, the method returns all SnapMirror endpoint IDs.	integer array	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorEndpoints	A list of existing SnapMirror endpoints.	<i>snapMirrorEndpoint</i> array

ListSnapMirrorLuns

The Element software web UI uses the `ListSnapMirrorLuns` method to list the LUN information for the SnapMirror relationship from the remote ONTAP cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	List only the LUN information associated with the specified endpoint ID.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	<i>snapMirrorVolumeInfo</i>	None	Yes

Return values

This method has the following return values:

Name	Description	Type
snapMirrorLunInfos	A list of objects containing information about SnapMirror LUNs.	<i>snapMirrorLunInfo</i> array

ListSnapMirrorNetworkInterfaces

The Element software web UI uses the `ListSnapMirrorNetworkInterfaces` method to list all available SnapMirror interfaces on a remote ONTAP system.

Parameter

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	Return only the network interfaces associated with the specified endpoint ID. If no endpoint ID is provided, the system lists interfaces from all known SnapMirror endpoints.	integer	None	No
interfaceRole	List only the network interface serving the specified role.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorNetworkInterfaces	A list of the SnapMirror network interfaces available on the remote ONTAP storage system.	<i>snapMirrorNetworkInterface</i> array

ListSnapMirrorNodes

The Element software web UI uses the `ListSnapMirrorNodes` method to get a list of nodes in a remote ONTAP cluster.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	If provided, the system lists the nodes of the endpoint with the specified snapMirrorEndpointID . If not provided, the system lists the nodes of all known SnapMirror endpoints.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorNodes	A list of the nodes on the ONTAP cluster.	<i>snapMirrorNode</i> array

ListSnapMirrorPolicies

The Element software web UI uses the `ListSnapMirrorPolicies` method to list all SnapMirror policies on a remote ONTAP system.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	List only the policies associated with the specified endpoint ID. If no endpoint ID is provided, the system lists policies from all known SnapMirror endpoints.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorPolicies	A list of the SnapMirror policies on the ONTAP storage system.	<i>snapMirrorPolicy</i> array

ListSnapMirrorSchedules

The Element software web UI uses the `ListSnapMirrorSchedules` method to get a list of schedules that are available on a remote ONTAP cluster.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	If provided, the system lists the schedules of the endpoint with the specified SnapMirror endpoint ID. If not provided, the system lists the schedules of all known SnapMirror endpoints.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorSchedules	A list of the SnapMirror schedules on the remote ONTAP cluster.	snapMirrorJobScheduleCronInfo on page 62 array

ListSnapMirrorRelationships

The Element software web UI uses the `ListSnapMirrorRelationships` method to list one or all SnapMirror relationships on an Element storage cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	List only the relationships associated with the specified endpoint ID. If no endpoint ID is provided, the system lists relationships from all known SnapMirror endpoints.	integer	None	No
destinationVolume	List relationships associated with the specified destination volume.	snapMirrorVolumeInfo	None	No
sourceVolume	List relationships associated with the specified source volume.	snapMirrorVolumeInfo	None	No
vserver	List relationships on the specified Vserver.	string	None	No

Name	Description	Type	Default value	Required
relationshipID	List relationships associated with the specified relationship ID.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationships	A list of objects containing information about SnapMirror relationships.	<i>snapMirrorRelationship</i> array

ListSnapMirrorVolumes

The Element software web UI uses the `ListSnapMirrorVolumes` method to list all SnapMirror volumes available on a remote ONTAP system.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	List only the volumes associated with the specified endpoint ID. If no endpoint ID is provided, the system lists volumes from all known SnapMirror endpoints.	integer	None	No
vserver	List volumes hosted on the specified Vserver. The Vserver must be of type "data".	string	None	No
name	List only ONTAP volumes with the specified name.	string	None	No

Name	Description	Type	Default value	Required
type	List only ONTAP volumes of the specified type. Possible values: <ul style="list-style-type: none"> • <code>rw</code>: Read-write volumes • <code>ls</code>: Load-sharing volumes • <code>dp</code>: Data protection volumes 	string	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorVolumes	A list of the SnapMirror volumes available on the ONTAP storage system.	snapMirrorVolume on page 69 array

ListSnapMirrorVservers

The Element software web UI uses the `ListSnapMirrorVservers` method to list all SnapMirror Vservers available on a remote ONTAP system.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	List only the Vservers associated with the specified endpoint ID. If no endpoint ID is provided, the system lists Vservers from all known SnapMirror endpoints.	integer	None	No

Name	Description	Type	Default value	Required
vserverType	List only Vservers of the specified type. Possible values: <ul style="list-style-type: none"> • admin • data • node • system 	string	None	No
vserverName	List only Vservers with the specified name.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorVservers	A list of the SnapMirror Vservers available on the ONTAP storage system.	<i>snapMirrorVserver</i> array

ModifySnapMirrorEndpoint

The Element software web UI uses the `ModifySnapMirrorEndpoint` method to change the name and management attributes for a SnapMirror endpoint.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
SnapMirrorEndpointID	The SnapMirror endpoint to modify.	integer	None	Yes
managementIP	The new management IP Address for the ONTAP system.	string	None	No
username	The new management user name for the ONTAP system.	string	None	No
password	The new management password for the ONTAP system.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorEndpoint	Information about the modified SnapMirror endpoint.	<i>snapMirrorEndpoint</i>

ModifySnapMirrorEndpoint (unmanaged)

Element software uses this version of the `ModifySnapMirrorEndpoint` method to modify the storage cluster name or IP address attributes for an unmanaged SnapMirror endpoint. Unmanaged endpoints cannot be administered using the Element SnapMirror APIs. They must be managed with ONTAP management software or APIs.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
SnapMirrorEndpointID	The SnapMirror endpoint to modify.	integer	None	Yes
clusterName	The new name of the endpoint.	string	None	No
ipAddresses	The new list of IP addresses for a cluster of ONTAP storage systems that should communicate with this Element storage cluster.	string array	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorEndpoint	Information about the modified SnapMirror endpoint.	<i>snapMirrorEndpoint</i>

ModifySnapMirrorRelationship

You can use `ModifySnapMirrorRelationship` to change the intervals at which a scheduled snapshot occurs. You can also delete or pause a schedule by using this method.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
destinationVolume	The destination volume in the SnapMirror relationship.	<i>snapMirrorVolumein fo</i>	None	Yes
maxTransferRate	Specifies the maximum data transfer rate between the volumes in kilobytes per second. The default value, 0, is unlimited and permits the SnapMirror relationship to fully utilize the available network bandwidth.	integer	None	No
policyName	Specifies the name of the ONTAP SnapMirror policy for the relationship.	string	None	No
scheduleName	The name of the pre-existing cron schedule on the ONTAP system that is used to update the SnapMirror relationship.	string	None	No
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationship	An object containing the modified SnapMirror relationship attributes.	<i>snapMirrorRelationship</i>

UpdateSnapMirrorRelationship

The Element software web UI uses the `UpdateSnapMirrorRelationship` method to make the destination volume in a SnapMirror relationship an up-to-date mirror of the source volume.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	snapMirrorVolumeinfo	None	Yes
maxTransferRate	Specifies the maximum data transfer rate between the volumes in kilobytes per second. The default value, 0, is unlimited and permits the SnapMirror relationship to fully utilize the available network bandwidth.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationship	An object containing information about the updated SnapMirror relationship.	snapMirrorRelationship

QuiesceSnapMirrorRelationship

The Element software web UI uses the `QuiesceSnapMirrorRelationship` method to disable future data transfers for a SnapMirror relationship. If a transfer is in progress, the relationship status becomes "quiescing" until the transfer is complete. If the current transfer is aborted, it will not restart. You can reenable data transfers for the relationship using the `ResumeSnapMirrorRelationship` API method.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	snapMirrorVolumeinfo	None	Yes

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationship	An object containing information about the quiesced SnapMirror relationship.	<i>snapMirrorRelationship</i>

ResumeSnapMirrorRelationship

The Element software web UI uses the `ResumeSnapMirrorRelationship` method to enable future transfers for a quiesced SnapMirror relationship.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	<i>snapMirrorVolumeinfo</i>	None	Yes

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationship	An object containing information about the resumed SnapMirror relationship.	<i>snapMirrorRelationship</i>

ResyncSnapMirrorRelationship

The Element software web UI uses the `ResyncSnapMirrorRelationship` method to establish or reestablish a mirror relationship between a source and destination endpoint. When you resync a relationship, the system removes snapshots on the destination volume that are newer than the common snapshot copy, and then mounts the destination volume as a data protection volume with the common snapshot copy as the exported snapshot copy.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapMirrorEndpointID	The endpoint ID of the remote ONTAP storage system communicating with the Element storage cluster.	integer	None	Yes
destinationVolume	The destination volume in the SnapMirror relationship.	snapMirror Volumeinfo	None	Yes
maxTransferRate	Specifies the maximum data transfer rate between the volumes in kilobytes per second. The default value, 0, is unlimited and permits the SnapMirror relationship to fully utilize the available network bandwidth.	integer	None	No
sourceVolume	The source volume in the SnapMirror relationship.	snapMirror Volumeinfo	None	No

Return value

This method has the following return value:

Name	Description	Type
snapMirrorRelationship	An object containing information about the resynced SnapMirror relationship.	snapMirrorRelationship

System configuration API methods

System configuration API methods enable you to obtain and set configuration values that apply to all nodes in the cluster.

DisableClusterSsh

You can use the `DisableClusterSsh` method to disable the SSH service for the entire storage cluster. When you add nodes to the storage cluster, the new nodes will inherit this cluster-wide setting.

Parameter

This method has no input parameter.

Return value

This method has the following return value:

Name	Description	Type
result	A JSON object containing the status of the SSH service for the storage cluster, the time remaining until SSH is disabled, and the SSH service status for each node.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DisableClusterSsh",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : {
    "enabled": true,
    "timeRemaining": "00:43:21",
    "nodes": [
      {
        "nodeID": 1,
        "enabled": true
      },
      {
        "nodeID": 2,
        "enabled": true
      },
      {
        "nodeID": 3,
        "enabled": false
      }
    ]
  }
}
```



```

    },
    {
      "nodeID": 4,
      "enabled": false
    } ]
  }
}

```

DisableSnmpp

You can use the `DisableSnmpp` method to disable SNMP on the cluster nodes.

Parameter

This method has no input parameter.

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "DisableSnmpp",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "result" : {},
  "id" : 1
}

```

EnableClusterSsh

You can use the `EnableClusterSsh` method to enable the SSH service on all nodes in the storage cluster.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
duration	The amount of time that the SSH service will remain enabled.	string	None	Yes

Return values

This method has the following return values:

Name	Description	Type
result	A JSON object containing the status of the SSH service for the storage cluster, the time remaining until SSH is disabled, and the SSH service status for each node.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "EnableClusterSsh",
  "params": {
    "duration" : "02:00:00.00"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : {
    "enabled": true,
    "timeRemaining": "00:43:21",
    "nodes": [
      {
        "nodeID": 1,
        "enabled": true
      },
      {
        "nodeID": 2,
        "enabled": true
      },
      {
        "nodeID": 3,
        "enabled": false
      },
      {
        "nodeID": 4,
        "enabled": false
      }
    ]
  }
}
```

EnableSnmpp

You can use the `EnableSnmpp` method to enable SNMP on cluster nodes. When you enable SNMP, the action applies to all nodes in the cluster, and the values that are passed replace all values set in any previous call to `EnableSnmpp`.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
snmpV3Enabled	If set to <code>true</code> , then SNMP v3 is enabled on each node in the cluster. If set to <code>false</code> , then SNMP v2 is enabled.	boolean	false	No

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "EnableSnmp",
  "params": {
    "snmpV3Enabled" : "true"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

GetClusterSshInfo

You can use the `GetClusterSshInfo` method to query the status of the SSH service for the entire storage cluster.

Parameter

This method has no input parameter.

Return value

This method has the following return value:

Name	Description	Type
result	A JSON object containing the status of the SSH service for the storage cluster, the time remaining until SSH is disabled, and the SSH service status for each node.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterSshInfo",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : {
    "enabled": "true",
    "timeRemaining": "00:43:21",
    "nodes": [
      {
        "nodeID": 1,
        "enabled": true
      },
      {
        "nodeID": 2,
        "enabled": true
      },
      {
        "nodeID": 3,
        "enabled": false
      },
      {
        "nodeID": 4,
        "enabled": false
      }
    ]
  }
}
```

GetClusterStructure

You can use the `GetClusterStructure` method to back up the current storage cluster configuration information. If the storage cluster configuration is changed while this method is running, the contents of the configuration backup will be unpredictable. You can save this data to a text file and restore it on other clusters, or the same cluster in the case of a disaster.

Parameter

This method has no input parameter.

Return values

This method has the following return values:

Name	Description	Type
result	A JSON object containing the current storage cluster configuration information.	<i>clusterStructure</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetClusterStructure",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : <clusterStructure object containing configuration
information>
}
```

GetFipsReport

You can use the `GetFipsReport` method to check the FIPS 140-2 encryption feature support status of all nodes in the storage cluster.

Parameter

This method has no input parameter.

Return values

This method has the following return values:

Name	Description	Type
result	A JSON object containing the status of FIPS 140-2 feature support for every node, and error information for each node that did not respond to the query.	<i>fipsReport</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetFipsReport",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nodes": [
      {
```

```

        "nodeID": 1,
        "httpsEnabled": true
      },
      {
        "nodeID": 3,
        "httpsEnabled": true
      }
    ],
    "errorNodes": [
      {
        "nodeID": 2,
        "error": {
          "message": "The RPC timed out.",
          "name": "xRpcTimeout"
        }
      }
    ]
  }
}

```

GetLldpConfig

You can use the `GetLldpConfig` method to get the Link Layer Discovery Protocol (LLDP) configuration for each node of a storage cluster.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
lldpConfig	Information about the storage cluster LLDP configuration.	JSON object

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetLldpConfig",
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": null,
  "result": {
    "lldpConfig": {
      "enableLldp": true,
      "enableMed": false,
      "enableOtherProtocols": true
    }
  }
}

```

GetLldpInfo

You can use the `GetLldpInfo` method to get the Link Layer Discovery Protocol (LLDP) configuration for each node of a storage cluster, or an individual storage node.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
lldpInfo	Information about the chassis, interface, and neighbor LLDP settings for each node of a storage cluster.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetLimits",
  "id" : 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[GetLldpInfo](#) on page 482

GetNtpInfo

You can use the `GetNtpInfo` method to get the current network time protocol (NTP) configuration information.

Parameter

This method has no input parameter.

Return values

This method has the following return values:

Name	Description	Type
servers	List of NTP servers.	string array

Name	Description	Type
broadcastclient	Indicates whether or not the nodes in the cluster are listening for broadcast NTP messages. Possible values: <ul style="list-style-type: none"> true false 	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetNtpInfo",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "broadcastclient" : false,
    "servers" : [ "us.pool.ntp.org" ]
  }
}
```

GetNvramInfo

You can use the `GetNvramInfo` method to get information from each node about the NVRAM card.

Parameter

This method has the following input parameter:

Name	Description	Type	Default Value	Required
force	The force parameter must be included on this method to successfully run on all nodes in the cluster.	boolean	None	Yes

Return value

This method has the following return value:

Name	Description	Type
nvramInfo	Arrays of events and errors detected on the NVRAM card.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetNvramInfo",
  "params": {
    "force": true
  },
  "id" : 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

Related references

[GetNvramInfo](#) on page 510

GetRemoteLoggingHosts

You can use the `GetRemoteLoggingHosts` method to get the current list of log servers.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
remoteHosts	List of IP address and port information about hosts configured to receive forwarded logging information.	loggingServer array

Request example

Requests for this method are similar to the following example:

```
{
  "id": 3386609,
  "method": "GetRemoteLoggingHosts",
  "params": {}
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 3386609,
  "result": {
    "remoteHosts": [
      {
        "host": "172.16.1.20",
```

```

        "port": 10514
      },
      {
        "host": "172.16.1.25"
      }
    ]
  }
}

```

Related references

[SetRemoteLoggingHosts](#) on page 305

GetSnmpACL

You can use the `GetSnmpACL` method to get the current SNMP access permissions on the cluster nodes.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
networks	List of networks and what type of access they have to the SNMP servers running on the cluster nodes. This value is present if SNMP v3 is disabled.	network array
usmUsers	List of users and the type of access they have to the SNMP servers running on the cluster nodes. This value is present if SNMP v3 is enabled.	usmUser array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetSnmpACL",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {
    "usmUsers" : [
      {
        "name": "jdoe",
        "access": "rouser",
        "secLevel": "priv",
        "password": "mypassword",

```

```

    "passphrase": "mypassphrase",
  }
}
}

```

GetSnmplInfo

You can use the `GetSnmplInfo` method to get the current simple network management protocol (SNMP) configuration information.

Note: `GetSnmplInfo` is deprecated for versions later than Element version 8.0. The [GetSnmplState](#) and [SetSnmplACL](#) methods replace the `GetSnmplInfo` method.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
networks	List of networks and access types enabled for SNMP. Note: <code>networks</code> is only displayed if SNMP v3 is disabled.	network
enabled	Indicates if the nodes in the cluster are configured for SNMP. Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean
snmpV3Enabled	If the node in the cluster is configured for SNMP v3. Possible values: <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean
usmUsers	If SNMP v3 is enabled, a list of user access parameters for SNMP is returned from the cluster. This is returned instead of the <code>networks</code> parameter.	usmUser

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetSnmplInfo",
  "params": {},
}

```

```

    "id" : 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {
    "enabled" : true,
    "networks" : [
      {
        "access" : "rosys",
        "cidr" : 0,
        "community" : "public",
        "network" : "localhost"
      }
    ]
  }
}

```

Related references

[GetSnmpState](#) on page 292

[SetSnmpACL](#) on page 306

GetSnmpState

You can use the `GetSnmpState` method to get the current state of the SNMP feature.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
enabled	Possible values: <ul style="list-style-type: none"> • true • false Default value is false. Returns <code>true</code> if the nodes in the cluster are configured for SNMP.	boolean
snmpV3Enabled	Possible values: <ul style="list-style-type: none"> • true • false Default value is false. Returns <code>true</code> if the nodes in the cluster are configured for SNMP v3.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetSnmpState",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "enabled": true,
    "snmpV3Enabled": false
  }
}
```

Related references

[SetSnmpACL](#) on page 306

GetSnmpTrapInfo

You can use the `GetSnmpTrapInfo` method to get current SNMP trap configuration information.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
trapRecipients	List of hosts that are to receive the traps generated by the cluster.	snmpTrapRecipient array
clusterFaultTrapsEnabled	The value <code>true</code> indicates that a <code>solidFireClusterFaultNotification</code> is configured to be sent to the list of trap recipients when a cluster fault is logged.	boolean
clusterFaultResolvedTrapsEnabled	The value <code>true</code> indicates that a <code>solidFireClusterFaultResolvedNotification</code> is configured to be sent to the list of trap recipients when a cluster fault is resolved.	boolean
clusterEventTrapsEnabled	The value <code>true</code> indicates that a <code>solidFireClusterEventNotification</code> is configured to be sent to the list of trap recipients when a cluster event is logged.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetSnmpTrapInfo"
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "clusterEventTrapsEnabled": true,
    "clusterFaultResolvedTrapsEnabled": true,
    "clusterFaultTrapsEnabled": true,
    "trapRecipients": [
      {
        "community": "public",
        "host": "192.168.151.60",
        "port": 162
      },
      {
        "community": "solidfireAlerts",
        "host": "NetworkMonitor",
        "port": 162
      },
      {
        "community": "wakeup",
        "host": "PhoneHomeAlerter",
        "port": 1008
      }
    ]
  }
}
```

GetNodeSSLCertificate

You can use the `GetNodeSSLCertificate` method to retrieve the SSL certificate that is currently active on the management node.

Note: You must call this method against the management node. For example:

```
https://<management node IP>:442/json-rpc/10.0
```

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
certificate	The full PEM-encoded text of the certificate.	string


```

    }
  }
}

```

GetSSLCertificate

You can use the `GetSSLCertificate` method to retrieve the SSL certificate that is currently active on the storage nodes of the cluster.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
certificate	The full PEM-encoded text of the certificate.	string
details	The decoded information of the certificate.	JSON object

Request example

Requests for this method are similar to the following example:

```

{
  "method" : "GetSSLCertificate",
  "params" : {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "certificate": "-----BEGIN CERTIFICATE-----
\nMIIEdzCCA1+gAwIBAgIJAMwbIhWY43/zMA0GCSqGSIb3DQEBBQUAMIGDMQswCQYD
\nVQQGEwJVUzELMAkGA1UECBMCTlYxFTATBgNVBACUFDZlZ2FzLCBCYXWJ5ITEhMB8G
\nA1UEChMYV2hhdBGkqYXW5ZGluIFZlZ2FzLi4uMS0wKwYJKoZIhvcNAQkBFh53\ngaGF0a
\nGFwcGVuc0B2ZWdhc3N0YXlzaW4udmVnYXNwHhcNMTCwMzA4MjI1MDI2WWhcN
\nMjcwMzA4MjI1MDI2WjCBGzELMAkGA1UEBhMCVVMxMzA4MjI1MDI2WWhcN
\nVQQQHFAXWZWhdchcywGQmFieSExITAFBgNVBAoTGFdoYXQgSGFwcGVucyBpbWZWhd
\nncy4uLjEtMCsGCsGSIb3DQEJARYed2hhdBGhHcHBlbnNAdmVnYXNzdGF5c2luLnZl
\nZ2FzMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAE8U+28fnLKQNWEMMR
\nn6akeDKuehSpS79odLGigI18qlCV/AUY5ZLjqsTjBvTJVRv44yoCTgNrx36U7FHP4\nt6P/
\nSi0aYr4ovxl5wDpEM3Qyy5JPB7JelOB6AD7fmiTweP20HRYpZvY+Uz7LYEFC
\nnmrgpGZQF3i0SiCBHtLKE5186JVT6j5dg6yJUGOQ352ylc9HXHcn61b/jy10DmVNU
\nnZ0caQwAmIS3Jmoyx+zj/Ya4WKq+2SqTAX7bX0F3wHHfXnZlHnM8fET5N/9A+K6lS
\nn7dg9cyXu4afXcgKy14JiNBvqbBjhGJtE76yAy6rTHu0xM3jjdkcb9Y8miNzx+AC\nng
\n+itawIDAQAB04HrMIHOMB0GA1UdDgQWBRRvBRPno5S34zGRhrnDJyTsdnEbTcb
\nnuAYDVR0jBIGwMIGtgBRvvBRPno5S34zGRhrnDJyTsdnEbaGBiasBhjCBgzELMAkG
\nA1UEBhMCVVMxMzA4MjI1MDI2WWhcN
\nBgNVBAoTGFdoYXQgSGFwcGVucyBpbWZWhdchcy4uLjEtMCsGCsGSIb3DQEJARYe
\nnd2hhdBGhHcHBlbnNAdmVnYXNzdGF5c2luLnZlZ2FzggkAzBsiFzjjf/MwDAYDVR0T
\nnBAUwAwEB/zANBgkqhkiG9w0BAQUFAAOCAQEAhVND5s7lmQPECwVLFiE/ndtIbnpe
\nnMqo5geQHCHnNlu5RV9j8aYHp9kW2qCDJ5vueZtZ2L1tC4D7Jyfs3714rRolFpX6N
\nniebEgAaE5eWvB6zgiAcMRIKqu3DmJ7y3CFGk9dHOLQ+WYnoO/eIMy0coT26JB15H
\nnDEwvd1+DwKxnlcxlvERv51g1gua6AE3tBrlov8q1G4zMJboo3YEwMFwxLkxAFXR

```



```

\nHgMoPDym099kvc84B1k7HkDGHpr4tLfVelDJy2zCWIQ5ddbVpyPW2xuE4p4BGx2B
\n7ASOjG+DzUxzwaUI6Jzvs3Xq5Jx8ZAjJDg10QoQDWNDoTeRBsz80nwiouA==\n-----END
CERTIFICATE-----\n",
  "details": {
    "issuer": "/C=US/ST=NV/L=Denver/O=NetApp/",
    emailAddress="test@netapptest.org",
    "modulus":
      "F14FB6F1F9CB290356116311E9A91E0CAB9E852A52EFDA1D2C68A0235F2A94257F014639
      64B8EAB138C1BD325546FE38CA809380DAF1DFA53B1473F8B7A3FF4A2D1A62BE28BF1979C
      03A44337432CB924F07B25E94E07A003EDF9A24F078FDB41D162966F63E533ECB6041429A
      B829199405DE239221C047B4B284E75F3A2554FA8F9760EB28D41903B7E76CA573D1D71DC
      9FA95BFE3CA5D0399535467471A430026212DC99A8CB1FB38FF61AE162AAFB64AA4C05FB6
      D7D05DF01C77D79D99479CCF1F113E4DFFD03E2BA952EDD83D7325EEE1A7D77202B2D7826
      2341BEA6C18E1809B44EFAC80CBAAD31EED313378E376471BF58F2688DCF117E002ABE8AD
      6B",
    "notAfter": "2027-03-06T22:50:26Z",
    "notBefore": "2017-03-08T22:50:26Z",
    "serial": "CC1B221598E37FF3",
    "sha1Fingerprint": "1D:70:7A:6F:18:8A:CD:29:50:C7:95:B1:DD:
    5E:63:21:F4:FA:6E:21",
    "subject": "/C=US/ST=NV/L=Denver/O=NetApp/
    emailAddress=test@netapptest.org"
  }
}

```

ListProtectionDomainLevels

You can use the `ListProtectionDomainLevels` method to list the tolerance and resiliency levels of the storage cluster. Tolerance levels indicate the cluster's ability to continue reading and writing data in the event of a failure, and resiliency levels indicate the storage cluster's ability to automatically heal itself from one or more failures.

Parameter

This method has no input parameter.

Return values

This method has the following return values:

Name	Description	Type
protectionDomainLevels	A list of the different protection domain levels, where each supplies the storage cluster's tolerance and resiliency information.	<i>protectionDomainLevel</i>

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListProtectionDomainLevels",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "protectionDomainLevels": [
      {
        "protectionDomainType": "node",
        "resiliency": {
          "protectionSchemeResiliencies": [
            {
              "protectionScheme": "doubleHelix",
              "sustainableFailuresForBlockData": 0,
              "sustainableFailuresForMetadata": 1
            }
          ],
          "singleFailureThresholdBytesForBlockData": 0,
          "sustainableFailuresForEnsemble": 1
        },
        "tolerance": {
          "protectionSchemeTolerances": [
            {
              "protectionScheme": "doubleHelix",
              "sustainableFailuresForBlockData": 0,
              "sustainableFailuresForMetadata": 1
            }
          ],
          "sustainableFailuresForEnsemble": 1
        }
      },
      {
        "protectionDomainType": "chassis",
        "resiliency": {
          "protectionSchemeResiliencies": [
            {
              "protectionScheme": "doubleHelix",
              "sustainableFailuresForBlockData": 0,
              "sustainableFailuresForMetadata": 1
            }
          ],
          "singleFailureThresholdBytesForBlockData": 0,
          "sustainableFailuresForEnsemble": 1
        },
        "tolerance": {
          "protectionSchemeTolerances": [
            {
              "protectionScheme": "doubleHelix",
              "sustainableFailuresForBlockData": 0,
              "sustainableFailuresForMetadata": 1
            }
          ],
          "sustainableFailuresForEnsemble": 1
        }
      }
    ]
  }
}
```

RemoveNodeSSLCertificate

You can use the `RemoveNodeSSLCertificate` method to remove the user SSL certificate and private key for the management node. After the certificate and private key are removed, the management node is configured to use the default certificate and private key.

Note: You must call this method against the management node. For example:

```
https://<management node IP>:442/json-rpc/10.0
```

Parameters

This method has no input parameters.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method" : "RemoveNodeSSLCertificate",
  "params" : {},
  "id" : 3
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 3,
  "result" : {}
}
```

RemoveSSLCertificate

You can use the `RemoveSSLCertificate` method to remove the user SSL certificate and private key for the storage nodes in the cluster. After the certificate and private key are removed, the storage nodes are configured to use the default certificate and private key.

Parameters

This method has no input parameters.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method" : "RemoveSSLCertificate",
  "params" : {},
  "id" : 3
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 3,
  "result" : {}
}
```

ResetNetworkConfig

You can use the `ResetNetworkConfig` method to help resolve network configuration issues for an individual node. This method resets an individual node's network configuration to the factory default settings.

Parameters

This method has no input parameters.

Return value

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ResetNetworkConfig",
  "params": {},
  "id" : 1
}
```

Response example

This method does not return a response.

SetClusterStructure

You can use the `SetClusterStructure` method to restore the storage cluster configuration information from a backup. When you call the method, you pass the `clusterStructure` object containing the configuration information you want to restore as the `params` parameter.

Parameter

This method has the following input parameter:

Name	Description	Type
params	A JSON object containing the current storage cluster configuration information.	<i>clusterStructure</i>

Return values

This method has the following return values:

Name	Description	Type
result	Asynchronous result handle.	asyncHandle

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetClusterStructure",
  "params": <insert clusterStructure object here>,
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result" : {
    "asyncHandle": 1
  }
}
```

SetLldpConfig

You can use the `SetLldpConfig` method to configure the Link Layer Discovery Protocol (LLDP) settings for a storage cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
enableOtherProtocols	Enable automatic use of other discovery protocols - CDP, FDP, EDP, and SONMP.	boolean	true	No
enableMed	Enable Media Endpoint Discovery (LLDP-MED).	boolean	false	No
enableLldp	Enable or disable LLDP.	boolean	true	No

Return values

This method has the following return value:

Name	Description	Type
lldpConfig	Information about the current storage cluster LLDP configuration, including newly changed settings.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "id": 3920,
  "method": "SetLldpConfig",
  "params": {
    "lldpConfig": {
      "enableMed": true
    }
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 3920,
  "result": {
    "lldpConfig": {
      "enableLldp": true,
      "enableMed": true,
      "enableOtherProtocols": true
    }
  }
}
```

SetNodeSSLCertificate

You can use the `SetNodeSSLCertificate` method to set a user SSL certificate and private key for the management node.

Note: You must call this method against the management node. For example:

```
https://<management node IP>:442/json-rpc/10.0
```

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
certificate	The PEM-encoded text version of the certificate.	string	None	Yes


```

\nDEwvdl+DwkxnSlcxlvERv51g1gua6AE3tBrlov8q1G4zMJboo3YEwMFwxLkxAFXR
\nHgMoPDym099kvc84B1k7HkDGHpr4tLfVelDJy2zCWIQ5ddbVpyPW2xuE4p4BGx2B
\n7ASOjG+DzUxzwaUI6Jzvs3Xq5Jx8ZAJJDg10QoQDWNDOTeRBSz80nwiouA==\n-----END
CERTIFICATE-----\n"
    },
    "id" : 2
  }
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 2,
  "result" : {}
}

```

SetNtpInfo

You can use the `SetNtpInfo` method to configure NTP on cluster nodes. The values you set with this interface apply to all nodes in the cluster. If an NTP broadcast server periodically broadcasts time information on your network, you can optionally configure nodes as broadcast clients.

Note: Ensure that you use NTP servers that are internal to your network, rather than the installation defaults.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
servers	List of NTP servers to add to each node NTP configuration.	string array	None	Yes
broadcastclient	Enables every node in the cluster as a broadcast client.	boolean	false	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "SetNtpInfo",
  "params": {
    "servers" : [
      "ntpserver1.example.org",
      "ntpserver2.example.org",
      "ntpserver3.example.org"
    ],
    "broadcastclient" : false
  }
}

```



```

    "id" : 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {}
}

```

SetRemoteLoggingHosts

You can use the `SetRemoteLoggingHosts` method to configure remote logging from the nodes in the storage cluster to a centralized log server or servers. Remote logging is performed over TCP using the default port 514. This API does not add to the existing logging hosts. Rather, it replaces what currently exists with new values specified by this API method. You can use `GetRemoteLoggingHosts` to determine what the current logging hosts are and then use `SetRemoteLoggingHosts` to set the desired list of current and new logging hosts.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>remoteHosts</code>	List of hosts that are log message recipients.	<i>loggingServer</i> array	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "id": 1,
  "method": "SetRemoteLoggingHosts",
  "params": {
    "remoteHosts": [
      {
        "host": "172.16.1.20",
        "port": 10514
      },
      {
        "host": "172.16.1.25"
      }
    ]
  }
}

```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

Related references

[GetRemoteLoggingHosts](#) on page 289

SetSnmpACL

You can use the `SetSnmpACL` method to configure SNMP access permissions on the cluster nodes. The values you set with this interface apply to all nodes in the cluster, and the values that are passed replace all values set in any previous call to `SetSnmpACL`. Also note that the values set with this interface replace all `network` or `usmUsers` values set with the `SetSnmpInfo`.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>networks</code>	List of networks and what type of access they have to the SNMP servers running on the cluster nodes. See <code>SNMP network</code> object for possible <code>networks</code> values. This parameter is required if SNMP v3 is disabled.	network	None	No
<code>usmUsers</code>	List of users and the type of access they have to the SNMP servers running on the cluster nodes. This parameter is required if SNMP v3 is enabled.	usmUser	None	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetSnmpACL",
  "params": {
    "usmUsers" : [
      {
        "name": "jdoe",
        "access": "rouser",
        "secLevel": "priv",

```

```

        "password": "mypassword",
        "passphrase": "mypassphrase",
      }
    ],
    "id" : 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {}
}

```

Related references

[SetSnmplibInfo](#) on page 307

SetSnmplibInfo

You can use the `SetSnmplibInfo` method to configure SNMP version 2 and version 3 on cluster nodes. The values you set with this interface apply to all nodes in the cluster, and the values that are passed replace all values set in any previous call to `SetSnmplibInfo`.

Note: `SetSnmplibInfo` is deprecated for Element versions 6.0 and later. Use the [EnableSnmplib](#) and [SetSnmplibACL](#) methods instead.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
networks	List of networks and what type of access they have to the SNMP servers running on the cluster nodes. See the SNMP network object for possible values. This parameter is required for SNMP v2 only.	network array	None	No
enabled	If set to <code>true</code> , SNMP is enabled on each node in the cluster.	boolean	false	No
snmpV3Enabled	If set to <code>true</code> , SNMP v3 is enabled on each node in the cluster.	boolean	false	No

Name	Description	Type	Default value	Required
usmUsers	If SNMP v3 is enabled, this value must be passed in place of the networks parameter. This parameter is required for SNMP v3 only.	<i>usmUser</i>	None	No

Return values

This method has no return values.

Request example with SNMP v3 enabled

Requests for this method are similar to the following example:

```
{
  "method": "SetSnmpInfo",
  "params": {
    "enabled": true,
    "snmpV3Enabled": true,
    "usmUsers": [
      {
        "name": "user1",
        "access": "rouser",
        "secLevel": "auth",
        "password": "namex1",
        "passphrase": "yourpassphrase"
      }
    ]
  },
  "id": 1
}
```

Request example with SNMP v2 enabled

Requests for this method are similar to the following example:

```
{
  "method": "SetSnmpInfo",
  "params": {
    "enabled": true,
    "snmpV3Enabled": false,
    "networks": [
      {
        "community": "public",
        "access": "ro",
        "network": "localhost",
      }
    ]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1
}
```

```

    "result" : {
    }
  }

```

SetSnmpTrapInfo

You can use the `SetSnmpTrapInfo` method to enable and disable the generation of cluster SNMP notifications (traps) and to specify the set of hosts that receive the notifications. The values you pass with each `SetSnmpTrapInfo` method call replace all values set in any previous call.

Parameters

This method has the following input parameters:

Name	Description	Type
trapRecipients	List of hosts that are to receive the traps generated by the storage cluster. At least one object is required if any one of the trap types is enabled. This parameter is required only if any boolean parameters are set to <code>true</code> . (No default value. Not required.)	snmpTrapRecipient array
clusterFaultTrapsEnabled	If set to <code>true</code> , a corresponding cluster fault notification is sent to the configured list of trap recipients when a cluster fault is logged. (Default value: <code>false</code> . Not required.)	boolean
clusterFaultResolvedTraps Enabled	If set to <code>true</code> , a corresponding cluster fault resolved notification is sent to the configured list of trap recipients when a cluster fault is resolved. (Default value: <code>false</code> . Not required.)	boolean
clusterEventTrapsEnabled	If set to <code>true</code> , a corresponding cluster event notification is sent to the configured list of trap recipients when a cluster event is logged. (Default value: <code>false</code> . Not required.)	boolean

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "SetSnmpTrapInfo",
  "params": {
    "clusterFaultTrapsEnabled": true,
    "clusterFaultResolvedTrapsEnabled": true,

```

```

    "clusterEventTrapsEnabled":true,
    "trapRecipients":[
      {
        "host":"192.30.0.10",
        "port":162,
        "community":"public"
      }
    ],
    "id":1
  }
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {}
}

```

SetSSLCertificate

You can use the `SetSSLCertificate` method to set a user SSL certificate and private key for the storage nodes in the cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
certificate	The PEM-encoded text version of the certificate.	string	None	Yes
privateKey	The PEM-encoded text version of the private key.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "method" : "SetSSLCertificate",
  "params" : {
    "privateKey": "-----BEGIN RSA PRIVATE KEY-----
\nMIIEowIBAAKCAQEA8U+28fnLKQNWEMR6akeDKuehSpS79odLGigI18qlCV/
AUY5\nZLjqsTjBvTJVRv44yoCTgNrx36U7FHP4t6P/Si0aYr4ovxl5wDpEM3Qyy5JPB7Je
\nlOB6AD7fmiTweP20HRYpZvY+Uz7LYEFCmrGpGZQF3iOSIcBHtLKE5186JVT6j5dg
\n6yjUGQO352ylc9HXHcn6lb/jy10DmVNUZ0caQwAmIS3Jmoyx+zj/Ya4WKq+2SqTA
\nX7bX0F3wHHfXnZ1HnM8fET5N/9A+K6lS7dg9cyXu4afXcgKy14JiNBvqbBjhgJtE
\n76yAy6rThu0xM3jjdkcb9Y8miNzxF+ACq+itawIDAQABaoIBAH1jlIZr6/sltqVW
\nO0qVC/49dyNu+KWVSq92ti9rFe7hBPueh9gklh78hp9QlitLkir3YK4GFsTFUMux

```

```

\n7z1NRCxA/4LrmLSkAjW2kRXDfVl2bwZq0ua9NefGw9208D20ZvbuOxk7Put2p6se
\nfgNzSjf2SI5DIX3UMe5dDN5FByu52CJ9mI4U16ngbWln2wc4nsxJg0aAEkzB7wnq\nt
+Am5/VuLI6rGiG6oHEW0oGSuHllesIyXXa2hqkU+1+iF2iGRMTiXac4C8d11NU
\nWGIRCXfJAmsAQ+hQm7pmtsKdEqumj/PIoGXf0BoFVEWaiJIMEgnfuLZp8IelJQXn
\nSFJbk2ECgYEA+d5ooU4thZXylWHUZqomaxyzOruA1T53UeH69HiFTrLjvfwuaiqj
\nlHzPlhms6hxexwzldzApgog/NOM+2bAc0rn0dqvT4doejtLDZKRqrNCf/cuN2QX
\njaCJC1CWau3sEHCckLOhWeY4HaPSoWq0GKLmKkKDCb4nWUYg3gSWQkCgYEA9zuN
\nHW8GPS+yjixeKXmkK00x/vvxzR+J5HH5znaIHss48THyhzXpLr+v30Hy2h0yAlBS
\nny5Ja6wsomb0mVe4NxVtVawg2E9vVvTa1UC+TNmFBBuLRPfjcnjDerrSuQ51YY+M
\nC9MJtXGfhp//G0bzwsRzZxOBsUJb15tpPaZIs9MCgYAJricpkKjM0x1Z1jdvXsoss
\nPilnbho4qLngrzuUuxKXEPEnzBxUOqCpwQgdzZLYYw788TCVVIVXLEYem2s07dDA\ndTo
+WrzQNkvC6IqgtXhIRgqegIoG1VbgQsbsYmDhdaQ+os4+AoeQXw3vgAhJ/qNJ
\njq4Ttw3ylt7FYkRH26ACWQKBgQC74Zmf4JuRLAo5WSZFxpemMvtnlvdtuqUH4kXA
\nzPssy6t+QELa1fFbAXkZ5Pg1ITK752aiaX6KQNG6qRsA3VS1J6drD9/2AofOQU17\n
+jOkGzmmoXf49Zj3iSakwg0ZbQNGXNxEsCAUr0BYAobPp9/fB4PbtUs99fvtocFr
\njS562QKBgCb+JMdp5q7jpUuspj0obd/ZS+MsomE+gFAMBj71KFQ7KuNezNFO+ZE
\n3rnR8AqAm4VMzqRahs2PWNe2Hl4J4hKu96qNpNHbsW1njXdAL9P7oqQIrhGLVdhX
\nInDXvTgXMDMoet4BKnfteLrXFKHgGqXJocZq4JWzGSIHNgvkrH60\n-----END RSA
PRIVATE KEY-----\n",
  "certificate": "-----BEGIN CERTIFICATE-----
\nMIIEEdzCCA1+gAwIBAgIJAMwbIhWY43/zMAOGCSqGSIb3DQEBBQUAMIGDMQswCQYD
\nVQQGEwJVVzELMAkGA1UECBMCTlYxFTATBgNVBACUUDFZlZ2FzLCBCYUWJ5ITEhMB8G
\nA1UEChMYV2hhdBhCBYXZBwZ5ZlGluIFZlZ2FzLi4uMS0wKwYJKoZIhvcNAQkBFh53naGF0a
\nGFwGcGVuO2B2ZWdhc3N0YXlzaW4udmVnYXNwHhcNMjcwMzA4MjI1MDI2WWhcNAQk
\nBmJcwMzA2MjI1MDI2WjCBGzELMAkGA1UEBhMCVVMxMzA2BgNVBAGTAk5WMRUwEwYD
\nVQQHFAXWZWhcywQmFieSExITAFBgNVBAoTGFdoYXQSGFwGcGVucyBpbWZkdWdh
\nncy4uLjEtMCSGCSqGSIb3DQEJARYed2hhdBhCBHlbnNAdmVnYXNzdGF5c2luLnZl
\nZ2F2ZmI1BjIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAAU+28fnLKQNWEMMR
\nn6akeDKuehSpS79odLGigI18q1CV/AUY5ZLjqsTjBvTJVRv44yoCTgNrx36U7FHP4\nt6P/
\nSi0aYr4ovxl5wDpEM3Qyy5JPB7JelOB6AD7fmiTweP20HRYpZvY+Uz7LYEFC
\nnmrgpGZQF3iOSIcBHTLKE5186JVT6j5dg6yJUGQO352ylc9HXHcn61b/jyl0DmVNU
\nz0caQwAmIS3Jmoyx+zj/Ya4WKq+2SqtAX7bX0F3wHHfXnZlHnM8fET5N/9A+K61S
\nn7dg9cyXu4afXcgKy14JiNBvqbBjhgJtE76yAy6rTHu0xM3jJdkcb9Y8miNzx+AC\nnq
+itawIDAQAB04HrMIHoMB0GA1UdDgQWBBrvBRPno5S34zGRhrnDJyTsdnEbTCB
\nnuAYDVR0jBIGwMIGtgBrvBRPno5S34zGRhrnDJyTsdnEbaGBiasBhjCBGzELMAkG
\nA1UEBhMCVVMxMzA2BgNVBAGTAk5WMRUwEwYDQHFAXWZWhcywQmFieSExITAF
\nBgNVBAoTGFdoYXQSGFwGcGVucyBpbWZkdWdhcy4uLjEtMCSGCSqGSIb3DQEJARYe
\nnd2hhdBhCBHlbnNAdmVnYXNzdGF5c2luLnZlZ2FzZGgkAzBsiFZjJf/MwDAYDVR0T
\nnBAUwAwEB/zANBgkqhkiG9w0BAQUFAAOCAQEAAhVND5s7lmQPECwVLFiE/ndtIbnpe
\nnMqo5geQHCHnNlu5RV9j8aYHp9kW2qCDJ5vueZtZ2L1tC4D7Jyfs3714rRolfpX6N
\nniebEgAaE5eWvB6zgiAcMRiKqu3DmJ7y3CFGk9dH0lQ+WYno0/eIMy0coT26JB15H
\nnDEwvdl+DwkxnSlcxlvERv51glgua6AE3tBrlov8q1G4zMJboo3YEWfWxLkxAFXR
\nnHgMoPDym099kvc84B1k7HkDGHpr4tLfVelDJy2zCWIQ5ddbVpyPW2xuE4p4BGx2B
\nn7ASOjG+DzUxzwaUI6Jzvs3Xq5Jx8ZAJJDgl0QoQDWNDoTeRBsz80nwiouA==\n-----END
CERTIFICATE-----\n"
},
  "id" : 2
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 2,
  "result" : {}
}

```

SnmpSendTestTraps

`SnmpSendTestTraps` enables you to test SNMP functionality for a cluster. This method instructs the cluster to send test SNMP traps to the currently configured SNMP manager.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
status	Status of the test.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SnmpSendTestTraps",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "status": "complete"
  }
}
```

TestAddressAvailability

You can use the `TestAddressAvailability` method to check to see if a certain IP address is in use on an interface within the storage cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
interface	The target network interface (such as eth0, Bond10G, etc).	string	None	Yes
address	The IP address to scan for on the target interface.	string	None	Yes

Name	Description	Type	Default value	Required
virtualNetworkTag	The target VLAN ID.	integer	None	No
timeout	The timeout in seconds for testing the target address.	integer	5	No

Return values

This method has the following return values:

Name	Description	Type
address	The IP address tested.	string
available	True if the requested IP address is in use, and false if it is not.	boolean

Request example

Requests for this method are similar to the following example:

```
{
  "method": "TestAddressAvailability",
  "params": {
    "interface": "Bond10G",
    "address": "10.0.0.1",
    "virtualNetworkTag": 1234
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "address": "10.0.0.1",
    "available": true
  }
}
```

Multitenant networking API methods

Multitenant networking in Element storage clusters allows traffic between multiple clients that are on separate logical networks to be connected to one Element storage cluster without layer 3 routing.

Connections to the storage cluster are segregated in the networking stack through the use of VLAN tagging.

Prerequisites for setting up a multitenant virtual network

- You must have identified the block of client network IP addresses to be assigned to the virtual networks on the storage nodes.
- You must have identified a client storage network IP (SVIP) address to be used as an endpoint for all storage traffic.

Virtual networking order of operations

1. Use the `AddVirtualNetwork` method to bulk provision the IP addresses you enter.
After you add a virtual network, the cluster automatically performs the following steps:
 - Each storage node creates a virtual network interface.
 - Each storage node is assigned a VLAN address that can be routed to using the virtual SVIP.
 - VLAN IP addresses persist on each node in the event of a node reboot.
2. When the virtual network interface and VLAN addresses have been assigned, you can assign client network traffic to the virtual SVIP.

Related concepts

[Virtual network naming conventions](#) on page 314

Virtual network naming conventions

NetApp Element storage systems use monotonically increasing numbers as unique identifiers for all objects in the system.

When you create a new volume, the new volumeID is an increment of exactly 1. This convention holds true with virtual networks in storage clusters running Element software. The first virtual network you create in an Element cluster has a `VirtualNetworkID` of 1. This ID is not the same thing as a VLAN tag number.

You can use `VirtualNetworkID` and the `VirtualNetworkTag` (VLAN tag) interchangeably where noted in the API methods.

AddVirtualNetwork

You can use the `AddVirtualNetwork` method to add a new virtual network to a cluster configuration.

When you add a virtual network, an interface for each node is created and each interface requires a virtual network IP address. The number of IP addresses you specify as a parameter for this API method must be equal to or greater than the number of nodes in the cluster. The system bulk

provisions virtual network addresses and assigns them to individual nodes automatically. You do not need to assign virtual network addresses to nodes manually.

Note: The `AddVirtualNetwork` method is used only to create a new virtual network. If you want to make changes to an existing virtual network, use the [ModifyVirtualNetwork](#) method.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
addressBlocks	Unique range of IP addresses to include in the virtual network. Required members for the object: <ul style="list-style-type: none"> <code>start</code>: The start of the IP address range. (string) <code>size</code>: The number of IP addresses to include in the block. (integer) 	JSON object array	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
gateway	The IP address of a gateway of the virtual network. This parameter is valid only if the <code>namespace</code> parameter is set to <code>true</code> .	string	None	No
name	A user-defined name for the new virtual network.	string	None	Yes
namespace	When set to <code>true</code> , enables the Routable Storage VLANs functionality by creating and configuring a namespace and the virtual network contained by it.	boolean	None	No

Name	Description	Type	Default value	Required
netmask	Unique network mask for the virtual network being created.	string	None	Yes
svip	Unique storage IP address for the virtual network being created.	string	None	Yes
virtualNetworkTag	A unique virtual network (VLAN) tag. Supported values are 1 through 4094.	integer	None	Yes

Note: Virtual network parameters must be unique to each virtual network when you set namespace to false.

Return value

This method has the following return value:

Name	Description	Type
virtualNetworkID	The virtual network ID of the new virtual network.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "AddVirtualNetwork",
  "params": {
    "virtualNetworkTag": 2010,
    "name": "network1",
    "addressBlocks": [
      { "start": "192.86.5.1", "size": 10 },
      { "start": "192.86.5.50", "size": 20 }
    ],
    "netmask": "255.255.192.0",
    "gateway": "10.0.1.254",
    "svip": "192.86.5.200",
    "attributes": {}
  },
  "namespace": true
},
{id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "virtualNetworkID": 5
  }
}
```

```
}
}
```

ModifyVirtualNetwork

You can use the `ModifyVirtualNetwork` method to change the attributes of an existing virtual network.

This method enables you to add or remove address blocks, change the netmask, or modify the name or description of the virtual network. You can also use it to enable or disable namespaces, as well as add or remove a gateway if namespaces are enabled on the virtual network.

Note: This method requires either the `virtualNetworkID` or the `virtualNetworkTag` as a parameter, but not both.

Caution: Enabling or disabling the Routable Storage VLANs functionality for an existing virtual network by changing the `namespace` parameter disrupts any traffic handled by the virtual network. It is best if you change the `namespace` parameter during a scheduled maintenance window.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>virtualNetworkID</code>	Unique identifier of the virtual network to modify. This is the virtual network ID assigned by the cluster.	integer	None	No
<code>virtualNetworkTag</code>	The network tag that identifies the virtual network to modify.	integer	None	No

Name	Description	Type	Default value	Required
addressBlocks	<p>The new address block to set for this virtual network. This might include new address blocks to add to the existing object or omit unused address blocks that need to be removed. Alternatively, you can extend or reduce the size of existing address blocks. You can only increase the size of the starting addressBlocks for a Virtual Network object; you can never decrease it. Required members for this object:</p> <ul style="list-style-type: none"> start: The start of the IP address range. (string) size: The number of IP addresses to include in the block. (integer) 	JSON object	None	No
gateway	The IP address of a gateway of the virtual network. This parameter is valid only if the namespace parameter is set to true.	string	None	No
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
name	The new name for the virtual network.	string	None	No
namespace	When set to true, enables the Routable Storage VLANs functionality by recreating the virtual network and configuring a namespace to contain it. When set to false, disables the VRF functionality for the virtual network. Changing this value disrupts traffic running through this virtual network.	boolean	None	No
netmask	New network mask for this virtual network.	string	None	No

Name	Description	Type	Default value	Required
svip	The storage virtual IP address for this virtual network. The SVIP for a virtual network cannot be changed. You must create a new virtual network to use a different SVIP address.	string	None	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyVirtualNetwork",
  "params": {
    "virtualNetworkID": 2,
    "name": "ESX-VLAN-3112",
    "addressBlocks": [
      {
        "start": "10.1.112.1",
        "size": 20
      },
      {
        "start": "10.1.112.100",
        "size": 20
      }
    ],
    "netmask": "255.255.255.0",
    "gateway": "10.0.1.254",
    "svip": "10.1.112.200",
    "attributes": {}
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
  }
}
```

ListVirtualNetworks

You can use the `ListVirtualNetworks` method to list all configured virtual networks for the cluster.

You can use this method to verify the virtual network settings in the cluster. There are no required parameters for this method. However, to filter the results, you can pass one or more `virtualNetworkID` or `virtualNetworkTag` values.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
virtualNetworkID	Network ID to filter the list for a single virtual network.	integer	None	No
virtualNetworkTag	Network tag to filter the list for a single virtual network.	integer	None	No
virtualNetworkIDs	Network IDs to include in the list.	integer array	None	No
virtualNetworkTags	Network tag to include in the list.	integer array	None	No

Return value

This method has the following return value:

Name	Description	Type
virtualNetworks	Object containing virtual network IP addresses.	virtualNetwork

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVirtualNetworks",
  "params": {
    "virtualNetworkIDs": [5,6]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "virtualNetworks": [
      {
        "addressBlocks": [
          {
            "available": "11000000",
            "size": 8,
            "start": "10.26.250.207"
          }
        ]
      }
    ],
    "attributes": null,
    "gateway": "10.26.250.254",
    "name": "2250",
    "namespace": false,
  }
}
```



```
{
    "netmask": "255.255.255.0",
    "svip": "10.26.250.200",
    "virtualNetworkID": 2250
},
{
    "addressBlocks": [
        {
            "available": "11000000",
            "size": 8,
            "start": "10.26.241.207"
        }
    ],
    "attributes": null,
    "gateway": "10.26.241.254",
    "name": "2241",
    "namespace": false,
    "netmask": "255.255.255.0",
    "svip": "10.26.241.200",
    "virtualNetworkID": 2241
},
{
    "addressBlocks": [
        {
            "available": "11000000",
            "size": 8,
            "start": "10.26.240.207"
        }
    ],
    "attributes": null,
    "gateway": "10.26.240.254",
    "name": "2240",
    "namespace": false,
    "netmask": "255.255.255.0",
    "svip": "10.26.240.200",
    "virtualNetworkID": 2240
},
{
}
]
```

RemoveVirtualNetwork

You can use the `RemoveVirtualNetwork` method to remove a previously added virtual network.

Note: This method requires either the `virtualNetworkID` or the `virtualNetworkTag` as a parameter, but not both.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
virtualNetworkID	Network ID that identifies the virtual network to remove.	integer	None	Yes
virtualNetworkTag	Network tag that identifies the virtual network to remove.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveVirtualNetwork",
  "params": {
    "virtualNetworkID": 5
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

Volume API methods

Element software volume API methods enable you to manage volumes that reside on a storage node. You can create, modify, clone, and delete volumes with these methods. You can also use volume API methods to gather and display data measurements for a volume.

AddInitiatorsToVolumeAccessGroup

You can use the `AddInitiatorsToVolumeAccessGroup` method to add initiators to a specified volume access group.

The accepted format of an initiator IQN is `iqn.yyyy-mm`, where `y` and `m` are digits, followed by text which must only contain digits, lower-case alphabetic characters, a period (`.`), colon (`:`) or dash (`-`). See the following example:

```
iqn.2010-01.com.solidfire:17oi.solidfire-0.1
```

The accepted format of a Fibre Channel initiator WWPN is `Aa:bB:CC:dd:11:22:33:44`, or `AabBCCdd11223344`. See the following example:

```
21:00:00:0e:1e:11:f1:81
```

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>initiators</code>	<p>List of initiator IDs or names (IQNs and WWPNs) to include in the volume access group. If you pass a list of initiator names, the initiators are created if they do not already exist.</p> <p>If you pass a list of initiator IDs, the method returns an error if any of the initiators does not already exist.</p> <p>Passing initiator names is deprecated; you should use initiator IDs whenever possible.</p>	integer array or string array (deprecated)	<code>[]</code>	Yes

Name	Description	Type	Default value	Required
volumeAccessGroupID	The ID of the volume access group to add the initiator.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
volumeAccessGroup	An object containing information about the newly modified volume access group.	<i>volumeAccessGroup</i>

Request example

Requests for this method are similar to the following example:

```
{
  "id": 13171,
  "method": "AddInitiatorsToVolumeAccessGroup",
  "params": {
    "initiators": [116,117],
    "volumeAccessGroupID": 96
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 13171,
  "result": {
    "volumeAccessGroup": {
      "attributes": {},
      "deletedVolumes": [
        327
      ],
      "initiatorIDs": [
        116,
        117
      ],
      "initiators": [
        "iqn.1993-08.org.debian:01:181324777",
        "iqn.1993-08.org.debian:01:181324888"
      ],
      "name": "northbanktest",
      "volumeAccessGroupID": 96,
      "volumes": [
        346
      ]
    }
  }
}
```

AddVolumesToVolumeAccessGroup

You can use the `AddVolumesToVolumeAccessGroup` method to add volumes to a specified volume access group.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumes	List of volumeIDs to add to the volume access group.	integer array	None	Yes
volumeAccessGroupID	VolumeAccessGroupID of the volume access group to which volumes are added.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
volumeAccessGroup	An object containing information about the newly modified volume access group.	<i>volumeAccessGroup</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "AddVolumesToVolumeAccessGroup",
  "params": {
    "volumeAccessGroupID": 96,
    "volumes": [1,2]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeAccessGroup": {
      "attributes": {},
      "deletedVolumes": [
        346
      ],
      "initiatorIDs": [
        116,
        117
      ]
    }
  }
}
```

```

    "initiators": [
      "iqn.1993-08.org.debian:01:181324777",
      "iqn.1993-08.org.debian:01:181324888"
    ],
    "name": "northbanktest",
    "volumeAccessGroupID": 96,
    "volumes": [
      1,
      2
    ]
  }
}

```

CancelClone

You can use the `CancelClone` method to stop an ongoing volume clone or volume copy process. When you cancel a group clone operation, the system completes and removes the operation's associated `asyncHandle`.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>cloneID</code>	The cloneID for the ongoing clone process.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "CancelClone",
  "params": {
    "cloneID" : 5,
  },
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {}
}

```

CancelGroupClone

You can use the `CancelGroupClone` method to stop an ongoing clone process occurring on a group of volumes. When you cancel a group clone operation, the system completes and removes the operation's associated `asyncHandle`.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>groupCloneID</code>	The cloneID for the ongoing clone process.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CancelGroupClone",
  "params": {
    "cloneID" : 5,
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

CloneMultipleVolumes

You can use the `CloneMultipleVolumes` method to create a clone of a group of specified volumes. You can assign a consistent set of characteristics to a group of multiple volumes when they are cloned together.

Before using the `groupSnapshotID` parameter to clone the volumes in a group snapshot, you must first create the group snapshot using the [CreateGroupSnapshot](#) API method or the web UI. Using `groupSnapshotID` is optional when cloning multiple volumes.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
access	New default access method for the new volumes if not overridden by information passed in the volume's array.	string	None	No
enableSnapMirrorReplication	Determines whether the volume can be used for replication with SnapMirror endpoints. Possible values: <ul style="list-style-type: none"> • true • false 	boolean	false	No
groupSnapshotID	ID of the group snapshot to use as a basis for the clone.	integer	None	No
newAccountID	New account ID for the volumes if not overridden by information passed in the volumes array.	integer	None	No

Name	Description	Type	Default value	Required
volumes	<p>Collection of members that you specify for the new volumes. Members:</p> <ul style="list-style-type: none"> • <code>volumeID</code>: (Required) • <code>access</code>: (Optional) Can be one of <code>readOnly</code>, <code>readWrite</code>, <code>locked</code>, or <code>replicationTarget</code>. • <code>attributes</code>: (Optional) List of name-value pairs in JSON object format. • <code>name</code>: (Optional) New name for the clone. • <code>newAccountID</code>: (Optional) Account ID for the new volumes. • <code>newSize</code>: (Optional) Total size of the volume, in bytes. Size is rounded up to the nearest megabyte. <p>If optional members are not specified, the values are inherited from the source volumes.</p>	JSON object array	None	Yes (<code>volumeID</code>)

Return values

This method has the following return values:

Name	Description	Type
<code>asyncHandle</code>	A value returned from an asynchronous method call.	integer
<code>groupCloneID</code>	Unique ID of the new group clone.	integer
<code>members</code>	List of <code>volumeIDs</code> for the source and destination volume pairs.	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CloneMultipleVolumes",
  "params": {
```

```

    "volumes": [
      {
        "volumeID": 5
        "name": "foxhill",
        "access": "readOnly"
      },
      {
        "volumeID": 18
      },
      {
        "volumeID": 20
      }
    ]
  },
  "id": 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "asyncHandle": 12,
    "groupCloneID": 4,
    "members": [
      {
        "srcVolumeID": 5,
        "volumeID": 29
      },
      {
        "srcVolumeID": 18,
        "volumeID": 30
      },
      {
        "srcVolumeID": 20,
        "volumeID": 31
      }
    ]
  }
}

```

CloneVolume

You can use the `CloneVolume` method to create a copy of a volume. This method is asynchronous and might take a variable amount of time to complete.

The cloning process begins immediately when you make the `CloneVolume` request and is representative of the state of the volume when the API method is issued. You can use the [GetAsyncResult](#) method to determine when the cloning process is complete and the new volume is available for connections. You can use [ListSyncJobs](#) to see the progress of creating the clone. The initial attributes and quality of service settings for the volume are inherited from the volume being cloned. You can change these settings with [ModifyVolume](#).

Note: Cloned volumes do not inherit volume access group membership from the source volume.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
access	<p>Access allowed for the new volume. If a value is not specified, the access value does not change. Possible values:</p> <ul style="list-style-type: none"> readOnly: (Optional) Only read operations are allowed. readWrite: (Optional) Reads and writes are allowed. locked: (Optional) No reads or writes are allowed. If not specified, the access value of the volume being cloned is used. replicationTarget: (Optional) Identify a volume as the target volume for a paired set of volumes. If the volume is not paired, the access status is locked. 	string	None	No
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
enableSnapMirrorReplication	<p>Determines whether the volume can be used for replication with SnapMirror endpoints. Possible values:</p> <ul style="list-style-type: none"> true false 	boolean	false	No
name	Name of the new cloned volume; must be 1 to 64 characters in length.	string	None	Yes
newSize	New size of the volume, in bytes. Might be greater or less than the size of the volume being cloned. If not specified, the volume size is not changed. Size is rounded up to the nearest 1MB in size.	integer	None	No
snapshotID	ID of the snapshot that is used as the source of the clone. If no ID is provided, the current active volume is used.	integer	None	No
volumeID	VolumeID for the volume to be cloned.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
asyncHandle	The handle value used to obtain the operation result.	integer
cloneID	The cloneID for the newly cloned volume.	integer
curve	The QoS curve values applied to the clone.	JSON object
volume	An object containing information about the newly cloned volume.	volume
volumeID	VolumeID for the newly cloned volume.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CloneVolume",
  "params": {
    "volumeID": 5,
    "name": "mysqldata-snapshot1",
    "access": "readOnly"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "asyncHandle": 42,
    "cloneID": 37,
    "volume": {
      "access": "readOnly",
      "accountID": 1,
      "attributes": {},
      "blockSize": 4096,
      "createTime": "2016-03-31T22:26:03Z",
      "deleteTime": "",
      "enable512e": true,
      "iqn": "iqn.2010-01.com.solidfire:jyay.mysqldata-snapshot1.680",
      "name": "mysqldata-snapshot1",
      "purgeTime": "",
      "qos": {
        "burstIOPS": 100,
        "burstTime": 60,
        "curve": {
          "4096": 100,
          "8192": 160,
          "16384": 270,
          "32768": 500,
          "65536": 1000,
          "131072": 1950,
          "262144": 3900,
          "524288": 7600,
          "1048576": 15000
        }
      }
    }
  }
}
```

```

        "maxIOPS": 100,
        "minIOPS": 50
    },
    "scsiEUIDeviceID": "6a7961790000002a8f47acc0100000000",
    "scsiNAADeviceID": "6f47acc1000000006a7961790000002a8",
    "sliceCount": 0,
    "status": "init",
    "totalSize": 1000341504,
    "virtualVolumeID": null,
    "volumeAccessGroups": [],
    "volumeID": 680,
    "volumePairs": []
},
"volumeID": 680
}
}

```

Related references

[GetAsyncResult](#) on page 94

[ListSyncJobs](#) on page 366

[ModifyVolume](#) on page 387

CopyVolume

You can use the `CopyVolume` method to overwrite the data contents of an existing volume with the data contents of another volume (or snapshot). Attributes of the destination volume such as IQN, QoS settings, size, account, and volume access group membership are not changed. The destination volume must already exist and must be the same size as the source volume.

It is best if clients unmount the destination volume before the operation begins. If the destination volume is modified during the operation, the changes are lost. This operation can take a variable amount of time to complete. You can use the [GetAsyncResult](#) method to determine when the process has finished, and [ListSyncJobs](#) to see the progress of the copy.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
dstVolumeID	VolumeID of the volume to overwrite.	integer	None	Yes
volumeID	VolumeID of the volume to be read from.	integer	None	Yes
snapshotID	ID of the snapshot that is used as the source of the clone. If no ID is provided, the current active volume is used.	integer	None	No

Return values

This method has the following return values:

Name	Description	Type
asyncHandle	Handle value used to obtain the operation result.	integer
cloneID	CloneID for the newly cloned volume.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CopyVolume",
  "params": {
    "volumeID" : 3,
    "dstVolumeID" : 2
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "asyncHandle": 9,
    "cloneID": 5
  }
}
```

Related references

[GetAsyncResult](#) on page 94

[ListSyncJobs](#) on page 366

CreateQoSPolicy

You can use the `CreateQoSPolicy` method to create a `QoSPolicy` object that you can later apply to a volume upon creation or modification. A QoS policy has a unique ID, a name, and QoS settings.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
name	The name of the QoS policy; for example, gold, platinum, or silver.	string	None	Yes
qos	The QoS settings that this policy represents.	QoS	None	Yes

Return value

This method has the following return value:

Name	Description	Type
qosPolicy	The newly created QoSPolicy object.	<i>QoSPolicy</i>

Request example

Requests for this method are similar to the following example:

```
{
  "id": 68,
  "method": "CreateQoSPolicy",
  "params": {
    "name": "bronze",
    "qos": {
      "minIOPS": 50,
      "maxIOPS": 15000,
      "burstIOPS": 15000
    }
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 68,
  "result": {
    "qosPolicy": {
      "name": "bronze",
      "qos": {
        "burstIOPS": 15000,
        "burstTime": 60,
        "curve": {
          "4096": 100,
          "8192": 160,
          "16384": 270,
          "32768": 500,
          "65536": 1000,
          "131072": 1950,
          "262144": 3900,
          "524288": 7600,
          "1048576": 15000
        }
      },
      "maxIOPS": 15000,
      "minIOPS": 50
    },
    "qosPolicyID": 2,
    "volumeIDs": []
  }
}
```

CreateVolume

You can use the `CreateVolume` method to create a new, empty volume on the cluster. As soon as the volume creation is complete, the volume is available for connection via iSCSI.

Volumes created without specified QoS values use the default values. You can view default values for a volume by using the `GetDefaultQoS` method.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>accountID</code>	The ID of the account that owns this volume.	integer	None	Yes
<code>associateWithQoSPolicy</code>	Associate the volume with the specified QoS policy. Possible values: <ul style="list-style-type: none"> <code>true</code>: Associate the volume with the QoS policy specified in the <code>QoSPolicyID</code> parameter. <code>false</code>: Do not associate the volume with the QoS policy specified in the <code>QoSPolicyID</code> parameter. When <code>false</code>, any existing policy association is removed, regardless of whether you specify a QoS policy in the <code>QoSPolicy</code> parameter. 	boolean	<code>true</code>	No
<code>attributes</code>	List of name-value pairs in JSON object format. The total attribute size must be less than 1000B, or 1KB, including JSON formatting characters.	JSON object	None	No

Name	Description	Type	Default value	Required
enable512e	<p>Enable 512-byte sector emulation. Possible values:</p> <ul style="list-style-type: none"> • <code>true</code>: The volume provides 512-byte sector emulation. • <code>false</code>: 512e emulation is not enabled. 	boolean	None	Yes
enableSnapMirrorReplication	<p>Determines whether the volume can be used for replication with SnapMirror endpoints. Possible values:</p> <ul style="list-style-type: none"> • <code>true</code> • <code>false</code> 	boolean	false	No
name	Name of the volume access group (may be user-specified). Not required to be unique, but recommended. Must be 1 to 64 characters in length.	string	None	Yes
qos	<p>The initial quality of service settings for this volume. Default values are used if none are specified. Possible values:</p> <ul style="list-style-type: none"> • <code>minIOPS</code> • <code>maxIOPS</code> • <code>burstIOPS</code> 	QoS object	None	No
qosPolicyID	The ID for the policy whose QoS settings should be applied to the specified volumes. This parameter is mutually exclusive with the <code>qos</code> parameter.	integer	None	No
totalSize	Total size of the volume, in bytes. Size is rounded up to the nearest megabyte.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
volume	Object containing information about the newly created volume.	<i>volume</i>
volumeID	The volumeID for the newly created volume.	integer
curve	The curve is a set of key-value pairs. The keys are the I/O sizes in bytes. The values represent the cost of performing an IOP at a specific I/O size. The curve is calculated relative to a 4096 byte operation set at 100 IOPS.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateVolume",
  "params": {
    "name": "mysqldata",
    "accountID": 1,
    "totalSize": 107374182400,
    "enable512e": false,
    "attributes": {
      "name1": "value1",
      "name2": "value2",
      "name3": "value3"
    },
    "qos": {
      "minIOPS": 50,
      "maxIOPS": 500,
      "burstIOPS": 1500,
      "burstTime": 60
    }
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "curve": {
      "4096": 100,
      "8192": 160,
      "16384": 270,
      "32768": 500,
      "65536": 1000,
      "131072": 1950,
      "262144": 3900,
      "524288": 7600,
      "1048576": 15000
    }
  }
}
```

```

    },
    "volume": {
      "access": "readWrite",
      "accountID": 1,
      "attributes": {
        "name1": "value1",
        "name2": "value2",
        "name3": "value3"
      },
      "blockSize": 4096,
      "createTime": "2016-03-31T22:20:22Z",
      "deleteTime": "",
      "enable512e": false,
      "iqn": "iqn.2010-01.com.solidfire:mysqldata.677",
      "name": "mysqldata",
      "purgeTime": "",
      "qos": {
        "burstIOPS": 1500,
        "burstTime": 60,
        "curve": {
          "4096": 100,
          "8192": 160,
          "16384": 270,
          "32768": 500,
          "65536": 1000,
          "131072": 1950,
          "262144": 3900,
          "524288": 7600,
          "1048576": 15000
        },
        "maxIOPS": 500,
        "minIOPS": 50
      },
      "scsiEUIDeviceID": "6a7961790000002a5f47acc0100000000",
      "scsiNAADeviceID": "6f47acc1000000006a7961790000002a5",
      "sliceCount": 0,
      "status": "active",
      "totalSize": 107374182400,
      "virtualVolumeID": null,
      "volumeAccessGroups": [],
      "volumeID": 677,
      "volumePairs": []
    },
    "volumeID": 677
  }
}

```

Related references

[GetDefaultQoS](#) on page 354

CreateVolumeAccessGroup

You can use `CreateVolumeAccessGroup` to create a new volume access group. When you create the volume access group, you need to give it a name, and you can optionally enter initiators and volumes.

Any initiator IQN that you add to the volume access group is able to access any volume in the group without CHAP authentication.

Note: Cloned volumes do not inherit volume access group membership from the source volume. Consider the following when you create volume access groups:

- A volume access group can contain up to 64 initiator IQNs.
- An initiator can only belong to one volume access group.

- A volume access group can contain up to 2000 volumes.
- Each volume access group can belong to a maximum of four other volume access groups.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
initiators	List of initiator IDs or names (IQNs and WWPNs) to include in the volume access group. If you pass a list of initiator names, the initiators are created if they do not already exist. If you pass a list of initiator IDs, the method returns an error if any of the initiators does not already exist. Passing initiator names is deprecated; you should use initiator IDs whenever possible.	integer array or string array (deprecated)	[]	No
name	Name of the volume access group. Not required to be unique, but recommended. Must be 1 to 64 characters in length.	string	None	Yes
volumes	List of volumeIDs to include in the volume access group.	integer array	[]	No
attributes	List of name-value pairs in JSON object format.	JSON object	{ }	No

Return values

This method has the following return values:

Name	Description	Type
volumeAccessGroup	An object containing information about the newly created volume access group.	<i>volumeAccessGroup</i>
volumeAccessGroupID	The ID of the newly created volume access group.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateVolumeAccessGroup",
  "params": {
    "name": "myaccessgroup",
    "initiators": ["iqn.1993-08.org.debian: 01: a31b1d799d5c"],
    "volumes": [327],
```

```

    "attributes": {}
  }
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": null,
  "result": {
    "volumeAccessGroup": {
      "attributes": {},
      "deletedVolumes": [],
      "initiatorIDs": [
        95
      ],
      "initiators": [
        "iqn.1993-08.org.debian: 01: a31b1d799d5c"
      ],
      "name": "myaccessgroup",
      "volumeAccessGroupID": 96,
      "volumes": [
        327
      ]
    },
    "volumeAccessGroupID": 96
  }
}

```

Related references

[GetAsyncResult](#) on page 94

[ListSyncJobs](#) on page 366

[ModifyVolume](#) on page 387

CreateBackupTarget

You can use `CreateBackupTarget` to create and store backup target information so that you do not need to reenter it each time a backup is created.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
name	Name for the backup target.	string	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON object	None	Yes (but can be empty)

Return value

This method has the following return value:

Name	Description	Type
backupTargetID	Unique identifier assigned to the new backup target.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateBackupTarget",
  "params": {
    "name": "mytargetbackup"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "backupTargetID": 1
  }
}
```

CreateInitiators

You can use `CreateInitiators` to create multiple new initiator IQNs or World Wide Port Names (WWPNs) and optionally assign them aliases and attributes. When you use `CreateInitiators` to create new initiators, you can also add them to volume access groups.

If the operation fails to create one of the initiators provided in the parameter, the method returns an error and does not create any initiators (no partial completion is possible).

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
initiators	<p>A list of objects containing characteristics of each new initiator. Objects:</p> <ul style="list-style-type: none"> • name: (Required) The name of the initiator (IQN or WWPN) to create. (string) • alias: (Optional) The friendly name to assign to this initiator. (string) • attributes: (Optional) A set of JSON attributes to assign to this initiator. (JSON object) • volumeAccessGroupID: (Optional) The ID of the volume access group into to which this newly created initiator will be added. (integer) 	JSON object array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
initiators	<p>List of objects containing details about the newly created initiators:</p> <ul style="list-style-type: none"> • alias: The friendly name assigned to this initiator. (string) • attributes: A set of JSON attributes assigned to this initiator. (JSON object) • initiatorID: The numeric ID of the initiator that has been created. (integer) • initiatorName: The name of the initiator that has been created. (string) • volumeAccessGroups: A list of volumeAccessGroupIDs to which this initiator belongs. (integer array) 	JSON object array

Error

This method can return the following error:

Name	Description
xInitiatorExists	Returned if the initiator name you chose already exists.

Request example

Requests for this method are similar to the following example:

```
{
  "id": 3291,
  "method": "CreateInitiators",
  "params": {
    "initiators": [
      {
        "name": "iqn.1993-08.org.debian:01:288170452",
        "alias": "example1"
      },
      {
        "name": "iqn.1993-08.org.debian:01:297817012",
        "alias": "example2"
      }
    ]
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 3291,
  "result": {
    "initiators": [
      {
        "alias": "example1",
        "attributes": {},
        "initiatorID": 145,
        "initiatorName": "iqn.1993-08.org.debian:01:288170452",
        "volumeAccessGroups": []
      },
      {
        "alias": "example2",
        "attributes": {},
        "initiatorID": 146,
        "initiatorName": "iqn.1993-08.org.debian:01:297817012",
        "volumeAccessGroups": []
      }
    ]
  }
}
```

Related references

[ListInitiators](#) on page 364

DeleteInitiators

You can use `DeleteInitiators` to delete one or more initiators from the system (and from any associated volumes or volume access groups).

If `DeleteInitiators` fails to delete one of the initiators provided in the parameter, the system returns an error and does not delete any initiators (no partial completion is possible).

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
initiators	An array of IDs of initiators to delete.	integer array	None	Yes

Return values

This method has no return values.

Error

This method can return the following error:

Name	Description
xInitiatorDoesNotExist	Returned if the initiator name you choose does not exist.

Request example

Requests for this method are similar to the following example:

```
{
  "id": 5101,
  "method": "DeleteInitiators",
  "params": {
    "initiators": [
      145,
      147
    ]
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 5101,
  "result": {}
}
```

DeleteQoSPolicy

You can use the `DeleteQoSPolicy` method to delete a QoS policy from the system. The QoS settings for all volumes created or modified with this policy are unaffected.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
qosPolicyID	The ID of the QoS policy to be deleted.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "id": 663,
  "method": "DeleteQoSPolicy",
  "params": {
    "qosPolicyID": 4
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 663,
  "result": {}
}
```

DeleteVolume

You can use the `DeleteVolume` method to mark an active volume for deletion. When marked, the volume is purged (permanently deleted) after the cleanup interval elapses.

After making a request to delete a volume, any active iSCSI connections to the volume are immediately terminated and no further connections are allowed while the volume is in this state. A marked volume is not returned in target discovery requests.

Any snapshots of a volume that has been marked for deletion are not affected. Snapshots are kept until the volume is purged from the system. If a volume is marked for deletion and has a bulk volume read or bulk volume write operation in progress, the bulk volume read or write operation is stopped.

If the volume you delete is paired with a volume, replication between the paired volumes is suspended and no data is transferred to it or from it while in a deleted state. The remote volume the deleted volume was paired with enters into a `PausedMisconfigured` state and data is no longer sent to it or from the deleted volume. Until the deleted volume is purged, it can be restored and data transfers resume. If the deleted volume gets purged from the system, the volume it was paired with enters into a `StoppedMisconfigured` state and the volume pairing status is removed. The purged volume becomes permanently unavailable.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	The ID of the volume to delete.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
volume	Object containing information about the deleted volume.	<i>volume</i>
volumeID	The volumeID of the deleted volume.	integer
curve	The curve is a set of key-value pairs. The keys are the I/O sizes in bytes. The values represent the cost of performing an IOP at a specific I/O size. The curve is calculated relative to a 4096 byte operation set at 100 IOPS.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteVolume",
  "params": {
    "volumeID" : 5
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volume": {
      "access": "readWrite",
      "accountID": 1,
      "attributes": {
        "name1": "value1",
        "name2": "value2",
        "name3": "value3"
      },
      "blockSize": 4096,
      "createTime": "2016-03-28T16:16:13Z",
      "deleteTime": "2016-03-31T22:59:42Z",
      "enable512e": true,
      "iqn": "iqn.2010-01.com.solidfire:jyay.1459181777648.5",
      "name": "1459181777648",
      "purgeTime": "2016-04-01T06:59:42Z",
      "qos": {
        "burstIOPS": 150,
        "burstTime": 60,
        "curve": {
          "4096": 100,
          "8192": 160,
          "16384": 270,
          "32768": 500,
          "65536": 1000,
          "131072": 1950,
          "262144": 3900,
          "524288": 7600,
          "1048576": 15000
        },
        "maxIOPS": 100,
        "minIOPS": 60
      }
    },
    "scsiEUIDeviceID": "6a79617900000005f47acc0100000000",
  }
}
```

```

    "scsiNAADeviceID": "6f47acc1000000006a79617900000005",
    "sliceCount": 1,
    "status": "deleted",
    "totalSize": 1000341504,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
      1
    ],
    "volumeID": 5,
    "volumePairs": []
  }
}
}

```

DeleteVolumes

You can use the `DeleteVolumes` method to mark multiple (up to 500) active volumes for deletion. When marked, the volume is purged (permanently deleted) after the cleanup interval elapses.

After making a request to delete volumes, any active iSCSI connections to the volumes are immediately terminated and no further connections are allowed while the volumes are in this state. A marked volume is not returned in target discovery requests.

Any snapshots of a volume that has been marked for deletion are not affected. Snapshots are kept until the volume is purged from the system. If a volume is marked for deletion and has a bulk volume read or bulk volume write operation in progress, the bulk volume read or write operation is stopped.

If the volumes you delete are paired with a volume, replication between the paired volumes is suspended and no data is transferred to them or from them while in a deleted state. The remote volumes the deleted volumes were paired with enter into a `PausedMisconfigured` state and data is no longer sent to them or from the deleted volumes. Until the deleted volumes are purged, they can be restored and data transfers resume. If the deleted volumes are purged from the system, the volumes they were paired with enter into a `StoppedMisconfigured` state and the volume pairing status is removed. The purged volumes become permanently unavailable.

Parameters

This method has the following input parameters.

Note: At least one of the following parameters are required, and you must use only one of the parameters (they are all mutually exclusive with one another).

Name	Description	Type	Default value	Required
<code>volumeIDs</code>	The list of IDs of the volumes to delete from the system.	integer array	None	See Note.
<code>volumeAccessGroupIDs</code>	A list of volume access group IDs. All of the volumes from all of the volume access groups you specify in this list are deleted from the system.	integer array	None	See Note.

Name	Description	Type	Default value	Required
accountIDs	A list of account IDs. All volumes from these accounts are deleted from the system.	integer array	None	See Note.

Return values

This method has the following return values:

Name	Description	Type
volumes	Information about the newly deleted volume.	<i>volume</i>
curve	The curve is a set of key-value pairs. The keys are the I/O sizes in bytes. The values represent the cost of performing an IOP at a specific I/O size. The curve is calculated relative to a 4096 byte operation set at 100 IOPS.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteVolumes",
  "params": {
    "accountIDs" : [1, 2, 3]
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result": {
    "volumes" : [ {
      "access": "readWrite",
      "accountID": 1,
      "attributes": {},
      "blockSize": 4096,
      "createTime": "2015-03-06T18:50:56Z",
      "deleteTime": "",
      "enable512e": False,
      "iqn": "iqn.2010-01.com.solidfire:pzsr.vclient-030-v00001.1",
      "name": "vclient-030-v00001",
      "qos": {
        "burstIOPS": 15000,
        "burstTime": 60,
        "curve": {},
        "maxIOPS": 15000,
        "minIOPS": 100
      }
    } ],
  }
```

```

    "purgeTime": "",
    "sliceCount": 1,
    "scsiEUIDeviceID": "707a7372000000001f47acc0100000000",
    "scsiNAADeviceID": "6f47acc1000000000707a737200000001",
    "status": "active",
    "totalSize": 10000003072,
    "virtualVolumeID": 5,
    "volumeAccessGroups": [],
    "volumePairs": [],
    "volumeID": 1
  }
}
}

```

DeleteVolumeAccessGroup

You can use DeleteVolumeAccessGroup to delete a volume access group.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeAccessGroupID	The ID of the volume access group to be deleted.	integer	None	Yes
deleteOrphanInitiators	<p>Specifies whether to delete initiator objects or not. Possible values:</p> <ul style="list-style-type: none"> • true: Delete initiator objects after they are removed from a volume access group. • false: Do not delete initiator objects after they are removed from a volume access group. 	boolean	true	No

Name	Description	Type	Default value	Required
force	<p>Adding this flag will force the volume access group to be deleted even though it has a Virtual Network ID or Tag. Possible values:</p> <ul style="list-style-type: none"> • true: Volume access group will be deleted. • false: Default. Do not delete the volume access group if it has a Virtual Network ID or Tag. 	boolean	false	No

Return values

This method does not have return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteVolumeAccessGroup",
  "params": {
    "force": true
    "volumeAccessGroupID" : 3,
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result": {}
}
```

GetBackupTarget

You can use the `GetBackupTarget` method to return information about a specific backup target that you have created.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
backupTargetID	Unique identifier assigned to the backup target.	integer	None	Yes
name	Name of the backup target.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
backupTarget	List of name-value pairs in JSON object format.	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "id": 1,
  "method": "GetBackupTarget",
  "params": {
    "backupTargetID": 1
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "backupTarget": {
      "attributes": {
        "size": 100
      },
      "backupTargetID": 1,
      "name": "mytargetbackup"
    }
  }
}
```

GetVolumeStats

You can use the `GetVolumeStats` method to get high-level activity measurements for a single volume. Values are cumulative from the creation of the volume.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	Specifies the volume for which statistics are gathered.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
volumeStats	Volume activity information.	<i>volumeStats</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetVolumeStats",
  "params": {
    "volumeID": 32
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeStats": {
      "accountID": 1,
      "actualIOPS": 0,
      "asyncDelay": null,
      "averageIOPSsize": 0,
      "burstIOPSCredit": 0,
      "clientQueueDepth": 0,
      "desiredMetadataHosts": null,
      "latencyUsec": 0,
      "metadataHosts": {
        "deadSecondaries": [],
        "liveSecondaries": [
          32
        ],
      },
      "primary": 60
    },
    "nonZeroBlocks": 0,
    "readBytes": 0,
    "readBytesLastSample": 0,
    "readLatencyUsec": 0,
    "readOps": 0,
    "readOpsLastSample": 0,
    "samplePeriodMsec": 0,
    "throttle": 0,
    "timestamp": "2016-04-01T21:01:39.130840Z",
    "unalignedReads": 0,
    "unalignedWrites": 0,
    "volumeAccessGroups": [],
    "volumeID": 1,
    "volumeSize": 5000658944,
    "volumeUtilization": 0,
  }
}
```

```

        "writeBytes": 0,
        "writeBytesLastSample": 0,
        "writeLatencyUsec": 0,
        "writeOps": 0,
        "writeOpsLastSample": 0,
        "zeroBlocks": 1220864
    }
}
}

```

GetDefaultQoS

You can use the `GetDefaultQoS` method to get the default quality of service (QoS) values for a newly created volume.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
QoS	The default QoS values.	QoS

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetDefaultQoS",
  "params": {},
  "id" : 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id" : 1,
  "result" : {
    "burstIOPS" : 15000,
    "burstTime" : 60,
    "curve" : {
      "1048576" : 15000,
      "131072" : 1900,
      "16384" : 270,
      "262144" : 3000,
      "32768" : 500,
      "4096" : 100,
      "524288" : 7500,
      "65536" : 1000,
      "8192" : 160
    },
    "maxIOPS" : 15000,
    "minIOPS" : 100
  }
}

```

GetQoSPolicy

You can use the `GetQoSPolicy` method to get details about a specific QoS policy from the system.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>qosPolicyID</code>	The ID of the policy to be retrieved.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
<code>qosPolicy</code>	Details of the requested QoS policy.	<i>QoSPolicy</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetQoSPolicy",
  "params": {
    "qosPolicyID": 2
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "qosPolicy": {
      "name": "bronze",
      "qos": {
        "burstIOPS": 15002,
        "burstTime": 60,
        "curve": {
          "4096": 100,
          "8192": 160,
          "16384": 270,
          "32768": 500,
          "65536": 1000,
          "131072": 1950,
          "262144": 3900,
          "524288": 7600,
          "1048576": 15000
        },
        "maxIOPS": 15002,
        "minIOPS": 51
      }
    }
  }
}
```

```

        "qosPolicyID": 2,
        "volumeIDs": [
            2
        ]
    }
}

```

GetVolumeCount

You can use the `GetVolumeCount` method to get the number of volumes currently in the system.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
count	The number of volumes currently in the system.	integer

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetVolumeCount",
  "params": {
  },
  "id": 1
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "count": 7
  }
}

```

GetVolumeAccessGroupEfficiency

You can use the `GetVolumeAccessGroupEfficiency` method to get efficiency information about a volume access group. Only the volume access group you provide as the parameter in this API method is used to compute the capacity.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeAccessGroupID	Specifies the volume access group for which capacity is computed.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
compression	The amount of space saved by data compression for all volumes in the volume access group. Stated as a ratio where a value of 1 means data has been stored with no compression.	float
deduplication	The amount of space saved by not duplicating data for all volumes in the volume access group. Stated as a ratio.	float
thinProvisioning	The ratio of space used to the amount of space allocated for storing data. Stated as a ratio.	float
timestamp	The last time efficiency data was collected after garbage collection.	ISO 8601 data string
missingVolumes	The volumes that could not be queried for efficiency data. Missing volumes can be caused by a recent garbage collection, temporary network loss or restarted services since the garbage collection cycle.	integer array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetVolumeAccessGroupEfficiency",
  "params": {
    "volumeAccessGroupID": 1
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "compression": 2.006012925331075,
    "deduplication": 1,
    "missingVolumes": [],
    "thinProvisioning": 1.009861932938856,
  }
}
```

```

    "timestamp": "2014-03-10T17:05:27Z"
  }
}

```

GetVolumeEfficiency

You can use the `GetVolumeEfficiency` method to get information about a volume. Only the volume you give as a parameter in this API method is used to compute the capacity.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	Specifies the volume for which capacity is computed.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
compression	The amount of space being saved by compressing data on a single volume. Stated as a ratio, where 1 means data has been stored without being compressed.	float
deduplication	The amount of space being saved on a single volume by not duplicating data. Stated as a ratio.	float
missingVolumes	The volumes that could not be queried for efficiency data. Missing volumes can be caused by Garbage Collection (GC) being less than an hour old, temporary network loss or restarted services since the GC cycle.	integer array
thinProvisioning	The ratio of space used to the amount of space allocated for storing data. Stated as a ratio.	float
timestamp	The last time efficiency data was collected after GC.	ISO 8601 data string

Request example

Requests for this method are similar to the following example:

```

{
  "method": "GetVolumeEfficiency",
  "params": {
    "volumeID": 606
  },
}

```

```
{
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "compression": 2.001591240821456,
    "deduplication": 1,
    "missingVolumes": [],
    "thinProvisioning": 1.009861932938856,
    "timestamp": "2014-03-10T16:06:33Z"
  }
}
```

ListActiveVolumes

You can use the `ListActiveVolumes` method to get the list of active volumes currently in the system. The list of volumes is sorted in `VolumeID` order and can be returned in multiple parts (pages).

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>includeVirtualVolumes</code>	Virtual volumes are included in the response, by default. To exclude virtual volumes, set to <code>false</code> .	boolean	<code>true</code>	No
<code>startVolumeID</code>	Starting <code>VolumeID</code> to return. If no volume exists with this <code>VolumeID</code> , the next volume by <code>VolumeID</code> order is used as the start of the list. To page through the list, pass the <code>VolumeID</code> of the last volume in the previous response + 1.	integer	0	No
<code>limit</code>	Maximum number of volume info objects to return. 0 (zero) returns all volumes (unlimited).	integer	(unlimited)	No

Return value

This method has the following return value:

Name	Description	Type
volumes	List of active volumes.	<i>volume</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListActiveVolumes",
  "params": {
    "startVolumeID" : 0,
    "limit" : 1000
  },
  "id" : 1
}
```

Response example

Due to the length of this response example, it is documented in a supplementary topic.

ListBackupTargets

You can use the `ListBackupTargets` method to get information about all backup targets that have been created.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
backupTargets	Objects returned for each backup target. Included objects: <ul style="list-style-type: none"><code>attributes</code>: List of name-value pairs in JSON object format. (JSON object)<code>backupTargetID</code>: Unique identifier assigned to the backup target. (integer)<code>name</code>: Name of the backup target. (string)	JSON object

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListBackupTargets",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "backupTargets": [
      {
        "attributes" : {},
        "backupTargetID" : 1,
        "name" : "mytargetbackup"
      }
    ]
  }
}
```

ListBulkVolumeJobs

You can use the `ListBulkVolumeJobs` method to get information about each bulk volume read or write operation that is occurring in the system.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
bulkVolumeJobs	An array of information for each bulk volume job.	<i>bulkVolumeJob</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListBulkVolumeJobs",
  "params": {
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "bulkVolumeJobs": [
      {
        "attributes": {
          "blocksPerTransfer": 1024,
          "firstPendingLba": 216064,
          "nLbas": 2441472,
          "nextLba": 226304,
          "pendingLbas": "[220160, 223232, 221184, 224256, 217088, 225280, 222208, 218112, 219136, 216064]",
          "percentComplete": 8,
          "startLba": 0
        },
        "bulkVolumeID": 2,
        "createTime": "2015-05-07T14:52:17Z",
        "elapsedTime": 44,
        "format": "native",
        "key": "eaffb0526d4fb47107061f09bfc9a806",
        "percentComplete": 8,
        "remainingTime": 506,
        "script": "bv_internal.py",
        "snapshotID": 509,
        "srcVolumeID": 3,
        "status": "running",
        "type": "read"
      }
    ]
  }
}
```

ListDeletedVolumes

You can use the `ListDeletedVolumes` method to retrieve the list of volumes that have been marked for deletion and purged from the system.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>includeVirtualVolumes</code>	Virtual volumes are included in the response, by default. To exclude virtual volumes, set to false.	boolean	true	No

Return value

This method has the following return value:

Name	Description	Type
<code>volumes</code>	List of deleted volumes.	<i>volume</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListDeletedVolumes",
  "params": {},
  "id" : 1
}
```

Response example

Responses for this method are similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumes": [
      {
        "access": "readWrite",
        "accountID": 2,
        "attributes": {},
        "blockSize": 4096,
        "createTime": "2018-06-24T03:13:13Z",
        "deleteTime": "2018-07-22T16:12:39Z",
        "enable512e": true,
        "iqn": "iqn.2010-01.com.solidfire:0oto.deletethis.23",
        "name": "deleteThis",
        "purgeTime": "2016-07-23T00:12:39Z",
        "qos": {
          "burstIOPS": 15000,
          "burstTime": 60,
          "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
          },
          "maxIOPS": 15000,
          "minIOPS": 50
        },
        "scsiEUIDeviceID": "306f746f00000017f47acc0100000000",
        "scsiNAADeviceID": "6f47acc100000000306f746f00000017",
        "sliceCount": 1,
        "status": "deleted",
        "totalSize": 1396703232,
        "virtualVolumeID": null,
        "volumeAccessGroups": [],
        "volumeID": 23,
        "volumePairs": []
      }
    ]
  }
}
```

ListInitiators

You can use the `ListInitiators` method to get the list of initiator IQNs or World Wide Port Names (WWPNs).

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>initiators</code>	A list of initiator IDs to retrieve. You can supply this parameter or the <code>startInitiatorID</code> parameter, but not both.	integer array	None	No
<code>startInitiatorID</code>	The initiator ID at which to begin the listing. You can supply this parameter or the <code>initiators</code> parameter, but not both.	integer	0	No
<code>limit</code>	The maximum number of initiator objects to return.	integer	(unlimited)	No

Return value

This method has the following return value:

Name	Description	Type
<code>initiators</code>	List of the initiator information.	<i>initiator</i> array

Exceptions

This method can have the following exception:

Name	Description
<code>xInvalidParameter</code>	Thrown if you include both the <code>startInitiatorID</code> and the <code>initiators</code> parameters in the same method call.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListInitiators",
  "params": {},
}
```

```

    "id" : 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "initiators": [
      {
        "alias": "",
        "attributes": {},
        "initiatorID": 2,
        "initiatorName": "iqn.1993-08.org.debian:01:c84ffd71216",
        "volumeAccessGroups": [
          1
        ]
      }
    ]
  }
}

```

ListQoS Policies

You can use the `ListQoS Policies` method to list the settings of all QoS policies on the system.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
qosPolicies	A list of details about each QoS policy.	<i>QoS Policy</i> array

Request example

Requests for this method are similar to the following example:

```

{
  "id": 231,
  "method": "ListQoS Policies",
  "params": {}
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 231,
  "result": {
    "qosPolicies": [
      {
        "name": "silver",

```

```

        "qos": {
            "burstIOPS": 15000,
            "burstTime": 60,
            "curve": {
                "4096": 100,
                "8192": 160,
                "16384": 270,
                "32768": 500,
                "65536": 1000,
                "131072": 1950,
                "262144": 3900,
                "524288": 7600,
                "1048576": 15000
            },
            "maxIOPS": 14000,
            "minIOPS": 50
        },
        "qosPolicyID": 1,
        "volumeIDs": [
            1
        ]
    },
    {
        "name": "bronze",
        "qos": {
            "burstIOPS": 15000,
            "burstTime": 60,
            "curve": {
                "4096": 100,
                "8192": 160,
                "16384": 270,
                "32768": 500,
                "65536": 1000,
                "131072": 1950,
                "262144": 3900,
                "524288": 7600,
                "1048576": 15000
            },
            "maxIOPS": 15000,
            "minIOPS": 50
        },
        "qosPolicyID": 2,
        "volumeIDs": [
            2
        ]
    }
]
}

```

ListSyncJobs

You can use the `ListSyncJobs` method to get information about synchronization jobs that are running on an Element storage cluster. This method returns information about slice, clone, block, and remote synchronization jobs.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
syncJobs	List of objects describing synchronization processes that are currently running in the system.	<i>syncJob</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListSyncJobs",
  "params": { },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id":1,
  "result":{
    "syncJobs":[
      {
        "bytesPerSecond":275314.8834458956,
        "currentBytes":178257920,
        "dstServiceID":36,
        "elapsedTime":289.4568382049871,
        "percentComplete":8.900523560209423,
        "remainingTime":2962.675921065957,
        "sliceID":5,
        "srcServiceID":16,
        "stage":"whole",
        "totalBytes":200278016remote0,
        "type":"slice"
      },
      {
        "bytesPerSecond":305461.3198607744,
        "cloneID":1,
        "currentBytes":81788928,
        "dstServiceID":16,
        "dstVolumeID":6,
        "elapsedTime":291.7847648200743,
        "nodeID":1,
        "percentComplete":8.167539267015707,
        "remainingTime":3280.708270981153,
        "sliceID":6,
        "srcServiceID":16,
        "srcVolumeID":5,
        "stage":"whole",
        "totalBytes":1001390080,
        "type":"clone"
      },
      {
        "blocksPerSecond":0,
        "branchType": "snapshot",
        "dstServiceID":8,
        "dstVolumeID":2,
        "elapsedTime":0,
        "percentComplete":0,
        "remainingTime":0,
        "sliceID":2,
        "stage":"metadata",
        "type":"remote"
      }
    ]
  }
}
```

```
    }
  }
```

ListVolumeQoSHistograms

You can use the `ListVolumeQoSHistograms` method to generate a histogram of volume QoS usage for one volume or multiple volumes. This enables you to better understand how volumes are using QoS.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeIDs	An optional list of volume IDs specifying which volumes should have QoS histograms generated.	integer array	None	No

Return value

This method has the following return value:

Name	Description	Type
qosHistograms	A list of objects describing volume usage for one or more volumes.	JSON object array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumeQoSHistograms",
  "params": {
    "volumeIDs": [1]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "qosHistograms": [
      {
        "histograms": {
          "belowMinIopsPercentages": {
            "Bucket1To19": 2406,
            "Bucket20To39": 3,
            "Bucket40To59": 0,
            "Bucket60To79": 4,
            "Bucket80To100": 0
          }
        }
      }
    ]
  }
}
```



```

        "minToMaxIopsPercentages": {
            "Bucket101Plus": 0,
            "Bucket1To19": 0,
            "Bucket20To39": 0,
            "Bucket40To59": 2,
            "Bucket60To79": 0,
            "Bucket80To100": 0
        },
        "readBlockSizes": {
            "Bucket131072Plus": 0,
            "Bucket16384To32767": 0,
            "Bucket32768To65535": 0,
            "Bucket4096To8191": 0,
            "Bucket65536To131071": 0,
            "Bucket8192To16383": 0
        },
        "targetUtilizationPercentages": {
            "Bucket0": 134943,
            "Bucket101Plus": 0,
            "Bucket1To19": 2409,
            "Bucket20To39": 4,
            "Bucket40To59": 0,
            "Bucket60To79": 2,
            "Bucket80To100": 0
        },
        "throttlePercentages": {
            "Bucket0": 137358,
            "Bucket1To19": 0,
            "Bucket20To39": 0,
            "Bucket40To59": 0,
            "Bucket60To79": 0,
            "Bucket80To100": 0
        },
        "writeBlockSizes": {
            "Bucket131072Plus": 0,
            "Bucket16384To32767": 0,
            "Bucket32768To65535": 0,
            "Bucket4096To8191": 0,
            "Bucket65536To131071": 0,
            "Bucket8192To16383": 0
        }
    },
    "timestamp": "2018-06-21T18:45:52.010844Z",
    "volumeID": 1
}
]
}
}

```

ListVolumes

You can use the `ListVolumes` method to get a list of volumes that are in a cluster. You can specify the volumes you want to return in the list by using the available parameters.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
accounts	Only volumes owned by the accounts you specify here are returned. Mutually exclusive with the volumeIDs parameter.	integer array	None	No
includeVirtualVolumes	Virtual volumes are included in the response by default. To exclude virtual volumes, set to false.	boolean	true	No
isPaired	Returns volumes that are paired or not paired. Possible values: <ul style="list-style-type: none"> • true: Returns all paired volumes. • false: Returns all volumes not paired. 	boolean	None	No
limit	Enables you to set the maximum number of volume results that are returned. Mutually exclusive with the volumeIDs parameter.	integer	10000	No
startVolumeID	Only volumes with an ID greater than or equal to this value are returned. Mutually exclusive with the volumeIDs parameter.	integer	None	No
volumeIDs	A list of volume IDs. If you specify this parameter, other parameters operate only on this set of volumes. Mutually exclusive with the accounts, startVolumeID, and limit parameters.	integer array	No	No
volumeName	Only volume object information matching the volume name is returned.	string	No	No

Name	Description	Type	Default value	Required
volumeStatus	<p>Only volumes with a status equal to the status value are returned. Possible values:</p> <ul style="list-style-type: none"> creating snapshotting active deleted 	string	No	No

Return value

This method has the following return value:

Name	Description	Type
volumes	List of volumes.	<i>volume</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumes",
  "params": {
    "volumeIDs": [1],
    "volumeStatus": "active",
    "isPaired": "false"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumes": [
      {
        "access": "readWrite",
        "accountID": 1,
        "attributes": {},
        "blockSize": 4096,
        "createTime": "2016-03-28T14:39:05Z",
        "deleteTime": "",
        "enable512e": true,
        "iqn": "iqn.2010-01.com.solidfire:testvolume1.1",
        "name": "testVolume1",
        "purgeTime": "",
        "qos": {
          "burstIOPS": 15000,
          "burstTime": 60,
          "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
```

```

        "32768": 500,
        "65536": 1000,
        "131072": 1950,
        "262144": 3900,
        "524288": 7600,
        "1048576": 15000
    },
    "maxIOPS": 15000,
    "minIOPS": 50
},
"scsiEUIDeviceID": "6a796179000000001f47acc0100000000",
"scsiNAADeviceID": "6f47acc10000000006a79617900000001",
"sliceCount": 1,
"status": "active",
"totalSize": 5000658944,
"virtualVolumeID": null,
"volumeAccessGroups": [],
"volumeID": 1,
"volumePairs": []
}
    ]
}

```

ListVolumeStats

You can use the `ListVolumeStats` method to get high-level activity measurements for a single volume, list of volumes, or all volumes (if you omit the `volumeIDs` parameter). Measurement values are cumulative from the creation of the volume.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>includeVirtualVolumes</code>	Virtual volumes are included in the response by default. To exclude virtual volumes, set to <code>false</code> .	boolean	<code>true</code>	No
<code>volumeIDs</code>	A list of volumes from which to retrieve activity information.	integer array	No	No

Return value

This method has the following return value:

Name	Description	Type
<code>volumeStats</code>	List of volume activity information.	<i>volumeStats</i> array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListVolumeStats",

```

```

    "params": {
      "volumeIDs": [1]
    },
    "id": 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "volumeStats": [
      {
        "accountID": 1,
        "actualIOPS": 0,
        "asyncDelay": null,
        "averageIOPSize": 0,
        "burstIOPSCredit": 30000,
        "clientQueueDepth": 0,
        "desiredMetadataHosts": null,
        "latencyUsec": 0,
        "metadataHosts": {
          "deadSecondaries": [],
          "liveSecondaries": [
            47
          ],
          "primary": 33
        },
        "nonZeroBlocks": 22080699,
        "readBytes": 657262370816,
        "readBytesLastSample": 0,
        "readLatencyUsec": 0,
        "readOps": 160464446,
        "readOpsLastSample": 0,
        "samplePeriodMsec": 500,
        "throttle": 0,
        "timestamp": "2016-03-09T19:39:15.771697Z",
        "unalignedReads": 0,
        "unalignedWrites": 0,
        "volumeAccessGroups": [
          1
        ],
        "volumeID": 1,
        "volumeSize": 107374182400,
        "volumeUtilization": 0,
        "writeBytes": 219117547520,
        "writeBytesLastSample": 0,
        "writeLatencyUsec": 0,
        "writeOps": 53495495,
        "writeOpsLastSample": 0,
        "zeroBlocks": 4133701
      }
    ]
  }
}

```

ListVolumeAccessGroups

You can use the `ListVolumeAccessGroups` method to get information about the volume access groups that are currently in the system.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>limit</code>	Maximum number of <code>volumeAccessGroup</code> objects to return. Mutually exclusive with the <code>volumeAccessGroups</code> parameter.	integer	Unlimited	No
<code>startVolumeAccessGroupID</code>	The volume access group ID at which to begin the listing. Mutually exclusive with the <code>volumeAccessGroups</code> parameter.	integer	0	No
<code>volumeAccessGroups</code>	List of <code>volumeAccessGroupID</code> values to retrieve. Mutually exclusive with the <code>startVolumeAccessGroupID</code> and <code>limit</code> parameters.	integer array	[]	No

Return values

This method has the following return values:

Name	Description	Type
<code>volumeAccessGroups</code>	A list of objects describing each volume access group.	<i>volumeAccessGroup</i> array
<code>volumeAccessGroupsNotFound</code>	A list of volume access groups not found by the system. Present if you used the <code>volumeAccessGroups</code> parameter and the system was unable to find one or more volume access groups that you specified.	integer array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumeAccessGroups",
  "params": {
    "startVolumeAccessGroupID": 3,
    "limit" : 1
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeAccessGroups": [
      {
        "attributes": {},
        "deletedVolumes": [],
        "initiatorIDs": [],
        "initiators": [],
        "name": "example1",
        "volumeAccessGroupID": 3,
        "volumes": []
      }
    ]
  }
}
```

ListVolumesForAccount

You can use the `ListVolumesForAccount` method to list active and (pending) deleted volumes for an account.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>includeVirtualVolumes</code>	Virtual volumes are included in the response by default. To exclude virtual volumes, set to <code>false</code> .	boolean	<code>true</code>	No
<code>accountID</code>	All volumes owned by this <code>accountID</code> are returned.	integer	No	Yes

Return value

This method has the following return value:

Name	Description	Type
volumes	List of volume information.	<i>volume</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumesForAccount",
  "params": {
    "accountID" : 1
  },
  "id" : 1
}
```

Response example

Responses for this method are similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumes": [
      {
        "access": "readWrite",
        "accountID": 1,
        "attributes": {},
        "blockSize": 4096,
        "createTime": "2018-07-22T16:15:25Z",
        "deleteTime": "",
        "enable512e": false,
        "iqn": "iqn.2010-01.com.solidfire:0oto.test1.25",
        "name": "test1",
        "purgeTime": "",
        "qos": {
          "burstIOPS": 15000,
          "burstTime": 60,
          "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
          },
          "maxIOPS": 15000,
          "minIOPS": 50
        },
        "scsiEUIDeviceID": "306f746f00000019f47acc0100000000",
        "scsiNAADeviceID": "6f47acc100000000306f746f00000019",
        "sliceCount": 1,
        "status": "active",
        "totalSize": 1000341504,
        "virtualVolumeID": null,
        "volumeAccessGroups": [],
        "volumeID": 25,
        "volumePairs": []
      }
    ]
  }
}
```


ListVolumeStatsByAccount

You can use the `ListVolumeStatsByAccount` method to list high-level volume activity measurements for every account. Values are summed from all volumes owned by the account.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>includeVirtualVolumes</code>	Virtual volumes are included in the response by default. To exclude virtual volumes, set to <code>false</code> .	boolean	<code>true</code>	No
<code>accounts</code>	A list of account IDs for which to return volume statistics. If omitted, statistics for all accounts are returned.	integer array	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>volumeStats</code>	<p>List of volume activity information for each account.</p> <p>Note: The <code>volumeID</code> member is 0 for each entry, as the values represent the summation of all volumes owned by the account.</p>	<i>volumeStats</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumeStatsByAccount",
  "params": {"accounts": [3]},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeStats": [
      {
```

```

        "accountID": 3,
        "nonZeroBlocks": 155040175,
        "readBytes": 3156273328128,
        "readBytesLastSample": 0,
        "readOps": 770574543,
        "readOpsLastSample": 0,
        "samplePeriodMSec": 500,
        "timestamp": "2016-10-17T20:42:26.231661Z",
        "unalignedReads": 0,
        "unalignedWrites": 0,
        "volumeAccessGroups": [],
        "volumeID": 0,
        "volumeSize": 1127428915200,
        "writeBytes": 1051988406272,
        "writeBytesLastSample": 0,
        "writeOps": 256833107,
        "writeOpsLastSample": 0,
        "zeroBlocks": 120211025
    }
}
]
}

```

ListVolumeStatsByVirtualVolume

You can use the `ListVolumeStatsByVirtualVolume` method to list volume statistics for any volumes in the system that are associated with virtual volume. Statistics are cumulative from the creation of the volume.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>virtualVolumeIDs</code>	A list of one or more virtual volume IDs for which to retrieve information. If you specify this parameter, the method returns information about only these virtual volumes.	UUID string array	No	No

Return value

This method has the following return value:

Name	Description	Type
<code>volumeStats</code>	A list of objects containing activity information for each virtual volume in the system.	<i>volumeStats</i> array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListVolumeStatsByVirtualVolume",

```

```

    "params": {},
    "id": 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "volumeStats": [
      {
        "accountID": 17,
        "actualIOPS": 0,
        "asyncDelay": null,
        "averageIOPSize": 1074265444,
        "burstIOPSCredit": 0,
        "clientQueueDepth": 0,
        "desiredMetadataHosts": null,
        "latencyUsec": 0,
        "metadataHosts": {
          "deadSecondaries": [],
          "liveSecondaries": [
            26
          ],
          "primary": 56
        },
        "nonZeroBlocks": 36,
        "readBytes": 18366464,
        "readBytesLastSample": 0,
        "readLatencyUsec": 0,
        "readOps": 156,
        "readOpsLastSample": 0,
        "samplePeriodMsec": 500,
        "throttle": 0,
        "timestamp": "2016-10-10T17:46:35.914642Z",
        "unalignedReads": 156,
        "unalignedWrites": 185,
        "virtualVolumeID": "070ac0ba-f344-4f4c-b79c-142efa3642e8",
        "volumeAccessGroups": [],
        "volumeID": 12518,
        "volumeSize": 91271200768,
        "volumeUtilization": 0,
        "writeBytes": 23652213248,
        "writeBytesLastSample": 0,
        "writeLatencyUsec": 0,
        "writeOps": 185,
        "writeOpsLastSample": 0,
        "zeroBlocks": 22282972
      }
    ]
  }
}

```

ListVolumeStatsByVolume

You can use the `ListVolumeStatsByVolume` method to list high-level activity measurements for every volume, by volume. Values are cumulative from the creation of the volume.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
includeVirtualVolumes	Virtual volumes are included in the response by default. To exclude virtual volumes, set to false.	boolean	true	No

Return value

This method has the following return value:

Name	Description	Type
volumeStats	List of volume activity information.	<i>volumeStats</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumeStatsByVolume",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeStats": [
      {
        "accountID": 3,
        "actualIOPS": 0,
        "asyncDelay": null,
        "averageIOPSsize": 4096,
        "burstIOPSCredit": 30000,
        "clientQueueDepth": 0,
        "desiredMetadataHosts": null,
        "latencyUsec": 0,
        "metadataHosts": {
          "deadSecondaries": [],
          "liveSecondaries": [
            16
          ],
          "primary": 12
        },
        "nonZeroBlocks": 7499205,
        "readBytes": 159012818944,
        "readBytesLastSample": 0,
        "readLatencyUsec": 0,
        "readOps": 38821489,
        "readOpsLastSample": 0,
        "samplePeriodMsec": 500,
        "throttle": 0,
        "timestamp": "2016-10-17T20:55:31.087537Z",
        "unalignedReads": 0,
        "unalignedWrites": 0,
        "volumeAccessGroups": [

```

```

        1
      ],
      "volumeID": 1,
      "volumeSize": 53687091200,
      "volumeUtilization": 0,
      "writeBytes": 52992585728,
      "writeBytesLastSample": 0,
      "writeLatencyUSec": 0,
      "writeOps": 12937643,
      "writeOpsLastSample": 0,
      "zeroBlocks": 5607995
    }
  ]
}

```

ListVolumeStatsByVolumeAccessGroup

You can use the `ListVolumeStatsByVolumeAccessGroup` method to list total activity measurements for all of the volumes that are members of the specified volume access groups.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>includeVirtualVolumes</code>	Virtual volumes are included in the response by default. To exclude virtual volumes, set to <code>false</code> .	boolean	<code>true</code>	No
<code>volumeAccessGroups</code>	An array of <code>VolumeAccessGroupIDs</code> for which volume activity is returned. If omitted, statistics for all volume access groups are returned.	integer array	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>volumeStats</code>	<p>List of volume activity information for all volumes in the specified volume access group.</p> <p>Note: The <code>volumeID</code> member is 0 for each entry, because the values represent the summation of all volumes owned by the account.</p>	<i>volumeStats</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVolumeStatsByVolumeAccessGroup",
  "params": { "volumeAccessGroups": [1] },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeStats": [
      {
        "accountID": 0,
        "nonZeroBlocks": 149366393,
        "readBytes": 3156273328128,
        "readBytesLastSample": 0,
        "readOps": 770574543,
        "readOpsLastSample": 0,
        "samplePeriodMSec": 500,
        "timestamp": "2016-10-17T21:04:10.712370Z",
        "unalignedReads": 0,
        "unalignedWrites": 0,
        "volumeAccessGroups": [
          1
        ],
        "volumeID": 0,
        "volumeSize": 1073741824000,
        "writeBytes": 1051988406272,
        "writeBytesLastSample": 0,
        "writeOps": 256833107,
        "writeOpsLastSample": 0,
        "zeroBlocks": 112777607
      }
    ]
  }
}
```

ModifyBackupTarget

You can use the `ModifyBackupTarget` method to change attributes of a backup target.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
backupTargetID	Unique target ID for the target to modify.	integer	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON object	None	No

Name	Description	Type	Default value	Required
name	New name for the backup target.	string	None	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyBackupTarget",
  "params": {
    "backupTargetID" : 1,
    "name": "yourtargetS3"
    "attributes" : {
      "size" : 500,
    }
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

ModifyInitiators

You can use the `ModifyInitiators` method to change the attributes of one or more existing initiators.

You cannot change the name of an existing initiator. If you need to change the name of an initiator, delete it first with the [DeleteInitiators](#) method and create a new one with the [CreateInitiators](#) method.

If `ModifyInitiators` fails to change one of the initiators provided in the parameter, the method returns an error and does not modify any initiators (no partial completion is possible).

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
initiators	<p>A list of objects containing characteristics of each initiator to modify. Possible objects:</p> <ul style="list-style-type: none"> <code>initiatorID</code>: (Required) The ID of the initiator to modify. (integer) <code>alias</code>: (Optional) A new friendly name to assign to the initiator. (string) <code>attributes</code>: (Optional) A new set of JSON attributes to assign to the initiator. (JSON object) <code>volumeAccessGroupID</code>: (Optional) The ID of the volume access group to which the initiator should be added. If the initiator was previously in a different volume access group, it is removed from the old volume access group. If this key is present but null, the initiator is removed from its current volume access group, but not placed in any new volume access group. (integer) 	JSON object array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
initiators	List of objects describing the newly modified initiators.	<i>initiator</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "id": 6683,
  "method": "ModifyInitiators",
  "params": {
    "initiators": [
      {
        "initiatorID": 2,
        "alias": "alias1",
        "volumeAccessGroupID": null
      },
      {
        "initiatorID": 3,
        "alias": "alias2",
        "volumeAccessGroupID": 1
      }
    ]
  }
}
```



```

    }
  ]
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 6683,
  "result": {
    "initiators": [
      {
        "alias": "alias1",
        "attributes": {},
        "initiatorID": 2,
        "initiatorName": "iqn.1993-08.org.debian:01:395543635",
        "volumeAccessGroups": []
      },
      {
        "alias": "alias2",
        "attributes": {},
        "initiatorID": 3,
        "initiatorName": "iqn.1993-08.org.debian:01:935573135",
        "volumeAccessGroups": [
          1
        ]
      }
    ]
  }
}

```

Related references

[CreateInitiators](#) on page 342

[DeleteInitiators](#) on page 344

ModifyQoSPolicy

You can use the `ModifyQoSPolicy` method to modify an existing QoS policy on the system.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
qosPolicyID	The ID of the policy to be modified.	integer	None	Yes
name	If supplied, the name of the QoS policy (e.g. gold, platinum, silver) is changed to this value.	string	None	No

Name	Description	Type	Default value	Required
qos	If supplied, the QoS settings for this policy are changed to these settings. You can supply partial QoS values and only change some of the QoS settings.	QoS object	None	No

Return values

This method has the following return values:

Name	Description	Type
qosPolicy	Details of the newly modified QoS policy.	<i>QoSPolicy</i>

Request example

Requests for this method are similar to the following example:

```
{
  "id": 1950,
  "method": "ModifyQoSPolicy",
  "params": {
    "qosPolicyID": 2,
    "qos": {
      "minIOPS": 51,
      "maxIOPS": 15002,
      "burstIOPS": 15002
    }
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1950,
  "result": {
    "qosPolicy": {
      "name": "bronze",
      "qos": {
        "burstIOPS": 15002,
        "burstTime": 60,
        "curve": {
          "4096": 100,
          "8192": 160,
          "16384": 270,
          "32768": 500,
          "65536": 1000,
          "131072": 1950,
          "262144": 3900,
          "524288": 7600,
          "1048576": 15000
        }
      }
    },
  },
}
```

```

        "maxIOPS": 15002,
        "minIOPS": 51
    },
    "qosPolicyID": 2,
    "volumeIDs": [
        2
    ]
}
}
}

```

ModifyVolume

You can use the `ModifyVolume` method to modify settings on an existing volume. You can make modifications to one volume at a time and changes take place immediately.

If you do not specify QoS values when you modify a volume, they remain the same as before the modification. You can retrieve default QoS values for a newly created volume by running the `GetDefaultQoS` method.

When you need to increase the size of a volume that is being replicated, do so in the following order to prevent replication errors:

1. Increase the size of the volume with `replicationTarget` access.
2. Increase the size of the source or the volume with `readWrite` access.

Ensure that both the target and source volumes are the same size.

Note: If you change the access status to `locked` or `replicationTarget`, all existing iSCSI connections are terminated.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeID	The volumeID for the volume to be modified.	integer	None	Yes

Name	Description	Type	Default value	Required
access	<p>Access allowed for the volume. Possible values:</p> <ul style="list-style-type: none"> readOnly: Only read operations are allowed. readWrite: Reads and writes are allowed. locked: No reads or writes are allowed. If not specified, the access value does not change. replicationTarget: Identify a volume as the target volume for a paired set of volumes. If the volume is not paired, the access status is locked. If a value is not specified, the access value does not change. 	string	None	No
accountID	The accountID to which the volume is reassigned. If none is specified, the previous account name is used.	integer	None	No
associateWithQoS SPolicy	<p>Associate the volume with the specified QoS policy. Possible values:</p> <ul style="list-style-type: none"> true: Associate the volume with the QoS policy specified in the QoSPolicyID parameter. false: Do not associate the volume with the QoS policy specified in the QoSPolicyID parameter. When false, any existing policy association is removed, regardless of whether you specify a QoS policy in the QoSPolicy parameter. 	boolean	None	No
attributes	List of name-value pairs in JSON object format.	JSON object	None	No

Name	Description	Type	Default value	Required
createTime	An ISO 8601 date string to set as the new volume creation date. Required if setCreateTime is set to true.	ISO 8601 string	None	No
enableSnapMirrorReplication	Determines whether the volume can be used for replication with SnapMirror endpoints. Possible values: <ul style="list-style-type: none"> • true • false 	boolean	false	No
mode	Volume replication mode. Possible values: <ul style="list-style-type: none"> • <code>asynch</code>: Waits for system to acknowledge that data is stored on source before writing to the target. • <code>sync</code>: Does not wait for data transmission acknowledgment from source to begin writing data to the target. 	string	None	No
qos	The new quality of service settings for this volume. If not specified, the QoS settings are not changed. Possible values: <ul style="list-style-type: none"> • <code>minIOPS</code> • <code>maxIOPS</code> • <code>burstIOPS</code> 	<i>QoS</i>	None	No
qosPolicyID	The ID for the policy whose QoS settings should be applied to the specified volumes. This parameter is mutually exclusive with the <code>qos</code> parameter.	integer	None	No
setCreateTime	Set to <code>true</code> to change the recorded date of volume creation.	boolean	None	No

Name	Description	Type	Default value	Required
totalSize	The new size of the volume in bytes. 1000000000 is equal to 1GB. Size is rounded up to the nearest megabyte in size. This parameter can only be used to increase the size of a volume.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
volume	Object containing information about the newly modified volume.	<i>volume</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyVolume",
  "params": {
    "volumeID": 5,
    "attributes": {
      "name1": "value1",
      "name2": "value2",
      "name3": "value3"
    },
    "qos": {
      "minIOPS": 60,
      "maxIOPS": 100,
      "burstIOPS": 150,
      "burstTime": 60
    },
    "access": "readWrite"
  },
  "totalSize": 20000000000,
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volume": {
      "access": "readWrite",
      "accountID": 1,
      "attributes": {
        "name1": "value1",
        "name2": "value2",
        "name3": "value3"
      },
      "blockSize": 4096,
      "createTime": "2016-03-28T16:16:13Z",
      "deleteTime": "",
      "enable512e": true,

```

```

    "iqn": "iqn.2010-01.com.solidfire:jyay.1459181777648.5",
    "name": "1459181777648",
    "purgeTime": "",
    "qos": {
      "burstIOPS": 150,
      "burstTime": 60,
      "curve": {
        "4096": 100,
        "8192": 160,
        "16384": 270,
        "32768": 500,
        "65536": 1000,
        "131072": 1950,
        "262144": 3900,
        "524288": 7600,
        "1048576": 15000
      },
      "maxIOPS": 100,
      "minIOPS": 60
    },
    "scsiEUIDeviceID": "6a796179000000005f47acc0100000000",
    "scsiNAADeviceID": "6f47acc10000000006a796179000000005",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 1000341504,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
      1
    ],
    "volumeID": 5,
    "volumePairs": []
  }
}

```

Related references

[GetDefaultQoS](#) on page 354

ModifyVolumes

You can use the `ModifyVolumes` method to configure up to 500 existing volumes at one time. Changes take place immediately. If `ModifyVolumes` fails to modify any of the specified volumes, none of the specified volumes are changed.

If you do not specify QoS values when you modify volumes, the QoS values for each volume remain unchanged. You can retrieve default QoS values for a newly created volume by running the `GetDefaultQoS` method.

When you need to increase the size volumes that are being replicated, do so in the following order to prevent replication errors:

1. Increase the size of the volume with `replicationTarget` access.
2. Increase the size of the source or the volume with `readWrite` access.

Ensure that both the target and source volumes are the same size.

Note: If you change the access status to `locked` or `replicationTarget`, all existing iSCSI connections are terminated.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
access	<p>Access allowed for the volumes. Possible values:</p> <ul style="list-style-type: none"> readOnly: Only read operations are allowed. readWrite: Reads and writes are allowed. locked: No reads or writes are allowed. If not specified, the access value does not change. replicationTarget: Identify a volume as the target volume for a paired set of volumes. If the volume is not paired, the access status is locked. If a value is not specified, the access value does not change. 	string	None	No
accountID	The accountID to which the volumes are reassigned. If none is specified, the previous account name is used.	integer	None	No
associateWithQoSPolicy	<p>Associate the volume with the specified QoS policy. Possible values:</p> <ul style="list-style-type: none"> true: Associate the volume with the QoS policy specified in the QoSPolicyID parameter. false: Do not associate the volume with the QoS policy specified in the QoSPolicyID parameter. When false, any existing policy association is removed, regardless of whether you specify a QoS policy in the QoSPolicy parameter. 	boolean	None	No
attributes	List of name-value pairs in JSON object format.	JSON object	None	No

Name	Description	Type	Default value	Required
createTime	An ISO 8601 date string to set as the new volume creation date. Required if setCreateTime is set to true.	ISO 8601 string	None	No
enableSnapMirrorReplication	Determines whether the volume can be used for replication with SnapMirror endpoints. Possible values: <ul style="list-style-type: none"> • true • false 	boolean	false	No
mode	Volume replication mode. Possible values: <ul style="list-style-type: none"> • <code>asynch</code>: Waits for system to acknowledge that data is stored on source before writing to the target. • <code>sync</code>: Does not wait for data transmission acknowledgment from source to begin writing data to the target. 	string	None	No
qos	The new quality of service settings for the volumes. If not specified, the QoS settings are not changed. Possible values: <ul style="list-style-type: none"> • <code>minIOPS</code> • <code>maxIOPS</code> • <code>burstIOPS</code> 	<i>QoS</i>	None	No
qosPolicyID	The ID for the policy whose QoS settings should be applied to the specified volumes. This parameter is mutually exclusive with the <code>qos</code> parameter.	integer	None	No
setCreateTime	Set to true to change the recorded date of volume creation.	boolean	None	No

Name	Description	Type	Default value	Required
totalSize	The new size of the volumes in bytes. 10000000000 is equal to 1GB. Size is rounded up to the nearest megabyte in size. This parameter can only be used to increase the size of a volume.	integer	None	No
volumeIDs	A list of volumeIDs for the volumes to be modified.	integer array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
volume	An array of objects containing information about each newly modified volume.	<i>volume</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyVolumes",
  "params": {
    "volumeIDs": [2,3],
    "attributes": {
      "name1": "value1",
      "name2": "value2",
      "name3": "value3"
    },
    "qos": {
      "minIOPS": 50,
      "maxIOPS": 100,
      "burstIOPS": 150,
      "burstTime": 60
    },
    "access": "replicationTarget"
  },
  "totalSize": 80000000000,
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumes": [
      {
        "access": "replicationTarget",
        "accountID": 1,
        "attributes": {
          "name1": "value1",
```

```

        "name2": "value2",
        "name3": "value3"
    },
    "blockSize": 4096,
    "createTime": "2016-04-06T17:25:13Z",
    "deleteTime": "",
    "enable512e": false,
    "iqn": "iqn.2010-01.com.solidfire:jo73.2",
    "name": "doctest1",
    "purgeTime": "",
    "qos": {
        "burstIOPS": 150,
        "burstTime": 60,
        "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
        },
        "maxIOPS": 100,
        "minIOPS": 50
    },
    "scsiEUIDeviceID": "6a6f373300000002f47acc0100000000",
    "scsiNAADeviceID": "6f47acc1000000006a6f373300000002",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 1000341504,
    "virtualVolumeID": null,
    "volumeAccessGroups": [],
    "volumeID": 2,
    "volumePairs": []
},
{
    "access": "replicationTarget",
    "accountID": 1,
    "attributes": {
        "name1": "value1",
        "name2": "value2",
        "name3": "value3"
    },
    "blockSize": 4096,
    "createTime": "2016-04-06T17:26:31Z",
    "deleteTime": "",
    "enable512e": false,
    "iqn": "iqn.2010-01.com.solidfire:jo73.3",
    "name": "doctest2",
    "purgeTime": "",
    "qos": {
        "burstIOPS": 150,
        "burstTime": 60,
        "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
        },
        "maxIOPS": 100,
        "minIOPS": 50
    },
    "scsiEUIDeviceID": "6a6f373300000003f47acc0100000000",
    "scsiNAADeviceID": "6f47acc1000000006a6f373300000003",

```

```

        "sliceCount": 1,
        "status": "active",
        "totalSize": 1000341504,
        "virtualVolumeID": null,
        "volumeAccessGroups": [],
        "volumeID": 3,
        "volumePairs": []
    }
  ]
}

```

Related references

[GetDefaultQoS](#) on page 354

ModifyVolumeAccessGroup

You can use the `ModifyVolumeAccessGroup` method to update initiators and add or remove volumes from a volume access group.

If a specified initiator or volume is a duplicate of what currently exists, the volume access group is left as-is. If you do not specify a value for volumes or initiators, the current list of initiators and volumes is not changed.

You can also associate a virtual network with a volume access group. This association applies to all volumes in the volume access group.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>volumeAccessGroupID</code>	The ID of the volume access group to modify.	integer	None	Yes
<code>name</code>	The new name for this volume access group.	string	None	No
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object	None	No

Name	Description	Type	Default value	Required
<code>initiators</code>	List of initiator IDs or names (IQNs and WWPNS) to include in the volume access group. If you pass a list of initiator names, the initiators are created if they do not already exist. If you pass a list of initiator IDs, the method returns an error if any of the initiators does not already exist. Passing initiator names is deprecated; you should use initiator IDs whenever possible.	integer array (recommended) or string array (deprecated)	None	No
<code>deleteOrphanInitiators</code>	Specifies whether to delete initiator objects after they are removed from a volume access group or not. Possible values: <ul style="list-style-type: none"> <code>true</code>: Delete initiator objects after they are removed from a volume access group. <code>false</code>: Do not delete initiator objects after they are removed from a volume access group. 	boolean	<code>true</code>	No
<code>volumes</code>	A list of volume IDs of volumes to modify.	integer array	None	<i>volumeAccessGroup</i>

Return value

This method has the following return value:

Name	Description	Type
<code>volumeAccessGroup</code>	An object containing information about the newly modified volume access group.	<i>volumeAccessGroup</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyVolumeAccessGroup",
  "params": {
    "volumeAccessGroupID": 96,
    "name": "accessgrouptest",
    "initiators": [115,114],
    "volumes": [
      346
    ],
    "attributes": {}
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": null,
  "result": {
    "volumeAccessGroup": {
      "attributes": {},
      "deletedVolumes": [
        327
      ],
      "initiatorIDs": [
        114,
        115
      ],
      "initiators": [
        "iqn.1998-01.com.vmware:desk1-esx1-577b283a",
        "iqn.1998-01.com.vmware:donesq-esx1-421b281b"
      ],
      "name": "accessgrouptest",
      "volumeAccessGroupID": 96,
      "volumes": [
        346
      ]
    }
  }
}
```

Related references

[AddInitiatorsTo VolumeAccessGroup](#) on page 323

[AddVolumesTo VolumeAccessGroup](#) on page 325

[RemoveInitiatorsFrom VolumeAccessGroup](#) on page 401

[Remove VolumesFrom VolumeAccessGroup](#) on page 403

PurgeDeletedVolume

You can use the `PurgeDeletedVolume` method to immediately and permanently purge a volume that has been deleted. You must delete a volume using `DeleteVolume` before it can be purged.

Volumes are purged automatically after a period of time, so usage of this method is not typically required.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	The volumeID of the volume to be purged.	integer	No	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "PurgeDeletedVolume",
  "params": {
    "volumeID" : 5
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result": {}
}
```

Related references

[Delete Volume](#) on page 346

PurgeDeletedVolumes

You can use the `PurgeDeletedVolumes` method to immediately and permanently purge volumes that have been deleted; you can use this method to purge up to 500 volumes at one time.

You must delete volumes using `DeleteVolumes` before they can be purged. Volumes are purged automatically after a period of time, so usage of this method is not typically required.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeIDs	A list of volumeIDs of volumes to be purged from the system.	integer array	No	No

Name	Description	Type	Default value	Required
accountIDs	A list of accountIDs. All of the volumes from all of the specified accounts are purged from the system.	integer array	No	No
volumeAccessGroupIDs	A list of volumeAccessGroupIDs . All of the volumes from all of the specified volume access groups are purged from the system.	integer array	No	No

Note: You can specify only one of the above parameters per method call. Specifying more than one, or none, results in an error.

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "PurgeDeletedVolumes",
  "params": {
    "accountIDs" : [1, 2, 3]
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result": {}
}
```

Related references

[Delete Volumes](#) on page 348

RemoveBackupTarget

You can use the `RemoveBackupTarget` method to remove backup targets.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
backupTargetID	Unique target ID of the target to remove.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveBackupTarget",
  "params": {
    "backupTargetID" : 1
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

RemoveInitiatorsFromVolumeAccessGroup

You can use the `RemoveInitiatorsFromVolumeAccessGroup` method to remove initiators from a specified volume access group.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeAccessGroupID	The ID of the volume access group from which initiators are removed.	integer	None	Yes

Name	Description	Type	Default value	Required
<code>initiators</code>	List of initiator IDs or names (IQNs and WWPNs) to include in the volume access group. If you pass a list of initiator names, the initiators are created if they do not already exist. If you pass a list of initiator IDs, the method returns an error if any of the initiators does not already exist. Passing initiator names is deprecated; you should use initiator IDs whenever possible.	integer array (recommended) or string array (deprecated)	None	No
<code>deleteOrphanInitiators</code>	Specifies whether to delete initiator objects after they are removed from a volume access group or not. Possible values: <ul style="list-style-type: none"> <code>true</code>: Delete initiator objects after they are removed from a volume access group. <code>false</code>: Do not delete initiator objects after they are removed from a volume access group. 	boolean	<code>true</code>	No

Return value

This method has the following return value:

Name	Description	Type
volumeAccessGroup	An object containing information about the newly modified volume access group.	<i>volumeAccessGroup</i>

Request example

Requests for this method are similar to the following example:

```
{
  "id": 13171,
  "method": "RemoveInitiatorsFromVolumeAccessGroup",
  "params": {
    "initiators": [114,115],
    "volumeAccessGroupID": 96
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 13171,
  "result": {
    "volumeAccessGroup": {
      "attributes": {},
      "deletedVolumes": [
        327
      ],
      "initiatorIDs": [],
      "initiators": [],
      "name": "northbanktest",
      "volumeAccessGroupID": 96,
      "volumes": [
        346
      ]
    }
  }
}
```

RemoveVolumesFromVolumeAccessGroup

You can use the `RemoveVolumesFromVolumeAccessGroup` method to remove volumes from a specified volume access group.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeAccessGroupID	VolumeAccessGroupID to remove volumes from.	integer	None	Yes

Name	Description	Type	Default value	Required
volumes	VolumeIDs of volumes to remove from the volume access group.	integer array	None	Yes

Return value

This method has the following return value:

Name	Description	Type
volumeAccessGroup	An object containing information about the newly modified volume access group.	<i>volumeAccessGroup</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RemoveVolumesFromVolumeAccessGroup",
  "params": {
    "volumeAccessGroupID": 96,
    "volumes": [1,2]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeAccessGroup": {
      "attributes": {},
      "deletedVolumes": [
        346
      ],
      "initiatorIDs": [
        116,
        117
      ],
      "initiators": [
        "iqn.1993-08.org.debian:01:181324777",
        "iqn.1993-08.org.debian:01:181324888"
      ],
      "name": "northbanktest",
      "volumeAccessGroupID": 96,
      "volumes": []
    }
  }
}
```

RestoreDeletedVolume

You can use the `RestoreDeletedVolume` method to mark a deleted volume as active again. This action makes the volume immediately available for iSCSI connection.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeID	The volumeID of the deleted volume to restore.	integer	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RestoreDeletedVolume",
  "params": {
    "volumeID" : 5
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result": {}
}
```

SetDefaultQoS

You can use the `SetDefaultQoS` method to configure the default Quality of Service (QoS) values (measured in inputs and outputs per second, or IOPS) for a volume.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
minIOPS	The minimum number of sustained IOPS that are provided by the cluster to a volume.	integer	None	No

Name	Description	Type	Default value	Required
maxIOPS	The maximum number of sustained IOPS that are provided by the cluster to a volume.	integer	None	No
burstIOPS	The maximum number of IOPS allowed in a short burst scenario.	integer	None	No

Return values

This method has the following return values:

Name	Description	Type
minIOPS	The minimum number of sustained IOPS that are provided by the cluster to a volume.	integer
maxIOPS	The maximum number of sustained IOPS that are provided by the cluster to a volume.	integer
burstIOPS	The maximum number of IOPS allowed in a short burst scenario.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "SetDefaultQoS",
  "params": {
    "burstIOPS": 8000,
    "maxIOPS": 1000,
    "minIOPS": 200
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "burstIOPS": 8000,
    "maxIOPS": 1000,
    "minIOPS": 200
  }
}
```

StartBulkVolumeRead

You can use the `StartBulkVolumeRead` method to start a bulk volume read session on a specified volume.

Only two bulk volume processes can run simultaneously on a volume. When you initialize the session, data is read from a SolidFire storage volume to be stored on an external backup source. The external data is accessed by a web server running on an Element storage node. Server interaction information for external data access is passed by a script running on the storage system.

At the start of a bulk volume read operation, a snapshot of the volume is made and the snapshot is deleted when the read has completed. You can also read a snapshot of the volume by entering the ID of the snapshot as a parameter. When you read a previous snapshot, the system does not create a new snapshot of the volume, nor does it delete the previous snapshot when the read completes.

Note: This process creates a new snapshot if the ID of an existing snapshot is not provided. Snapshots can be created if cluster fullness is at stage 2 or 3. Snapshots are not created when cluster fullness is at stage 4 or 5.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>format</code>	The format of the volume data. Can be either: <ul style="list-style-type: none"> <code>uncompressed</code>: Every byte of the volume is returned without any compression. <code>native</code>: Opaque data is returned that is smaller and more efficiently stored and written on a subsequent bulk volume write. 	string	None	Yes
<code>volumeID</code>	The ID of the volume to be read.	integer	None	Yes
<code>snapshotID</code>	The ID of a previously created snapshot used for bulk volume reads. If no ID is entered, a snapshot of the current active volume image is made.	integer	None	No

Name	Description	Type	Default value	Required
script	The name of an executable script. If no script name is given, the key and URL are necessary to access Element storage nodes. The script is run on the primary node, and the key and URL are returned to the script so the local web server can be contacted.	string	None	No
scriptParameters	JSON parameters to pass to the script.	JSON object	None	No
attributes	JSON attributes for the bulk volume job.	JSON object	None	No

Return values

This method has the following return values:

Name	Description	Type
asyncHandle	The ID of the asynchronous process to be checked for completion.	integer
key	Opaque key uniquely identifying the session.	string
url	URL to access the node's web server.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "StartBulkVolumeRead",
  "params": {
    "volumeID" : 5,
    "format" : "native",
    "snapshotID" : 2
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "asyncHandle" : 1,
    "key" : "11eed8f086539205beeaadd981aad130",
    "url" : "https://127.0.0.1:44000/"
  }
}
```



```

    }
}

```

StartBulkVolumeWrite

You can use the `StartBulkVolumeWrite` method to start a bulk volume write session on a specified volume.

Only two bulk volume processes can run simultaneously on a volume. When you initialize the session, data is written to an Element storage volume from an external backup source. The external data is accessed by a web server running on an Element storage node. Server interaction information for external data access is passed by a script running on the storage system.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>format</code>	The format of the volume data. Can be either: <ul style="list-style-type: none"> <code>uncompressed</code>: Every byte of the volume is returned without any compression. <code>native</code>: Opaque data is returned that is smaller and more efficiently stored and written on a subsequent bulk volume write. 	string	None	Yes
<code>volumeID</code>	The ID of the volume to be written to.	integer	None	Yes
<code>script</code>	The name of an executable script. If no script name is given, the key and URL are necessary to access Element storage nodes. The script is run on the primary node, and the key and URL are returned to the script so the local web server can be contacted.	string	None	No
<code>scriptParameters</code>	JSON parameters to pass to the script.	JSON object	None	No
<code>attributes</code>	JSON attributes for the bulk volume job.	JSON object	None	No

Return values

This method has the following return values:

Name	Description	Type
asyncHandle	The ID of the asynchronous process to be checked for completion.	integer
key	Opaque key uniquely identifying the session.	string
url	URL to access the node's web server.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "StartBulkVolumeWrite",
  "params": {
    "volumeID" : 5,
    "format" : "native",
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "asyncHandle" : 1,
    "key" : "11eed8f086539205beeaadd981aad130",
    "url" : "https://127.0.0.1:44000/"
  }
}
```

UpdateBulkVolumeStatus

You can use the `UpdateBulkVolumeStatus` method to update the status of a bulk volume job that you started with the `StartBulkVolumeRead` or `StartBulkVolumeWrite` methods.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
key	The key assigned during initialization of a StartBulkVolumeRead or StartBulkVolumeWrite session.	string	None	Yes

Name	Description	Type	Default value	Required
status	The system sets the status of the given bulk volume job. Possible values: <ul style="list-style-type: none"> running: Jobs that are still active. complete: Jobs that are done. failed: Jobs that have failed. 	string	None	Yes
percentComplete	The completed progress of the bulk volume job as a percentage.	string	None	No
message	Returns the status of the bulk volume job when the job has completed.	string	None	No
attributes	JSON attributes; updates what is on the bulk volume job.	JSON object	None	No

Return values

This method has the following return values:

Name	Description	Type
status	Status of the session requested. Returned status: <ul style="list-style-type: none"> preparing active done failed 	string
attributes	Returns attributes that were specified in the method call. Values are returned whether they have changed or not.	string
url	The URL to access the node's web server; provided only if the session is still active.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "UpdateBulkVolumeStatus",
  "params": {
    "key": "0b2f532123225febda2625f55dcb0448",
    "status": "running"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result": {
    "status" : "running",
    "url" : "https://10.10.23.47:8443/"
  }
}
```

Related references

[StartBulk VolumeRead](#) on page 407

[StartBulk VolumeWrite](#) on page 409

Volume snapshot API methods

Element software volume snapshot API methods enable you to manage volume snapshots. You can create, modify, clone, and delete volume snapshots using the volume snapshot API methods.

Snapshots overview

A volume snapshot is a point-in-time copy of a volume. You can use snapshots to roll a volume back to the state it was in at the time the snapshot was created.

You can group volume snapshots together so that related volumes can be backed up or rolled back in a consistent manner. A group snapshot captures a point-in-time image of all volume slice files. You can then use the image to roll back a group of volumes to a point-in-time state and ensure that all data is consistent across all volumes in the group.

You can schedule volume snapshots to occur autonomously at defined intervals. You can define intervals by time, days of the week, or days of the month. You can also use scheduled snapshots to ensure snapshots are backed up to remote storage for archiving purposes.

CreateGroupSnapshot

You can use `CreateGroupSnapshot` to create a point-in-time copy of a group of volumes.

You can use this snapshot later as a backup or rollback to ensure the data on the group of volumes is consistent for the point in time that you created the snapshot.

Note: You can create snapshots if cluster fullness is at stage 1, 2, or 3. You cannot create snapshots when cluster fullness reaches stage 4 or 5.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object	None	No
<code>enableRemoteReplication</code>	Specifies whether the snapshot will be replicated to remote storage or not. Possible values: <ul style="list-style-type: none"> <code>true</code>: The snapshot will be replicated to remote storage. <code>false</code>: The snapshot will not be replicated to remote storage. 	boolean	<code>false</code>	No

Name	Description	Type	Default value	Required
name	The name of the group snapshot. If no name is entered, the date and time the group snapshot was taken is used. The maximum name length allowed is 255 characters.	string	None	No
retention	The amount of time the snapshot will be retained. If left empty, the snapshot is retained forever. Enter in the HH:mm:ss format.	string	None	No
snapMirrorLabel	The label used by SnapMirror software to specify the snapshot retention policy on a SnapMirror endpoint.	string	None	No
volumes	Unique ID of the volume image from which to copy.	volumeID array	None	Yes

Return values

This method has the following return values:

Name	Description	Type
members	<p>List of checksum, volumeIDs, and snapshotIDs for each member of the group. Valid values:</p> <ul style="list-style-type: none"> checksum: A small string representation of the data in the stored snapshot. This checksum can be used later to compare other snapshots to detect errors in the data. (string) snapshotID: Unique ID of a snapshot from which the new snapshot is made. The snapshotID must be from a snapshot on the given volume. (integer) volumeID: The source volume ID for the snapshot. (integer) 	JSON object array
groupSnapshotID	Unique ID of the new group snapshot.	groupSnapshot ID
groupSnapshot	Object containing information about the newly created group snapshot.	<i>groupSnapshot</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateGroupSnapshot",
  "params": {
    "volumes": [1,2]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "groupSnapshot": {
      "attributes": {},
      "createTime": "2016-04-04T22:43:29Z",
      "groupSnapshotID": 45,
      "groupSnapshotUUID": "473b78a3-ef85-4541-9438-077306b2d3ca",
      "members": [
        {
          "attributes": {},

```

```

        "checksum": "0x0",
        "createTime": "2016-04-04T22:43:29Z",
        "enableRemoteReplication": false,
        "expirationReason": "None",
        "expirationTime": null,
        "groupID": 45,
        "groupSnapshotUUID": "473b78a3-ef85-4541-9438-077306b2d3ca",
        "name": "2016-04-04T22:43:29Z",
        "snapshotID": 3323,
        "snapshotUUID": "7599f200-0092-4b41-b362-c431551937d1",
        "status": "done",
        "totalSize": 5000658944,
        "virtualVolumeID": null,
        "volumeID": 1
    },
    {
        "attributes": {},
        "checksum": "0x0",
        "createTime": "2016-04-04T22:43:29Z",
        "enableRemoteReplication": false,
        "expirationReason": "None",
        "expirationTime": null,
        "groupID": 45,
        "groupSnapshotUUID": "473b78a3-ef85-4541-9438-077306b2d3ca",
        "name": "2016-04-04T22:43:29Z",
        "snapshotID": 3324,
        "snapshotUUID": "a0776a48-4142-451f-84a6-5315dc37911b",
        "status": "done",
        "totalSize": 6001000448,
        "virtualVolumeID": null,
        "volumeID": 2
    }
],
"name": "2016-04-04T22:43:29Z",
"status": "done"
},
"groupSnapshotID": 45,
"members": [
    {
        "checksum": "0x0",
        "snapshotID": 3323,
        "snapshotUUID": "7599f200-0092-4b41-b362-c431551937d1",
        "volumeID": 1
    },
    {
        "checksum": "0x0",
        "snapshotID": 3324,
        "snapshotUUID": "a0776a48-4142-451f-84a6-5315dc37911b",
        "volumeID": 2
    }
]
}
}

```

CreateSchedule

You can use `CreateSchedule` to schedule an automatic snapshot of a volume at a defined interval.

You can use the created snapshot later as a backup or rollback to ensure the data on a volume or group of volumes is consistent for the point in time in which the snapshot was created. If you schedule a snapshot to run at a time period that is not divisible by 5 minutes, the snapshot will run at the next time period that is divisible by 5 minutes. For example, if you schedule a snapshot to run at 12:42:00 UTC, it will run at 12:45:00 UTC. You cannot schedule a snapshot to run at intervals of less than 5 minutes.

Note: You can create snapshots if cluster fullness is at stage 1, 2, or 3. You cannot create snapshots when cluster fullness reaches stage 4 or 5.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
attributes	Use the “frequency” string to indicate the frequency of the snapshot. Possible values: <ul style="list-style-type: none"> Days of Week Days of Month Time Interval 	JSON object	None	No
hours	Number of hours between recurring snapshots or hour in GMT time that the snapshot will occur in Days of Week or Days of Month mode. Valid values are 0 through 23.	integer	None	No
name	The name of the snapshot. If no name is entered, the date and time the group snapshot was taken is used. The maximum name length allowed is 244 characters.	string	None	No
minutes	Number of minutes between recurring snapshots or the minute in GMT time that the snapshot will occur in Days of Week or Days of Month mode. Valid values are 5 through 59.	integer	None	No
paused	Indicates if the schedule should be paused or not. Valid values: <ul style="list-style-type: none"> true false 	boolean	None	No
recurring	Indicates if the schedule will be recurring or not. Valid values are: <ul style="list-style-type: none"> true false 	boolean	None	No

Name	Description	Type	Default value	Required
scheduleName	Unique name for the schedule. The maximum schedule name length allowed is 244 characters.	string	None	Yes
scheduleType	Indicates the type of schedule to create. Valid value is snapshot.	string	None	Yes
scheduleInfo	<p>An object of schedule information about how the snapshot should be created at each scheduled interval.</p> <ul style="list-style-type: none"> volumeID: The ID of the volume to be included in the snapshot. (integer) volumes: A list of volume IDs to be included in the group snapshot. (integer array) name: The snapshot name to be used. (string) enableRemoteReplication: Indicates if the snapshot should be included in remote replication. (boolean) retention: The amount of time the snapshot will be retained in HH:mm:ss. (string) 	JSON object	None	Yes
snapMirrorLabel	The label used by SnapMirror software to specify the snapshot retention policy on a SnapMirror endpoint.	string	None	No
startingDate	Time after which the schedule will be run. If not set, the schedule starts immediately. Formatted in UTC time.	ISO 8601 date string	None	No
monthdays	The days of the month that a snapshot will be made. Valid values are 1 through 31.	integer array	None	Yes (if scheduling for days of the month)

Name	Description	Type	Default value	Required
weekdays	Day of the week the snapshot is to be created. Required values (if used): <ul style="list-style-type: none"> Day: 0 through 6 (Sunday through Saturday) Offset: 1 	JSON object array	None	Yes (if scheduling for days of the week)

Return values

This method has the following return values:

Name	Description	Type
scheduleID	ID of the schedule created.	integer
schedule	An object containing information about the newly created schedule.	schedule

Request example 1

The following example schedule has the following parameters:

- No start hours or minutes are specified so the schedule starts as closely as possible to midnight (00:00:00Z).
- It is not recurring (will only run once).
- It runs once on either the first Sunday or Wednesday following June 1, 2015, UTC 19:17:15Z (whichever day comes first).
- It includes only one volume (volumeID = 1).

```
{
  "method": "CreateSchedule",
  "params": {
    "hours": 0,
    "minutes": 0,
    "paused": false,
    "recurring": false,
    "scheduleName": "MCASnapshot1",
    "scheduleType": "snapshot",
    "attributes": {
      "frequency": "Days Of Week"
    },
    "scheduleInfo": {
      "volumeID": "1",
      "name": "MCA1"
    },
    "monthdays": [],
    "weekdays": [
      {
        "day": 0,
        "offset": 1
      },
      {
        "day": 3,
        "offset": 1
      }
    ]
  }
}
```

```

    }
  ],
  "startingDate": "2015-06-01T19:17:54Z"
},
"scheduleID": 1
}
}
}

```

Response example 1

The above request returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "schedule": {
      "attributes": {
        "frequency": "Days Of Week"
      },
      "hasError": false,
      "hours": 0,
      "lastRunStatus": "Success",
      "lastRunTimeStarted": null,
      "minutes": 0,
      "monthdays": [],
      "paused": false,
      "recurring": false,
      "runNextInterval": false,
      "scheduleID": 4,
      "scheduleInfo": {
        "name": "MCA1",
        "volumeID": "1"
      },
      "scheduleName": "MCASnapshot1",
      "scheduleType": "Snapshot",
      "startingDate": "2015-06-01T19:17:54Z",
      "toBeDeleted": false,
      "weekdays": [
        {
          "day": 0,
          "offset": 1
        },
        {
          "day": 3,
          "offset": 1
        }
      ]
    },
    "scheduleID": 4
  }
}

```

Request example 2

The following example schedule has the following parameters:

- It is recurring (will run at each scheduled interval of the month at the specified time).
- It runs on the 1st, 10th, 15th and 30th of each month following the starting date.
- It runs at 12:15 PM on each day it is scheduled to occur.
- It includes only one volume (volumeID = 1).

```

{
  "method": "CreateSchedule",
  "params": {

```

```

    "hours":12,
    "minutes":15,
    "paused":false,
    "recurring":true,
    "scheduleName":"MCASnapshot1",
    "scheduleType":"snapshot",
    "attributes":{
      "frequency":"Days Of Month"
    },
    "scheduleInfo":{
      "volumeID":"1"
    },
    "weekdays":[
    ],
    "monthdays":[
      1,
      10,
      15,
      30
    ],
    "startingDate":"2015-04-02T18:03:15Z"
  },
  "id":1
}

```

Response example 2

The above request returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "schedule": {
      "attributes": {
        "frequency": "Days Of Month"
      },
      "hasError": false,
      "hours": 12,
      "lastRunStatus": "Success",
      "lastRunTimeStarted": null,
      "minutes": 15,
      "monthdays": [
        1,
        10,
        15,
        30
      ],
      "paused": false,
      "recurring": true,
      "runNextInterval": false,
      "scheduleID": 5,
      "scheduleInfo": {
        "volumeID": "1"
      },
      "scheduleName": "MCASnapshot1",
      "scheduleType": "Snapshot",
      "startingDate": "2015-04-02T18:03:15Z",
      "toBeDeleted": false,
      "weekdays": []
    },
    "scheduleID": 5
  }
}

```

Request example 3

The following example schedule has the following parameters:

- It starts within 5 minutes of the scheduled interval on April 2, 2015.
- It is recurring (will run at each scheduled interval of the month at the specified time).
- It runs on the second, third, and fourth of each month following the starting date.
- It runs at 14:45 PM on each day it is scheduled to occur.
- It includes a group of volumes (volumes = 1 and 2).

```
{
  "method": "CreateSchedule",
  "params": {
    "hours": 14,
    "minutes": 45,
    "paused": false,
    "recurring": true,
    "scheduleName": "MCASnapUser1",
    "scheduleType": "snapshot",
    "attributes": {
      "frequency": "Days Of Month"
    },
    "scheduleInfo": {
      "volumes": [1, 2]
    },
    "weekdays": [],
    "monthdays": [2, 3, 4],
    "startingDate": "2015-04-02T20:38:23Z"
  },
  "id": 1
}
```

Response example 3

The above request returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "schedule": {
      "attributes": {
        "frequency": "Days Of Month"
      },
      "hasError": false,
      "hours": 14,
      "lastRunStatus": "Success",
      "lastRunTimeStarted": null,
      "minutes": 45,
      "monthdays": [
        2,
        3,
        4
      ],
      "paused": false,
      "recurring": true,
      "runNextInterval": false,
      "scheduleID": 6,
      "scheduleInfo": {
        "volumes": [
          1,
          2
        ]
      },
      "scheduleName": "MCASnapUser1",
      "scheduleType": "Snapshot",
      "startingDate": "2015-04-02T20:38:23Z",
      "toBeDeleted": false,
      "weekdays": []
    }
  }
}
```

```

    },
    "scheduleID": 6
  }
}

```

CreateSnapshot

You can use `CreateSnapshot` to create a point-in-time copy of a volume. You can create a snapshot from any volume or from an existing snapshot.

If you do not provide a `SnapshotID` with this API method, a snapshot is created from the volume's active branch. If the volume from which the snapshot is created is being replicated to a remote cluster, the snapshot can also be replicated to the same target. Use the `enableRemoteReplication` parameter to enable snapshot replication.

Note: You can create snapshots if cluster fullness is at stage 1, 2, or 3. You cannot create snapshots when cluster fullness reaches stage 4 or 5.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>attributes</code>	List of name-value pairs in JSON object format.	JSON object	None	No
<code>enableRemoteReplication</code>	Specifies whether the snapshot will be replicated to remote storage or not. Possible values: <ul style="list-style-type: none"> <code>true</code>: The snapshot will be replicated to remote storage. <code>false</code>: The snapshot will not be replicated to remote storage. 	boolean	<code>false</code>	No
<code>name</code>	The name of the snapshot. If no name is entered, the date and time the snapshot was taken is used. The maximum name length allowed is 255 characters.	string	None	No

Name	Description	Type	Default value	Required
retention	The amount of time the snapshot will be retained. If left empty, the snapshot is retained forever. Enter in the HH:mm:ss format.	string	None	No
snapMirrorLabel	The label used by SnapMirror software to specify the snapshot retention policy on a SnapMirror endpoint.	string	None	No
snapshotID	Unique ID of a snapshot from which the new snapshot is made. The snapshotID passed must be a snapshot on the given volume.	integer	None	No
volumeID	Unique ID of the volume image from which to copy.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
checksum	A string that represents the correct digits in the stored snapshot. This checksum can be used later to compare other snapshots to detect errors in the data.	string
snapshotID	Unique ID of the new snapshot.	Snapshot ID
snapshot	An object containing information about the newly created snapshot.	<i>snapshot</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateSnapshot",
  "params": {
    "volumeID": 1
  },
}
```



```
{
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "checksum": "0x0",
    "snapshot": {
      "attributes": {},
      "checksum": "0x0",
      "createTime": "2016-04-04T17:14:03Z",
      "enableRemoteReplication": false,
      "expirationReason": "None",
      "expirationTime": null,
      "groupID": 0,
      "groupSnapshotUUID": "00000000-0000-0000-0000-000000000000",
      "name": "2016-04-04T17:14:03Z",
      "snapshotID": 3110,
      "snapshotUUID": "6f773939-c239-44ca-9415-1567eae79646",
      "status": "done",
      "totalSize": 5000658944,
      "virtualVolumeID": null,
      "volumeID": 1
    },
    "snapshotID": 3110
  }
}
```

DeleteGroupSnapshot

You can use `DeleteGroupSnapshot` to delete a group snapshot.

You can use the `saveMembers` parameter to preserve all the snapshots that were made for the volumes in the group, but the group association will be removed.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>groupSnapshotID</code>	Unique ID of the group snapshot.	integer	None	Yes
<code>saveMembers</code>	Specifies what to delete when you delete a group snapshot. Valid values: <ul style="list-style-type: none"> <code>true</code>: Snapshots are kept, but the group association is removed. <code>false</code>: The group and snapshots are deleted. 	boolean	<code>false</code>	No

Return value

This method has no return value.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteGroupSnapshot",
  "params": {
    "groupSnapshotID": 10,
    "saveMembers" : true
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

DeleteSnapshot

You can use the `DeleteSnapshot` method to delete a snapshot.

A snapshot that is currently the active snapshot cannot be deleted. You must rollback and make another snapshot active before the current snapshot can be deleted.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
snapshotID	The ID of the snapshot to delete.	integer	None	Yes
overrideSnapMirrorHold	Override the lock placed on snapshots during replication. You can use this parameter to delete stale SnapMirror snapshots after the associated SnapMirror relationship has been deleted.	boolean	false	No

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "DeleteSnapshot",
  "params": {
    "snapshotID": 8,
    "overrideSnapMirrorHold": true
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

Related references

[RollbackToSnapshot](#) on page 443

GetSchedule

You can use `GetSchedule` to get information about a scheduled snapshot.

You can see information about a specific schedule if there are many snapshot schedules in the system. You also retrieve information about more than one schedule with this method by specifying additional IDs in the `scheduleID` parameter.

Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
scheduleID	Unique ID of the schedule or multiple schedules to display.	integer	None	Yes

Return value

This method has the following return value:

Name	Description	Type
schedule	An array of schedule attributes.	schedule array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetSchedule",
  "params": {
```

```

        "scheduleID" : 2
      },
      "id" : 1
    }
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "schedule": {
      "attributes": {
        "frequency": "Time Interval"
      },
      "hasError": false,
      "hours": 0,
      "lastRunStatus": "Success",
      "lastRunTimeStarted": "2015-03-23T21:25:00Z",
      "minutes": 2,
      "monthdays": [],
      "paused": false,
      "recurring": true,
      "runNextInterval": false,
      "scheduleID": 2,
      "scheduleInfo": {
        "name": "MCA2",
        "volumeID": "3"
      },
      "scheduleName": "MCAsnapshot2",
      "scheduleType": "Snapshot",
      "startingDate": "2015-03-23T19:28:57Z",
      "toBeDeleted": false,
      "weekdays": []
    }
  }
}

```

ListGroupSnapshots

You can use `ListGroupSnapshots` method to return information about all group snapshots that have been created.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumes	An array of unique volume IDs to query. If you do not specify this parameter, all group snapshots on the cluster are included.	volumeID array	None	No
groupSnapshotID	Retrieve information for an individual group snapshot ID.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
groupSnapshots	A list of objects containing information about each group snapshot.	<i>groupSnapshot</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListGroupSnapshots",
  "params": {
    "volumes": [
      31,
      49
    ]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "groupSnapshots": [
      {
        "attributes": {},
        "createTime": "2014-06-17T17:35:05Z",
        "groupSnapshotID": 5,
        "groupSnapshotUUID": "6f02941b-08e7-4463-a2a9-1adbd260b607",
        "members": [
          {
            "checksum" : "0x9d0815a7d9f0fa38",
            "snapshotID" : 4,
            "snapshotUUID": "ee33d408-0be2-479c-a9f7-d126742b9c33",
            "volumeID" : 31
          },
          {
            "checksum" : "0x15d7a7383ed0501f",
            "snapshotID" : 5,
            "snapshotUUID": "761ec3b6-217b-43dc-b66b-b6b71849f601",
            "volumeID" : 49
          }
        ]
      },
      {
        "name" : "group-snapshot49",
        "status" : "done"
      }
    ]
  }
}
```

ListSchedules

You can use `ListSchedules` to get information about all scheduled snapshots that have been created.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
schedules	A list of the schedules currently on the cluster.	<i>schedule</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListSchedules",
  "params": {},
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "schedules": [
      {
        "attributes": {
          "frequency": "Days Of Week"
        },
        "hasError": false,
        "hours": 0,
        "lastRunStatus": "Success",
        "lastRunTimeStarted": null,
        "minutes": 1,
        "monthdays": [],
        "paused": false,
        "recurring": false,
        "runNextInterval": false,
        "scheduleID": 3,
        "scheduleInfo": {
          "name": "Wednesday Schedule",
          "retention": "00:02:00",
          "volumeID": "2"
        },
        "scheduleName": "Vol2Schedule",
        "scheduleType": "Snapshot",
        "startingDate": "2015-03-23T20:08:33Z",
        "toBeDeleted": false,
        "weekdays": [
          {
            "day": 3,
            "offset": 1
          }
        ]
      }
    ]
  }
}
```

```

    }
  ],
  {
    "attributes": {
      "frequency": "Time Interval"
    },
    "hasError": false,
    "hours": 0,
    "lastRunStatus": "Success",
    "lastRunTimeStarted": "2015-03-23T21:40:00Z",
    "minutes": 2,
    "monthdays": [],
    "paused": false,
    "recurring": true,
    "runNextInterval": false,
    "scheduleID": 2,
    "scheduleInfo": {
      "name": "MCA2",
      "volumeID": "3"
    },
    "scheduleName": "MCASnapshot2",
    "scheduleType": "Snapshot",
    "startingDate": "2015-03-23T19:28:57Z",
    "toBeDeleted": false,
    "weekdays": []
  }
]
}

```

ListSnapshots

You can use `ListSnapshots` to return the attributes of each snapshot taken on the volume.

Information about snapshots that reside on the target cluster will be displayed on the source cluster when this method is called from the source cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeID	Retrieves snapshots for a volume. If volumeID is not provided, all snapshots for all volumes are returned.	integer	None	No
snapshotID	Retrieves information for an individual snapshot ID.	integer	None	No

Return value

This method has the following return value:

Name	Description	Type
snapshots	Information about each snapshot for each volume. If volumeID is not provided, all snapshots for all volumes are returned. Snapshots that are in a group are returned with a group ID.	<i>snapshot</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListSnapshots",
  "params": {
    "volumeID": "1"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "snapshots": [
      {
        "attributes": {},
        "checksum": "0x0",
        "createTime": "2015-05-08T13:15:00Z",
        "enableRemoteReplication": true,
        "expirationReason": "None",
        "expirationTime": "2015-05-08T21:15:00Z",
        "groupID": 0,
        "groupSnapshotUUID": "00000000-0000-0000-0000-000000000000",
        "name": "Hourly",
        "remoteStatuses": [
          {
            "remoteStatus": "Present",
            "volumePairUUID": "237e1cf9-fb4a-49de-a089-a6a9a1f0361e"
          }
        ],
        "snapshotID": 572,
        "snapshotUUID": "efa98e40-cb36-4c20-a090-a36c48296c14",
        "status": "done",
        "totalSize": 10000269312,
        "volumeID": 1
      }
    ]
  }
}
```


ModifyGroupSnapshot

You can use `ModifyGroupSnapshot` to change the attributes of a group of snapshots. You can also use this method to enable snapshots created on the read/write (source) volume to be remotely replicated to a target storage system.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>enableRemoteReplication</code>	Use to enable the snapshot created to be replicated to a remote cluster. Possible values: <ul style="list-style-type: none"> <code>true</code>: The snapshot will be replicated to remote storage. <code>false</code>: The snapshot will not be replicated to remote storage. 	boolean	false	No
<code>expirationTime</code>	Use to set the time when the snapshot should be removed. If no time is entered, the current time will be used. When set to "null", the snapshot never expires.	ISO 8601 date string	None	No
<code>name</code>	The name of the group snapshot. If no name is entered, the date and time the group snapshot was taken is used. The maximum name length allowed is 255 characters.	string	None	No
<code>groupSnapshotID</code>	The ID of the group of snapshots.	string	None	Yes
<code>snapMirrorLabel</code>	The label used by SnapMirror software to specify the snapshot retention policy on a SnapMirror endpoint.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
groupSnapshot	Object containing information about the newly modified group snapshot.	<i>groupSnapshot</i>

Request example

Requests for this method are similar to the following example:

```
{
  "id": 695,
  "method": "ModifyGroupSnapshot",
  "params": {
    "groupSnapshotID": 3,
    "enableRemoteReplication": true,
    "expirationTime": "2016-04-08T22:46:25Z"
  }
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 695,
  "result": {
    "groupSnapshot": {
      "attributes": {},
      "createTime": "2016-04-06T17:31:41Z",
      "groupSnapshotID": 3,
      "groupSnapshotUUID": "8b2e101d-c5ab-4a72-9671-6f239de49171",
      "members": [
        {
          "attributes": {},
          "checksum": "0x0",
          "createTime": "2016-04-06T17:31:41Z",
          "enableRemoteReplication": true,
          "expirationReason": "None",
          "expirationTime": "2016-04-08T22:46:25Z",
          "groupID": 3,
          "groupSnapshotUUID": "8b2e101d-c5ab-4a72-9671-6f239de49171",
          "name": "grpsnap1-2",
          "snapshotID": 2,
          "snapshotUUID": "719b162c-e170-4d80-b4c7-1282ed88f4e1",
          "status": "done",
          "totalSize": 1000341504,
          "virtualVolumeID": null,
          "volumeID": 2
        }
      ],
      "name": "grpsnap1",
      "status": "done"
    }
  }
}
```

ModifySchedule

You can use `ModifySchedule` to change the intervals at which a scheduled snapshot occurs. You can also delete or pause a schedule by using this method.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>attributes</code>	Use to change the frequency of the snapshot occurrence. Possible values: <ul style="list-style-type: none"> Days of Week Days of Month Time Interval 	JSON object	None	No
<code>hours</code>	Number of hours between snapshots or hour at which the snapshot will occur in Days of Week or Days of Month mode. Valid values are 0 through 24.	string	None	No
<code>name</code>	The name of the snapshot. If no name is entered, the date and time the group snapshot was taken is used. The maximum name length allowed is 244 characters.	string	None	No
<code>minutes</code>	Number of minutes between snapshots or minute at which snapshot will occur in Days of Week or Days of Month mode. Valid values are 0 through 59.	integer	None	No
<code>paused</code>	Indicates if the schedule should be paused or not. Valid values: <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean	None	No

Name	Description	Type	Default value	Required
recurring	Indicates if the schedule will be recurring or not. Valid values are: <ul style="list-style-type: none"> • true • false 	boolean	None	No
runNextInterval	Use to choose whether or not to run the snapshot the next time the scheduler is active. Valid values: <ul style="list-style-type: none"> • true • false When set to true, the scheduled snapshot runs the next time the scheduler is active, and then resets back to false.	boolean	false	No
scheduleID	Unique ID of the schedule.	integer	None	Yes
scheduleName	Unique name for the schedule. The maximum schedule name length allowed is 244 characters.	string	None	No
scheduleType	Indicates the type of schedule to create. Valid value is snapshot.	string	None	Yes

Name	Description	Type	Default value	Required
<code>scheduleInfo</code>	<p>The unique name given to the schedule, the retention period for the snapshot that was created, and the volume ID of the volume from which the snapshot was created. Valid values:</p> <ul style="list-style-type: none"> <code>volumeID</code>: The ID of the volume to be included in the snapshot. (integer) <code>volumes</code>: A list of volume IDs to be included in the group snapshot. (integer array) <code>name</code>: The snapshot name to be used. (string) <code>enableRemoteReplication</code>: Indicates if the snapshot should be included in remote replication. (boolean) <code>retention</code>: The amount of time the snapshot will be retained in HH:mm:ss. (string) 	JSON object	None	No
<code>snapMirrorLabel</code>	The label used by SnapMirror software to specify the snapshot retention policy on a SnapMirror endpoint.	string	None	No
<code>toBeDeleted</code>	<p>Indicates if the schedule is marked for deletion. Valid values:</p> <ul style="list-style-type: none"> <code>true</code> <code>false</code> 	boolean	None	No
<code>startingDate</code>	Indicates the date the first time the schedule began or will begin.	ISO 8601 date string	None	No

Name	Description	Type	Default value	Required
monthdays	The days of the month that a snapshot will be made. Valid values are 1 through 31.	integer array	None	Yes
weekdays	Day of the week the snapshot is to be created. The day of the week starts at Sunday with the value of 0 and an offset of 1.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
schedule	An object containing the modified schedule attributes.	<i>schedule</i>

Request example

```
{
  "method": "ModifySchedule",
  "params": {
    "scheduleName" : "Chicago",
    "scheduleID" : 3
  },
  "id": 1
}
```

Response example

```
{
  "id": 1,
  "result": {
    "schedule": {
      "attributes": {
        "frequency": "Days Of Week"
      },
      "hasError": false,
      "hours": 5,
      "lastRunStatus": "Success",
      "lastRunTimeStarted": null,
      "minutes": 0,
      "monthdays": [],
      "paused": false,
      "recurring": true,
      "runNextInterval": false,
      "scheduleID": 3,
      "scheduleInfo": {
        "volumeID": "2"
      },
      "scheduleName": "Chicago",
      "scheduleType": "Snapshot",
      "startingDate": null,
      "toBeDeleted": false,
      "weekdays": [
        {
          "day": 2,
```

```

    "offset": 1
  }
}
}
}

```

ModifySnapshot

You can use `ModifySnapshot` to change the attributes currently assigned to a snapshot. You can also use this method to enable snapshots created on the read/write (source) volume to be remotely replicated to a target storage cluster running Element software.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>enableRemoteReplication</code>	Use to enable the snapshot created to be replicated to a remote storage cluster. Possible values: <ul style="list-style-type: none"> <code>true</code>: The snapshot will be replicated to remote storage. <code>false</code>: The snapshot will not be replicated to remote storage. 	boolean	false	No
<code>expirationTime</code>	Use to set the time when the snapshot should be removed. When set to "null", the snapshot never expires.	ISO 8601 date string	None	No
<code>name</code>	The name of the snapshot. If no name is entered, the date and time the snapshot was taken is used. The maximum name length allowed is 255 characters.	string	None	No

Name	Description	Type	Default value	Required
snapMirrorLabel	The label used by SnapMirror software to specify the snapshot retention policy on a SnapMirror endpoint.	string	None	No
snapshotID	Identifier of the snapshot.	string	None	Yes

Return value

This method has the following return value:

Name	Description	Type
checksum	A string that represents the correct digits in the stored snapshot. This checksum can be used later to compare other snapshots to detect errors in the data.	string
snapshotID	Unique ID of the newly modified snapshot.	Snapshot ID
snapshot	An object containing information about the newly modified snapshot.	<i>snapshot</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifySnapshot",
  "params": {
    "snapshotID": 3114,
    "enableRemoteReplication": "true",
    "name": "Chicago"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "snapshot": {
      "attributes": {},
      "checksum": "0x0",
      "createTime": "2016-04-04T17:26:20Z",
      "enableRemoteReplication": true,
      "expirationReason": "None",
      "expirationTime": null,
      "groupID": 0,
      "groupSnapshotUUID": "00000000-0000-0000-0000-000000000000",
      "name": "test1",
      "snapshotID": 3114,

```



```

    "snapshotUUID": "5809a671-4ad0-4a76-9bf6-01cccf1e65eb",
    "status": "done",
    "totalSize": 5000658944,
    "virtualVolumeID": null,
    "volumeID": 1
  }
}
}

```

RollbackToGroupSnapshot

You can use `RollbackToGroupSnapshot` to roll back all individual volumes in a snapshot group to each volume's individual snapshot.

Rolling back to a group snapshot creates a temporary snapshot of each volume within the group snapshot.

Note: Creating a snapshot is allowed if cluster fullness is at stage 1, 2, or 3. Snapshots are not created when cluster fullness is at stage 4 or 5.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
groupSnapshotID	Unique ID of the group snapshot.	integer	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
name	Name for the group snapshot of the volume's current state that is created if <code>saveCurrentState</code> is set to <code>true</code> . If you do not give a name, then the name of the snapshots (group and individual volume) are set to a timestamp of the time that the rollback occurred.	string	None	No

Name	Description	Type	Default value	Required
saveCurrentState	<p>Specifies whether to save previous active volume image or not. Valid values:</p> <ul style="list-style-type: none"> • <code>true</code>: The previous active volume image is kept. • <code>false</code>: The previous active volume image is deleted. 	boolean	false	No

Return values

This method has the following return values:

Name	Description	Type
members	<p>An array with volumeIDs and snapshotIDs. Valid values:</p> <ul style="list-style-type: none"> • <code>checksum</code>: A small string representation of the data in the stored snapshot. This checksum can be used later to compare other snapshots to detect errors in the data. (string) • <code>snapshotID</code>: Unique ID of a snapshot from which the new snapshot is made. The snapshotID must be a snapshot on the given volume. (integer) • <code>volumeID</code>: The source volume ID for the snapshot. (integer) 	JSON object array
groupSnapshotID	The group snapshot ID of the old active snapshot branches.	integer
groupSnapshot	Object containing information about the newly created group snapshot.	<i>groupSnapshot</i>

Request example

Requests for this method are similar to the following example:

```
{
  "id": 438,
  "method": "RollbackToGroupSnapshot",
}
```

```

"params": {
  "groupSnapshotID": 1,
  "name": "grpsnap1",
  "saveCurrentState": true
}
}

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 438,
  "result": {
    "groupSnapshot": {
      "attributes": {},
      "createTime": "2016-04-06T17:27:17Z",
      "groupSnapshotID": 1,
      "groupSnapshotUUID": "468fe181-0002-4b1d-ae7f-8b2a5c171eee",
      "members": [
        {
          "attributes": {},
          "checksum": "0x0",
          "createTime": "2016-04-06T17:27:17Z",
          "enableRemoteReplication": false,
          "expirationReason": "None",
          "expirationTime": null,
          "groupID": 1,
          "groupSnapshotUUID": "468fe181-0002-4b1d-ae7f-8b2a5c171eee",
          "name": "2016-04-06T17:27:17Z",
          "snapshotID": 4,
          "snapshotUUID": "03563c5e-51c4-4e3b-a256-a4d0e6b7959d",
          "status": "done",
          "totalSize": 1000341504,
          "virtualVolumeID": null,
          "volumeID": 2
        }
      ],
      "name": "2016-04-06T17:27:17Z",
      "status": "done"
    },
    "groupSnapshotID": 3,
    "members": [
      {
        "checksum": "0x0",
        "snapshotID": 2,
        "snapshotUUID": "719b162c-e170-4d80-b4c7-1282ed88f4e1",
        "volumeID": 2
      }
    ]
  }
}

```

RollbackToSnapshot

You can use the `RollbackToSnapshot` method to make an existing snapshot of the active volume image. This method creates a new snapshot from an existing snapshot.

The new snapshot becomes active and the existing snapshot is preserved until it is manually deleted. The previously active snapshot is deleted unless you set the `saveCurrentState` parameter to `true`.

Note: You can create snapshots if cluster fullness is at stage 1, 2, or 3. You cannot create snapshots when cluster fullness reaches stage 4 or 5.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeID	VolumeID for the volume.	integer	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON attributes	None	No
name	Name for the snapshot. If no name is given, the name of the snapshot being rolled back to is used with "- copy" appended to the end of the name.	string	None	No
snapshotID	ID of a previously created snapshot on the given volume.	integer	None	Yes
saveCurrentState	Specifies whether to save previous active volume image or not. Valid values: <ul style="list-style-type: none"> • <code>true</code>: The previous active volume image is kept. • <code>false</code>: The previous active volume image is deleted. 	boolean	<code>false</code>	No

Return values

This method has the following return values:

Name	Description	Type
checksum	A small string representation of the data in the stored snapshot.	string
snapshotID	Unique ID of the newly created snapshot.	integer
snapshot	An object containing information about the newly created snapshot.	<i>snapshot</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "RollbackToSnapshot",
  "params": {
    "volumeID": 1,
    "snapshotID": 3114,
    "saveCurrentState": true
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "checksum": "0x0",
    "snapshot": {
      "attributes": {},
      "checksum": "0x0",
      "createTime": "2016-04-04T17:27:32Z",
      "enableRemoteReplication": false,
      "expirationReason": "None",
      "expirationTime": null,
      "groupID": 0,
      "groupSnapshotUUID": "00000000-0000-0000-0000-000000000000",
      "name": "test1-copy",
      "snapshotID": 1,
      "snapshotUUID": "30d7e3fe-0570-4d94-a8d5-3cc8097a6bfb",
      "status": "done",
      "totalSize": 5000658944,
      "virtualVolumeID": null,
      "volumeID": 1
    },
    "snapshotID": 1
  }
}
```

Virtual volume API methods

Element software virtual volume API methods enable you to manage virtual volumes (VVols). You can view existing VVols with these API methods as well as create, modify, and delete virtual volume storage containers. Although you cannot use these methods to operate on normal volumes, you can use the normal volume API methods to list information about VVols.

CreateStorageContainer

You can use the `CreateStorageContainer` method to create a Virtual Volume (VVol) storage container. You can use storage containers for reporting and resource allocation. You need to create at least one storage container to use the Virtual Volumes feature.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
name	Name of the storage container. Follows Element software account naming restrictions.	string	None	Yes
accountID	Non-storage container account that will become a storage container.	integer	None	No
initiatorSecret	The secret for CHAP authentication for the initiator.	string	None	No
targetSecret	The secret for CHAP authentication for the target.	string	None	No

Return value

This method has the following return value:

Name	Description	Type
storageContainer	Object containing Information about the newly created storage container.	<i>storageContainer</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateStorageContainer",
  "params": {
    "name": "example"
  }
}
```

```

    },
    "id": 1
  }

```

Response example

This method returns a response similar to the following example:

```

{
  "id": 1,
  "result": {
    "storageContainer": {
      "accountID": 8,
      "initiatorSecret": "rVTOi25^H.d;cP}1",
      "name": "example",
      "protocolEndpointType": "SCSI",
      "status": "active",
      "storageContainerID": "a9ec1138-e386-4a44-90d7-b9acbbc05176",
      "targetSecret": "6?AEIxWpvo6,!boM"
    }
  }
}

```

DeleteStorageContainers

You can use the `DeleteStorageContainers` method to remove up to 2000 Virtual Volume (VVol) storage containers from the system at one time. The storage containers you remove must not contain any VVols.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
storageContainerIDs	A list of IDs of the storage containers to delete. You can specify up to 2000 IDs in the list.	UUID array	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```

{
  "method": "DeleteStorageContainers",
  "params": {
    "storageContainerIDs" : ["a9ec1138-e386-4a44-90d7-b9acbbc05176"]
  },
  "id": 1
}

```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {}
}
```

GetStorageContainerEfficiency

You can use the `GetStorageContainerEfficiency` method to retrieve efficiency information about a virtual volume storage container.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
storageContainerID	The ID of the storage container for which to retrieve efficiency information.	integer	None	Yes

Return values

This method has the following return values:

Name	Description	Type
compression	The amount of space saved by data compression for all virtual volumes in the storage container. Stated as a ratio where a value of 1 means data has been stored with no compression.	float
deduplication	The amount of space saved by not duplicating data for all virtual volumes in the storage container. Stated as a ratio.	float
missingVolumes	The virtual volumes that could not be queried for efficiency data. Missing volumes can be caused by the Garbage Collection (GC) cycle being less than an hour old, temporary loss of network connectivity, or restarted services since the GC cycle.	integer array
thinProvisioning	The ratio of space used to the amount of space allocated for storing data. Stated as a ratio.	float
timestamp	The last time efficiency data was collected after GC.	ISO 8601 data string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetStorageContainerEfficiency",
  "params": {
    "storageContainerID" : "6c95e24f-9f0b-4793-affb-5a4bc6c3d7e1"
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "compression": 1,
    "deduplication": 1,
    "missingVolumes": [],
    "thinProvisioning": 1,
    "timestamp": "2016-04-12T15:39:49Z"
  }
}
```

GetVirtualVolumeCount

You can use the `GetVirtualVolumeCount` method to retrieve the number of virtual volumes currently in the system.

Parameters

This method has no input parameters.

Return value

This method has the following return value:

Name	Description	Type
count	The number of virtual volumes currently in the system.	integer

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetVirtualVolumeCount",
  "params": {
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "count": 5
  }
}
```

ListProtocolEndpoints

You can use the `ListProtocolEndpoints` method to retrieve information about all protocol endpoints in the cluster. Protocol endpoints govern access to their associated virtual volume storage containers.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>protocolEndpointIDs</code>	A list of protocol endpoint IDs for which to retrieve information. If you omit this parameter, the method returns information about all protocol endpoints.	<code>protocolEndpointID</code> UUID array	None	No

Return values

This method has the following return value:

Name	Description	Type
<code>protocolEndpoints</code>	List of objects containing information about each protocol endpoint in the system.	<i>protocolEndpoint</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "id": 1,
  "method": "ListProtocolEndpoints",
}
```

```
"params": {}
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "protocolEndpoints": [
      {
        "primaryProviderID": 1,
        "protocolEndpointID": "1387e257-d2e3-4446-be6d-39db71583e7b",
        "protocolEndpointState": "Active",
        "providerType": "Primary",
        "scsiNAADeviceID": "6f47acc2000000016970687200000000",
        "secondaryProviderID": 2
      },
      {
        "primaryProviderID": 2,
        "protocolEndpointID": "1f16ed86-3f31-4c76-b004-a1251187700b",
        "protocolEndpointState": "Active",
        "providerType": "Primary",
        "scsiNAADeviceID": "6f47acc2000000026970687200000000",
        "secondaryProviderID": 3
      },
      {
        "primaryProviderID": 4,
        "protocolEndpointID": "c6458dfe-9803-4350-bb4e-68a3feb7e830",
        "protocolEndpointState": "Active",
        "providerType": "Primary",
        "scsiNAADeviceID": "6f47acc2000000046970687200000000",
        "secondaryProviderID": 1
      },
      {
        "primaryProviderID": 3,
        "protocolEndpointID": "f3e7911d-0e86-4776-97db-7468c272213f",
        "protocolEndpointState": "Active",
        "providerType": "Primary",
        "scsiNAADeviceID": "6f47acc2000000036970687200000000",
        "secondaryProviderID": 4
      }
    ]
  }
}
```

ListStorageContainers

You can use the `ListStorageContainers` method to retrieve information about all virtual volume storage containers known to the system.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
storageContainerIDs	A list of storage container IDs for which to retrieve information. If you omit this parameter, the method returns information about all storage containers in the system.	UUID array	None	No

Return value

This method has the following return value:

Name	Description	Type
storageContainers	List of objects containing information about all storage containers in the system.	<i>storageContainer</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListStorageContainers",
  "params": {
    "storageContainerIDs": ["efda8307-b916-4424-979e-658a3f16894d"]
  },
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 6395,
  "result": {
    "storageContainers": [
      {
        "accountID": 64,
        "initiatorSecret": "EJ:08AnlMyNQmL!7",
        "name": "VvolContainer",
        "protocolEndpointType": "SCSI",
        "status": "active",
        "storageContainerID": "efda8307-b916-4424-979e-658a3f16894d",
        "targetSecret": "g38}zWBK%206jQr~",
        "virtualVolumes": []
      }
    ]
  }
}
```

ListVirtualVolumeBindings

You can use the `ListVirtualVolumeBindings` method to get a list of all virtual volumes in the cluster that are bound to protocol endpoints.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>virtualVolumeBindingIDs</code>	A list of virtual volume binding IDs for which to retrieve information. If you omit this parameter, the method returns information about all virtual volume bindings.	integer array	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>bindings</code>	A list of objects describing all virtual volumes in the cluster that are bound to protocol endpoints.	<i>binding</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVirtualVolumeBindings",
  "params": {
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "bindings": [
      {
        "protocolEndpointID": "5dd53da0-b9b7-43f9-9b7e-b41c2558e92b",
        "protocolEndpointInBandID": "naa.6f47acc2000000016a67746700000000",
        "protocolEndpointType": "SCSI",
        "virtualVolumeBindingID": 177,
        "virtualVolumeHostID": "564dela4-9a99-da0f-8b7c-3a41dfd64bf1",
        "virtualVolumeID": "269d3378-1ca6-4175-a18f-6d4839e5c746",
        "virtualVolumeSecondaryID": "0xe200000000a6"
      }
    ]
  }
}
```

```

    }
  ]
}

```

ListVirtualVolumeHosts

You can use the `ListVirtualVolumeHosts` method to get a list of all virtual volume hosts known to the cluster. A virtual volume host is a VMware ESX host that has initiated a session with the VASA API provider.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>virtualVolumeHostIDs</code>	A list of virtual volume host IDs for which to retrieve information. If you omit this parameter, the method returns information about all virtual volume hosts.	<code>virtualVolumeHostID</code> UUID array	None	No

Return value

This method has the following return value:

Name	Description	Type
<code>hosts</code>	A list of objects describing the virtual volume hosts in the cluster.	<i>host</i> array

Request example

Requests for this method are similar to the following example:

```

{
  "method": "ListVirtualVolumeHosts",
  "params": {
  },
  "id": 1
}

```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "hosts": [
      {
        "bindings": [],
        "clusterID": "5ebdb4ad-9617-4647-adfd-c1013578483b",
        "hostAddress": "172.30.89.117",
        "initiatorNames": [
          "iqn.1998-01.com.vmware:zdc-dhcp-0-c-29-d6-4b-f1-1a0cd614",
          "iqn.1998-01.com.vmware:zdc-dhcp-0-c-29-d6-4b-f1-5bcf9254"
        ],
        "virtualVolumeHostID": "564de1a4-9a99-da0f-8b7c-3a41dfd64bf1",
        "visibleProtocolEndpointIDs": [
          "5dd53da0-b9b7-43f9-9b7e-b41c2558e92b"
        ]
      }
    ]
  }
}
```

ListVirtualVolumes

You can use the `ListVirtualVolumes` method to list the virtual volumes currently in the system. You can use this method to list all virtual volumes, or only list a subset.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
details	<p>The level of detail in the response. Possible values:</p> <ul style="list-style-type: none"> <code>true</code>: Include more details about each VVol in the response. <code>false</code>: Include the standard level of detail about each VVol in the response. 	boolean	False	No
limit	The maximum number of virtual volumes to list.	integer	10000	No

Name	Description	Type	Default value	Required
recursive	Specifies whether to include information about the children of each VVol in the response or not. Possible values: <ul style="list-style-type: none"> • true: Include information about the children of each VVol in the response. • false: Do not include information about the children of each VVol in the response. 	boolean	False	No
startVirtualVolumeID	The ID of the virtual volume at which to begin the list in the response.	UUIDType	None	No
virtualVolumeIDs	A list of virtual volume IDs for which to retrieve information. If you omit this parameter, the method returns information about only these virtual volumes.	virtualVolumeID UUID array	None	No

Return values

This method has the following return values:

Name	Description	Type
nextVirtualVolumeID	The ID of the next virtual volume in the list.	UUID
virtualVolumes	A list of objects describing the virtual volumes currently in the system.	<i>virtualVolume</i> array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVirtualVolumes",
  "params": {
  },
  "id": 1
}
```


Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "nextVirtualVolumeID": "00000000-0000-0000-0000-000000000000",
    "virtualVolumes": [
      {
        "bindings": [
          177
        ],
        "children": [],
        "metadata": {
          "SFProfileId": "f4e5bade-15a2-4805-bf8e-52318c4ce443",
          "SFgenerationId": "0",
          "VMW_ContainerId": "abaab415-bedc-44cd-98b8-f37495884db0",
          "VMW_VVolName": "asdf",
          "VMW_VVolType": "Config",
          "VMW_VmID": "502e0676-e510-ccdd-394c-667f6867fcdf",
          "VMW_VvolProfile": "f4e5bade-15a2-4805-bf8e-52318c4ce443:0"
        },
        "parentVirtualVolumeID": "00000000-0000-0000-0000-000000000000",
        "snapshotID": 0,
        "snapshotInfo": null,
        "status": "done",
        "storageContainer": {
          "accountID": 1,
          "initiatorSecret": "B5)D1y10K)8IDN58",
          "name": "test",
          "protocolEndpointType": "SCSI",
          "status": "active",
          "storageContainerID": "abaab415-bedc-44cd-98b8-f37495884db0",
          "targetSecret": "qgae@{o{~8\"2U)U^"
        },
        "virtualVolumeID": "269d3378-1ca6-4175-a18f-6d4839e5c746",
        "virtualVolumeType": "config",
        "volumeID": 166,
        "volumeInfo": null
      }
    ]
  }
}
```

ListVirtualVolumeTasks

You can use the `ListVirtualVolumeTasks` method to get a list of virtual volume tasks in the system.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
<code>virtualVolumeTaskIDs</code>	A list of virtual volume task IDs for which to retrieve information. If you omit this parameter, the method returns information about all virtual volume tasks.	UUID array	None	No

Return value

This method has the following return value:

Name	Description	Type
tasks	A list of objects describing the virtual volume tasks in the cluster.	task array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListVirtualVolumeTasks",
  "params": {
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "tasks": [
      {
        "cancelled": false,
        "cloneVirtualVolumeID": "fafeb3a0-7dd9-4c9f-8a07-80e0bbf6f4d0",
        "operation": "clone",
        "parentMetadata": {
          "SFProfileId": "f4e5bade-15a2-4805-bf8e-52318c4ce443",
          "SFgenerationId": "0",
          "VMW_ContainerId": "abaab415-bedc-44cd-98b8-f37495884db0",
          "VMW_GosType": "windows7Server64Guest",
          "VMW_VVolName": "asdf.vmdk",
          "VMW_VVolNamespace": "/vmfs/volumes/
vvol:abaab415bedc44cd-98b8f37495884db0/rfc4122.269d3378-1ca6-4175-
a18f-6d4839e5c746",
          "VMW_VVolType": "Data",
          "VMW_VmID": "502e0676-e510-ccdd-394c-667f6867fcdf",
          "VMW_VvolAllocationType": "4",
          "VMW_VvolProfile": "f4e5bade-15a2-4805-bf8e-52318c4ce443:0"
        },
        "parentTotalSize": 42949672960,
        "parentUsedSize": 0,
        "status": "success",
        "virtualVolumeHostID": "564de1a4-9a99-da0f-8b7c-3a41dfd64bf1",
        "virtualVolumeTaskID": "a1b72df7-66a6-489a-86e4-538d0dbe05bf",
        "virtualVolumeID": "fafeb3a0-7dd9-4c9f-8a07-80e0bbf6f4d0"
      }
    ]
  }
}
```

ModifyStorageContainer

You can use the `ModifyStorageContainer` method to make changes to an existing virtual volume storage container.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
<code>storageContainerID</code>	The unique ID of the virtual volume storage container to modify.	UUID	None	Yes
<code>initiatorSecret</code>	The new secret for CHAP authentication for the initiator.	string	None	No
<code>targetSecret</code>	The new secret for CHAP authentication for the target.	string	None	No

Return values

This method has the following return value:

Name	Description	Type
<code>storageContainer</code>	Information about the newly created storage container.	<i>storageContainer</i>

Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyStorageContainer",
  "params": {
    "storageContainerID": "6c95e24f-9f0b-4793-affb-5a4bc6c3d7e1",
    "targetSecret": "O,IM;tOQdn9$JJ*8"
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "storageContainer": {
      "accountID": 8,
      "initiatorSecret": "T$|5TO>2IY5sk4@k",
      "name": "doctest1",
      "protocolEndpointType": "SCSI",
      "status": "active",
      "storageContainerID": "6c95e24f-9f0b-4793-affb-5a4bc6c3d7e1",
      "targetSecret": "O,IM;tOQdn9$JJ*8"
    }
  }
}
```

```
}  
}  
}
```

Cluster fault codes

If a storage cluster experiences an error or a state that might be of interest to an administrator, it generates a cluster fault. You can use the `ListClusterFaults` method to retrieve the current list of resolved and unresolved faults on a storage cluster.

The following list gives more information about and possible solutions for NetApp Element storage cluster faults:

availableVirtualNetworkIPAddressesLow

The number of virtual network addresses in the block of IP addresses is low.

To resolve this fault, add more IP addresses to the block of virtual network addresses.

blockClusterFull

There is not enough free block storage space to support the loss of a single node.

To resolve this fault, purge or delete volumes or add another storage node to the storage cluster.

blockServiceTooFull

A block service is using too much space.

To resolve this fault, purge or delete volumes or add another storage node to the storage cluster.

clusterCannotSync

The storage cluster is out of space, and the system cannot synchronize data on the offline block storage drives to drives that are still active.

To resolve this fault, add more storage.

clusterFull

There is no more free storage space in the storage cluster.

To resolve this fault, add more storage.

clusterIOPSAreOverProvisioned

Storage cluster IOPS are over provisioned. The sum of all minimum QoS IOPS is greater than the expected IOPS of the cluster. The system cannot maintain minimum QoS for all volumes simultaneously.

To resolve this fault, lower the minimum QoS IOPS settings for volumes.

disconnectedClusterPair

A cluster pair is disconnected or configured incorrectly.

Check the network connectivity of the cluster.

disconnectedRemoteNode

A remote node is disconnected or configured incorrectly.

disconnectedSnapMirrorEndpoint

A remote SnapMirror endpoint is disconnected or configured incorrectly.

driveAvailable

One or more drives are available to be added in the storage cluster. In general, all storage clusters should have all drives added and none in the available state. If this fault appears unexpectedly, contact NetApp Support.

To resolve this fault, add any available drives to the storage cluster.

driveFailed

One or more drives have failed.

Contact NetApp Support for a drive replacement.

driveWearFault

A drive's remaining life has dropped below thresholds, but it is still functioning.

To resolve this fault, replace the drive soon.

duplicateClusterMasterCandidates

There is more than one storage cluster master candidate.

Contact NetApp Support for assistance.

ensembleDegraded

One of the ensemble nodes has lost network connectivity or power.

To resolve this fault, restore network connectivity or power to the affected node.

exception

An unusual fault has occurred. These faults are not automatically cleared from the fault queue.

Contact NetApp Support for assistance.

failedSpaceTooFull

A block service is not responding to data write requests. This causes the slice service to run out of space to store failed writes.

Contact NetApp Support for assistance.

fanSensor

A fan sensor has failed or is missing.

Contact NetApp Support for assistance.

fibreChannelAccessDegraded

A Fibre Channel node is not responding to other nodes in the storage cluster via its storage IP address.

Check the network connectivity of the cluster.

fibreChannelAccessUnavailable

All Fibre Channel nodes are unresponsive. The node IDs are displayed.

Check the network connectivity of the cluster.

fibreChannelConfig

This cluster fault indicates one of the following conditions:

- There is an unexpected Fibre Channel port on a PCI slot.
- There is an unexpected Fibre Channel HBA model.
- There is a problem with the firmware of a Fibre Channel HBA.
- A Fibre Channel port is not online.
- There is a persistent issue configuring Fibre Channel passthrough.

Contact NetApp Support for assistance.

fileSystemCapacityLow

There is insufficient space on one of the filesystems.

To resolve this fault, add more capacity to the filesystem.

fipsSelfTestFailure

The system has detected a failure during the FIPS self test.

Contact NetApp Support for assistance.

hardwareConfigMismatch

This cluster fault indicates one of the following conditions:

- The configuration does not match the node definition.
- There is an incorrect drive size for this type of node.
- A node is using unsupported drive.
- There is a drive firmware mismatch.
- A drive's encryption capable state does not match its parent node.

Contact NetApp Support for assistance.

inconsistentBondModes

The bond modes on the VLAN device are missing. This fault will display the expected bond mode and the bond mode currently in use.

To resolve this fault, modify the bond modes in the per-node web UI.

inconsistentInterfaceConfiguration

The interface configuration is inconsistent.

To resolve this fault, ensure the node interfaces in the storage cluster are consistently configured.

inconsistentMtus

This cluster fault indicates one of the following conditions:

- Bond1G mismatch: Inconsistent MTUs have been detected on Bond1G interfaces.
- Bond10G mismatch: Inconsistent MTUs have been detected on Bond10G interfaces.

This fault displays the node or nodes in question along with the associated MTU value.

To resolve this fault, modify the MTU settings in the per-node web UI.

inconsistentRoutingRules

The routing rules for this interface are inconsistent.

inconsistentSubnetMasks

The network mask on the VLAN device does not match the internally recorded network mask for the VLAN. This fault displays the expected network mask and the network mask currently in use.

To resolve this fault, modify the subnet mask in the Element (storage cluster) web UI.

incorrectBondPortCount

The number of bond ports is incorrect.

invalidConfiguredFibreChannelNodeCount

One of the two expected Fibre Channel node connections is degraded. This fault appears when only one Fibre Channel node is connected.

To resolve this fault, check the cluster network connectivity and network cabling, and check for failed services. If there are no network or service problems, contact NetApp Support for a Fibre Channel node replacement.

irqBalanceFailed

An exception occurred while attempting to balance interrupts.

Contact NetApp Support for assistance.

memoryUsageThreshold

Memory usage is above normal.

Contact NetApp Support for assistance.

metadataClusterFull

There is not enough free metadata space to support a single node loss.

To resolve this fault, add another storage node to the storage cluster.

mtuCheckFailure

A network device is not configured for the proper MTU size.

To resolve this fault, ensure that all network interfaces and switch ports are configured for jumbo frames (MTUs up to 9000 bytes in size).

networkConfig

This cluster fault indicates one of the following conditions:

- An expected network interface is not present.
- A duplicate network interface is present.
- A network interface is configured but down.
- A network interface restart is needed.

Contact NetApp Support for assistance.

networkErrorsExceedThreshold

This cluster fault indicates one of the following conditions:

- The number of network interface frame errors is above normal.
- The number of network interface CRC errors is above normal.

Replace the network cable connected to the network interface reporting these errors.

Contact NetApp Support if the issue persists.

noAvailableVirtualNetworkIPAddresses

There are no available virtual network addresses in the block of IP addresses. No more storage nodes can be added to the storage cluster.

To resolve this fault, add more IP addresses to the block of virtual network addresses.

nodeOffline

Element software cannot communicate with the specified node.

To resolve this fault, check network connectivity and network cabling of the cluster. If there are no network problems, contact NetApp Support for a node replacement.

notUsingLACPBondMode

LACP bonding mode is not configured.

To resolve this fault, use LACP bonding when deploying storage nodes; clients might experience performance issues if LACP is not enabled and properly configured.

ntpServerUnreachable

The storage cluster cannot communicate with the specified NTP server or servers.

To resolve this fault, check the NTP server configuration, network, and firewall.

ntpTimeNotInSync

The difference between storage cluster time and the specified NTP server time is too large.

The storage cluster cannot correct the difference automatically.

To resolve this fault, use NTP servers that are internal to your network, rather than the installation defaults. If you are using internal NTP servers and the issue persists, contact NetApp Support for assistance.

nvrAmDeviceStatus

An NVRAM device has an error, is failing, or has failed.

Contact NetApp Support for assistance.

powerSupplyError

This cluster fault indicates one of the following conditions:

- A power supply is not present.
- A power supply has failed.
- A power supply has no input or the input is out of range.

To resolve this fault, verify that redundant power is supplied to all nodes. Contact NetApp Support if the issue persists.

provisionedSpaceTooFull

The overall provisioned capacity of the storage cluster is too full.

To resolve this fault, add more provisioned space, or delete and purge volumes or snapshots.

remoteRepAsyncDelayExceeded

The configured asynchronous delay for replication has been exceeded.

remoteRepClusterFull

The volumes have paused remote replication because the target storage cluster is too full.

To resolve this fault, free up some space on the target storage cluster.

remoteRepSnapshotClusterFull

The volumes have paused remote replication of snapshots because the target storage cluster is too full.

To resolve this fault, free up some space on the target storage cluster.

remoteRepSnapshotsExceededLimit

The volumes have paused remote replication of snapshots because the target storage cluster volume has exceeded its snapshot limit.

To resolve this fault, remove some snapshots on the remote cluster.

scheduleActionError

One or more of the scheduled activities ran, but failed.

The fault clears if the scheduled activity runs again and succeeds, if the scheduled activity is deleted, or if the activity is paused and resumed.

sensorReadingFailed

The Baseboard Management Controller (BMC) self-test failed or a sensor could not communicate with the BMC.

Contact NetApp Support for assistance.

serviceNotRunning

A required service is not running.

Contact NetApp Support for assistance.

sliceServiceTooFull

A slice service has too little provisioned capacity assigned to it.

To resolve this fault, add more storage nodes or contact NetApp Support.

sshEnabled

The SSH service is enabled on one or more nodes in the storage cluster.

To resolve this fault, disable the SSH service on the node or nodes.

sslCertificateExpiration

The SSL certificate associated with this node has expired.

To resolve this fault, renew the SSL certificate. If needed, contact NetApp Support for assistance.

tempSensor

A temperature sensor is reporting higher than normal temperatures. This fault can be triggered in conjunction with powerSupplyError or fanSensor faults.

To resolve this fault, check for airflow obstructions near the storage cluster. If needed, contact NetApp Support for assistance.

upgrade

An upgrade has been in progress for more than 24 hours.

To resolve this fault, resume the upgrade or contact NetApp Support for assistance.

unbalancedMixedNodes

A single node accounts for more than one-third of the storage cluster's capacity.

Contact NetApp Support for assistance.

unresponsiveService

A system service has become unresponsive.

Contact NetApp Support for assistance.

virtualNetworkConfig

This cluster fault indicates one of the following conditions:

- An interface is not present.
- There is an incorrect namespace on an interface.
- There is an incorrect network mask.
- There is an incorrect IP address.
- An interface is not up and running.
- There is a superfluous interface on a node.

Contact NetApp Support for assistance.

volumesDegraded

Secondary volumes have not yet completely replicated and synchronized.

This fault is cleared when the synchronisation is complete.

If the fault persists, check for network connectivity issues and hardware errors.

volumesOffline

One or more volumes in the storage cluster are offline.

Contact NetApp Support for assistance.

Related concepts

[Contacting NetApp Support](#) on page 528

Related references

[*GetClusterFullThreshold*](#) on page 127

[*ListClusterFaults*](#) on page 143

Access control

The API methods available vary based on the type of access you set.

accounts

The following methods are available to the accounts access type:

AddAccount	GetAccountByID
ModifyAccount	GetAccountByName
ListAccounts	GetAccountEfficiency
RemoveAccount	

administrator

All methods are available to the administrator access type.

clusterAdmin

The following methods are available to the cluster admin access type:

AddClusterAdmin	ListBackupTargets
AddInitiatorsToVolumeAccessGroup	ListBulkVolumeJobs
AddLdapClusterAdmin	ListClusterAdmins
AddVirtualNetwork	ListClusterPairs
AddVirtualNetwork	ListNodeFibreChannelPortInfo
AddVolumeToVolumeAccessGroup	ListBackupTargets
CloneMultipleVolumes	ListDriveHardware
CompleteClusterPairing	ListFibreChannelSessions
CompleteVolumePairing	ListFibreChannelPortInfo
CreateBackupTarget	ListGroupSnapshots
CreateSchedule	ListActivePairedVolumes
CreateSnapshot	ModifyBackupTarget
CreateSupportBundle	ModifyClusterAdmin
CreateClusterSupportBundle	ModifyGroupSnapshot
CreateGroupSnapshot	ModifyClusterFullThreshold
CreateVolumeAccessGroup	ModifyVolumeAccessGroup
DeleteAllSupportBundles	ModifyVolumeAccessGroupLunAssignments
DeleteSnapshot	ModifyVolumePair
DeleteGroupSnapshot	ModifyVirtualNetwork
DeleteVolumeAccessGroup	RemoveClusterAdmin

DisableEncryptionAtRest	RemoveVolumePair
DisableLdapAuthentication	RemoveVirtualNetwork
DisableSnmpp	RemoveVolumesFromVolumeAccessGroup
EnableEncryptionAtRest	RemoveInitiatorsFromVolumeAccessGroup
EnableLdapAuthentication	RollbackToSnapshot
EnableSnmpp	RollbackToGroupSnapshot
GetBackupTarget	SetLoginSessionInfo
GetClusterFullThreshold	SetNtpInfo
GetClusterMasterNodeID	SetSnmppACL
GetHardwareConfig	SetSnmppInfo
GetLdapConfiguration	SetSnmppTrapInfo
GetLoginSessionInfo	SetRemoteLoggingHosts
GetNtpInfo	Shutdown
GetNvramInfo	StartBulkVolumeRead
GetRawStats	StartBulkVolumeWrite
GetSnmppACL	StartClusterPairing
GetVolumeAccessGroupEfficiency	StartVolumePairing
GetVolumeAccessLunAssignments	TestLdapAuthentication
GetVirtualNetwork	

drives

The following methods are available to the drives access type:

ListDrives	RemoveDrives
AddDrives	SecureEraseDrives

nodes

The following methods are available to the nodes access type:

AddNodes	ListPendingNodes
ListActiveNodes	RemoveNodes

read

The following methods are available to the read access type:

GetAccountByID	ListCloneJobs
GetAccountByName	ListDeletedVolumes
GetAsyncResult	ListDriveHardware
GetClusterCapacity	ListDrives
GetDefaultQoS	ListEvents

GetDriveStats	ListISCSISessions
GetSoftwareUpgrade	ListPendingNodes
GetVolumeStats	ListSyncJobs
ListAccounts	ListVolumeAccessGroups
ListActiveNodes	ListVolumeStatsByAccount
ListActiveNodes	ListVolumeStatsByVolume
ListActiveVolumes	ListVolumeStatsByVolumeAccessGroup
ListAllNodes	ListVolumesForAccount
ListBackupTargets	

reporting

The following methods are available to the reporting access type:

ClearClusterFaults	GetVolumeEfficiency
GetAccountEfficiency	GetVolumeStats
GetClusterCapacity	ListCloneJobs
GetClusterHardwareInfo	ListClusterFaults
GetClusterInfo	ListClusterPairs
GetClusterMasterNodeID	ListDriveHardware
GetClusterStats	ListEvents
GetDriveHardwareInfo	ListISCSISessions
GetDriveStats	ListSchedules
GetNetworkConfig	ListServices
GetNodeHardwareInfo	ListSyncJobs
GetNodeStats	ListVirtualNetworks
GetSnmpInfo	ListVolumeStatsByAccount
GetSnmpTrapInfo	ListVolumeStatsByVolume
GetVolumeAccessGroupEfficiency	ListVolumeStatsByVolumeAccessGroup

repositories

The ListAllNodes method is available to the repositories access type.

volumes

The following methods are available to the volumes access type:

CreateVolume	DeleteVolume	ModifyBackupTarget
CloneVolume	DeleteVolumePairing	ModifyVolumes
CloneMultipleVolumes	GetBackupTarget	ModifyVolumePair
CreateBackupTarget	GetDefaultQoS	PurgeDeletedVolume

CreateSnapshot	ListActiveVolumes	RemoveBackupTarget
CreateGroupSnapshot	ListBackupTarget	RemoveVolumePair
CompleteVolumePairing	ListGroupSnapshots	RestoreDeletedVolume
CloneMultipleVolumes	ListVolumesForAccount	RollbackToGroupSnapshot
DeleteGroupSnapshot	ListDeletedVolumes	RollbackToSnapshot
DeleteSnapshot	ListGroupSnapshots	StartBulkVolumeRead
StartBulkVolumeWrite	StartVolumePairing	UpdateBulkVolumeStatus

write

The following methods are available to the write access type:

AddDrives	RemoveNodes
AddNodes	RemoveAccount
AddAccount	RemoveVolumesFromVolumeAccessGroup
AddVolumeToVolumeAccessGroup	RemoveInitiatorsFromVolumeAccessGroup
AddInitiatorsToVolumeAccessGroup	DeleteVolumeAccessGroup
CreateVolumeAccessGroup	DeleteVolume
ModifyVolumeAccessGroup	RestoreDeletedVolume
ModifyAccount	PurgeDeletedVolume
CreateVolume	ModifyVolume
CloneVolume	GetAsyncResult
RemoveDrives	

Response examples

Complete response examples are provided here.

GetConfig

The `GetConfig` method returns a response similar to the following example. Due to length, the response contains information for one node of the cluster only.

```
{
  "id": 1,
  "result": {
    "config": {
      "cluster": {
        "cipi": "Bond10G",
        "cluster": "AutoTest2-Fjqt",
        "encryptionCapable": true,
        "ensemble": [
          "1:10.1.1.0",
          "3:10.1.1.0",
          "4:10.1.1.0"
        ],
        "mipi": "Bond1G",
        "name": "NLABP2605",
        "nodeID": 1,
        "pendingNodeID": 0,
        "role": "Storage",
        "sipi": "Bond10G",
        "state": "Active",
        "version": "11.0"
      },
      "network": {
        "Bond10G": {
          "#default": false,
          "address": "10.1.1.0",
          "auto": true,
          "bond-downdelay": "0",
          "bond-fail_over_mac": "None",
          "bond-miimon": "100",
          "bond-mode": "ActivePassive",
          "bond-primary_reselect": "Failure",
          "bond-slaves": "eth0 eth1",
          "bond-updelay": "200",
          "dns-nameservers": "10.1.1.0, 10.1.1.0",
          "dns-search": "ten.test.company.net., company.net.",
          "family": "inet",
          "gateway": "10.1.1.0",
          "linkSpeed": 10000,
          "macAddress": "c8:1f:66:ee:59:b9",
          "macAddressPermanent": "00:00:00:00:00:00",
          "method": "static",
          "mtu": "9000",
          "netmask": "255.255.240.0",
          "network": "10.1.1.0",
          "physical": {
            "address": "10.1.1.0",
            "macAddress": "c8:1f:66:ee:59:b9",
            "macAddressPermanent": "00:00:00:00:00:00",
            "mtu": "9000",
            "netmask": "255.255.240.0",
            "network": "10.1.1.0",
            "upAndRunning": true
          },
          "routes": [],

```



```

        "status": "UpAndRunning",
        "symmetricRouteRules": [
            "ip route add 10.1.1.1/20 dev Bond1G src 10.1.2.2
table Bond1G",
            "ip rule add from 10.1.1.1 table Bond1G",
            "ip route add default via 10.1.1.254"
        ],
        "upAndRunning": true,
        "virtualNetworkTag": "0"
    },
    "eth0": {
        "auto": true,
        "bond-master": "Bond10G",
        "family": "inet",
        "linkSpeed": 10000,
        "macAddress": "c8:1f:66:ee:59:b9",
        "macAddressPermanent": "c8:1f:66:ee:59:b9",
        "method": "bond",
        "physical": {
            "address": "0.0.0.0",
            "macAddress": "c8:1f:66:ee:59:b9",
            "macAddressPermanent": "c8:1f:66:ee:59:b9",
            "netmask": "N/A",
            "network": "N/A",
            "upAndRunning": true
        },
        "status": "UpAndRunning",
        "upAndRunning": true
    },
    "lo": {
        "auto": true,
        "family": "inet",
        "linkSpeed": 0,
        "macAddress": "00:00:00:00:00:00",
        "macAddressPermanent": "00:00:00:00:00:00",
        "method": "loopback",
        "physical": {
            "address": "0.0.0.0",
            "macAddress": "00:00:00:00:00:00",
            "macAddressPermanent": "00:00:00:00:00:00",
            "netmask": "N/A",
            "network": "N/A",
            "upAndRunning": true
        },
        "status": "UpAndRunning",
        "upAndRunning": true
    }
}
}
}
}

```

GetClusterHardwareInfo

The `GetClusterHardwareInfo` method returns a response similar to the following example.

```

{
  "id": null,
  "result": {
    "clusterHardwareInfo": {
      "drives": {
        "1": {
          "description": "ATA          Drive",
          "dev": "8:0",
          "devpath": "/dev/disk/by-id/scsi-SATA_VRFSD3400GNCVMT205121562-
part4",
          "driveSecurityAtMaximum": false,
          "driveSecurityFrozen": true,

```

```

        "driveSecurityLocked": false,
        "logicalname": "/dev/sda",
        "product": "VRFSD3400GNCVMTJS1",
        "securityFeatureEnabled": false,
        "securityFeatureSupported": true,
        "serial": "205121562",
        "size": 299988156416,
        "uuid": "febe39ae-4984-edc0-e3a7-3c47608cface",
        "version": "515ABBF0"
    },
    "2": { ...
    },
    "3": { ...
    },
    "4": { ...
    },
    "5": { ...
    },
    "6": { ...
    },
    .
    .
    .
    "44": { ...
    },
    },
    "nodes": {
        "1": {
            Storage Node
            "core_DMI:0200": {
                "description": "Motherboard",
                "physid": "0",
                "vendor": "SolidFire"
            },
            "fiber:0_PCI:0000:04:00.0": {
                "businfo": "pci@0000:04:00.0",
                "clock": "33000000",
                "description": "Fibre Channel",
                "physid": "0",
                "product": "ISP8324-based 16Gb Fibre Channel to PCI Express
Adapter",
                "vendor": "QLogic Corp.",
                "version": "02",
                "width": "64"
            },
            "Repeat fiber information": { ... }
            "Repeat fiber": { ... },
            "Repeat fiber": { ... },
        },
        "fans": {
            "Fan1A RPM": {
                "baseUnit": "RPM",
                "threshold": 840,
                "value": 4800
            },
            "Fan1B RPM": { ... },
            .
            .
            .
            "Fan7B RPM": { ...
            },
            "fibreChannelPorts": [
                {
                    "firmware": "7.04.00 (d0d5)",
                    "hbaPort": 1,
                    "model": "QLE2672",
                    "nPortID": "0x110c36",
                    "pciSlot": 3,
                    "serial": "BFE1341E09329",
                    "speed": "8 Gbit",
                    "state": "Online",

```

```

    "switchWwn": "20:01:00:2a:6a:a0:25:01",
    "wwnn": "5f:47:ac:c8:82:23:e0:00",
    "wwpn": "5f:47:ac:c0:82:23:e0:02"
  },
  {
    "firmware": "7.04.00 (d0d5)", {...}
    "firmware": "7.04.00 (d0d5)", {...}
    "firmware": "7.04.00 (d0d5)", {...}
  }
],
"hardwareConfig": {
  "BIOS_REVISION": {
    "Passed": true,
    "actual": "1.1",
    "comparator": ">=",
    "expected": "1.0"
  },
  "BIOS_VENDOR": {
    "Passed": true,
    "actual": "SolidFire",
    "comparator": "==",
    "expected": "SolidFire"
  },
  "BIOS_VERSION": {
    "Passed": true,
    "actual": "1.1.2",
    "comparator": ">=",
    "expected": "1.1.2"
  },
  "BMC_FIRMWARE_REVISION": {
    "Passed": true,
    "actual": "1.6",
    "comparator": ">=",
    "expected": "1.6"
  },
  "BMC_IPMI_VERSION": {
    "Passed": true,
    "actual": "2.0",
    "comparator": ">=",
    "expected": "2.0"
  },
  "CHASSIS_TYPE": {
    "Passed": true,
    "actual": "R620",
    "comparator": "==",
    "expected": "R620"
  },
  "CPU_CORES_00": {
    "Passed": true,
    "actual": "6",
    "comparator": "==",
    "expected": "6"
  },
  "CPU_CORES_01": {
    "Passed": true,
    "actual": "6",
    "comparator": "==",
    "expected": "6"
  },
  "CPU_CORES_ENABLED_00": {
    "Passed": true,
    "actual": "6",
    "comparator": "==",
    "expected": "6"
  },
  "CPU_CORES_ENABLED_01": {
    "Passed": true,
    "actual": "6",
    "comparator": "==",
    "expected": "6"
  },
}

```

```

"CPU_MODEL_00": {
  "Passed": true,
  "actual": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
  "comparator": "==",
  "expected": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz"
},
"CPU_MODEL_01": {
  "Passed": true,
  "actual": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
  "comparator": "==",
  "expected": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz"
},
"CPU_THREADS_00": {
  "Passed": true,
  "actual": "12",
  "comparator": "==",
  "expected": "12"
},
"CPU_THREADS_01": {
  "Passed": true,
  "actual": "12",
  "comparator": "==",
  "expected": "12"
},
"DRIVE_SIZE_BYTES_SDIMM0": {
  "Passed": true,
  "actual": "100030242816",
  "comparator": ">=",
  "expected": "100030242816"
},
"FIBRE_CHANNEL_FIRMWARE_REVISION": {
  "Passed": true,
  "actual": "FW:v7.04.00",
  "comparator": "==",
  "expected": "FW:v7.04.00"
},
"FIBRE_CHANNEL_MODEL": {
  "Passed": true,
  "actual": "QLE2672",
  "comparator": "==",
  "expected": "QLE2672"
},
"IDRAC_VERSION": {
  "Passed": true,
  "actual": "1.06.06",
  "comparator": ">=",
  "expected": "1.06.06"
},
"LIFECYCLE_VERSION": {
  "Passed": true,
  "actual": "1.0.0.5747",
  "comparator": ">=",
  "expected": "1.0.0.5747"
},
"MEMORY_GB": {
  "Passed": true,
  "actual": "32",
  "comparator": ">=",
  "expected": "32"
},
"MEMORY_MHZ_00": {
  "Passed": true,
  "actual": "1333",
  "comparator": ">=",
  "expected": "1333"
},
"MEMORY_MHZ_01": {
  "Passed": true,
  "actual": "1333",
  "comparator": ">=",
  "expected": "1333"
}

```

```

    },
    "MEMORY_MHZ_02": {
      "Passed": true,
      "actual": "1333",
      "comparator": ">=",
      "expected": "1333"
    },
    "MEMORY_MHZ_03": {
      "Passed": true,
      "actual": "1333",
      "comparator": ">=",
      "expected": "1333"
    },
    "NETWORK_DRIVER_ETH0": {
      "Passed": true,
      "actual": "bnx2x",
      "comparator": "=~",
      "expected": "^bnx2x$"
    },
    {
      "NETWORK_DRIVER_ETH1":, {...
    },
    "NETWORK_DRIVER_ETH2":, {...
    },
    "NETWORK_DRIVER_ETH3":, {...
    },
    "NETWORK_DRIVER_ETH4":, {...
    },
    "NETWORK_DRIVER_ETH5":, {...
    },
    "NODE_TYPE": {
      "Passed": true,
      "actual": "FC0025",
      "comparator": "==",
      "expected": "FC0025"
    },
    "NUM_CPU": {
      "Passed": true,
      "actual": "2",
      "comparator": "==",
      "expected": "2"
    },
    "NUM_DRIVES": {
      "Passed": true,
      "actual": "0",
      "comparator": "==",
      "expected": "0"
    },
    "NUM_DRIVES_INTERNAL": {
      "Passed": true,
      "actual": "1",
      "comparator": "==",
      "expected": "1"
    },
    "NUM_FIBRE_CHANNEL_PORTS": {
      "Passed": true,
      "actual": "4",
      "comparator": "==",
      "expected": "4"
    },
    "NVRAM_VENDOR": {
      "Passed": true,
      "actual": "",
      "comparator": "==",
      "expected": ""
    },
    "ROOT_DRIVE_REMOVABLE": {
      "Passed": true,
      "actual": "false",
      "comparator": "==",
      "expected": "false"
    }
  }

```

```

    },
    "memory": {
      "firmware_": {
        "capacity": "8323072",
        "date": "03/08/2012",
        "description": "BIOS",
        "physid": "0",
        "size": "65536",
        "vendor": "SolidFire",
        "version": "1.1.2"
      },
      "memory_DMI:1000": {
        "description": "System Memory",
        "physid": "1000",
        "size": "34359738368",
        "slot": "System board or motherboard"
      }
    },
    "network": {
      "network:0_PCI:0000:01:00.0": {
        "businfo": "pci@0000:01:00.0",
        "capacity": "1000000000",
        "clock": "33000000",
        "description": "Ethernet interface",
        "logicalname": "eth0",
        "physid": "0",
        "product": "NetXtreme II BCM57800 1/10 Gigabit Ethernet",
        "serial": "c8:1f:66:e0:97:2a",
        "vendor": "Broadcom Corporation",
        "version": "10",
        "width": "64"
      },
      "network:0_PCI:0000:41:00.0": {...},
      "network:1_PCI:0000:01:00.1": {...},
      "network:1_PCI:0000:41:00.1": {...},
      "network:2_PCI:0000:01:00.2": {...},
      "network:3_PCI:0000:01:00.3": {...}
    },
    "networkInterfaces": {
      "Bond10G": {
        "isConfigured": true,
        "isUp": true
      },
      "Bond1G": {
        "isConfigured": true,
        "isUp": true
      },
      "eth0": {
        "isConfigured": true,
        "isUp": true
      },
      "eth1": {...},
      "eth2": {...},
      "eth3": {...},
      "eth4": {...},
      "eth5": {...}
    },
    "nvram": {
      "errors": {
        "numOfErrorLogEntries": "0"
      }
    }
  }

```

```

    },
    "extended": {
      "dialogVersion": "4",
      "event": [
        {
          "name": "flushToFlash",
          "time": "2015-08-06 01:19:39",
          "value": "0"
        },
        {
          "name": "flushToFlash",
          "time": "2015-08-06 01:26:44",
          "value": "0"
        },
        {
          ... next "flushToFlash"
        },
        {
          ... next "flushToFlash"
        },
        {
          ... next "flushToFlash"
        },
        {
          ... next "flushToFlash"
        },
        {
          ... next "flushToFlash"
        },
        {
          ... next "flushToFlash"
        },
        {
          ... next "flushToFlash"
        }
      ],
      "eventOccurrences": [
        {
          "count": "740",
          "name": "flushToFlash"
        },
        {
          "count": "1",
          "name": "excessiveCurrent"
        }
      ],
      "initialCapacitance": "6.630 F",
      "initialEsr": "0.101 Ohm",
      "measurement": [
        {
          "level_0": "0",
          "level_1": "3969",
          "level_2": "4631",
          "level_3": "12875097",
          "level_4": "1789948",
          "level_5": "0",
          "level_6": "0",
          "level_7": "0",
          "level_8": "0",
          "level_9": "0",
          "name": "enterpriseFlashControllerTemperature",
          "recent": "66 C"
        },
        {
          "level_0": "0",
          "level_1": "58",
          "level_2": "1479058",
          "level_3": "12885356",
          "level_4": "308293",
          "level_5": "851",
          "level_6": "29",
          "level_7": "0",
          "level_8": "0",
          "level_9": "0",
          "name": "capacitor1And2Temperature",
          "recent": "30.69 C"
        },
        {
          ...next temp measurement

```

```

    },
    {
      ...next temp measurement
    },
    {
      ...next temp measurement
    },
    {
      "name": "voltageOfCapacitor1",
      "recent": "2.198 V"
    },
    {
      "name": "voltageOfCapacitor2",
      "recent": "2.181 V"
    },
    {
      "name": "voltageOfCapacitor3",
      "recent": "2.189 V"
    },
    {
      "name": "voltageOfCapacitor4",
      "recent": "2.195 V"
    },
    {
      "level_0": " 4442034",
      "level_1": " 6800018",
      "level_2": " 2846869",
      "level_3": " 119140",
      "level_4": " 29506",
      "level_5": " 428935",
      "level_6": " 7143",
      "level_7": " 0",
      "level_8": " 0",
      "level_9": " 0",
      "name": "capacitorPackVoltage",
      "recent": "8.763 V"
    },
    {
      "level_0": " 0",
      "level_1": " 0",
      "level_2": " 0",
      "level_3": " 0",
      "level_4": " 189",
      "level_5": " 17",
      "level_6": " 36",
      "level_7": " 0",
      "level_8": " 2",
      "level_9": " 490",
      "name": "capacitorPackVoltageAtEndOfFlushToFlash",
      "recent": "4.636 V"
    },
    {
      "name": "currentDerivedFromV3V4",
      "recent": "-0.004 A"
    },
    {
      "level_0": " 230",
      "level_1": " 482",
      "level_2": " 22",
      "level_3": " 0",
      "level_4": " 0",
      "level_5": " 0",
      "level_6": " 0",
      "level_7": " 0",
      "level_8": " 0",
      "level_9": " 0",
      "name": "derivedEnergy",
      "recent": "172 Joules"
    },
    {
      ...next voltage measurement
    },
    {
      ...next voltage measurement
    },

```



```

    {...next voltage measurement
    },
  ],
  "smartCounters": [
    {
      "name": "numberOf512ByteBlocksReadFromDdr",
      "value": "10530088847"
    },
    {
      "name": "numberOf512ByteBlocksWrittenToDdr",
      "value": "1752499453837"
    },
    {
      "name": "numberOfHostReadCommands",
      "value": "235317769"
    },
    {...next smartCounters measurement
    },
    {...next smartCounters measurement
    },
    {...next smartCounters measurement
    },
  ],
  "snapshotTime": "2015-08-20 16:30:01"
},
"firmware": {
  "activeSlotNumber": "2",
  "slot1Version": "1e5817bc",
  "slot2Version": "5fb7565c",
  "slot3Version": "1e5817bc",
  "slot4Version": "1e5817bc"
},
"identify": {
  "firmwareVersion": "5fb7565c on slot 2",
  "hardwareRevision": "B04",
  "modelName": "RMS-200",
  "serialNumber": "0000862"
},
"smart": {
  "availableSpace": "0%",
  "availableSpaceThreshold": "0%",
  "controllerBusyTimeMinutes": "6793",
  "criticalErrorVector": "0x0",
  "mediaErrors": "0",
  "numberOf512ByteBlocksRead": "10530088847",
  "numberOf512ByteBlocksWritten": "1752499439063",
  "numberOfErrorInfoLogs": "1",
  "numberOfHostReadCommands": "235317769",
  "numberOfHostWriteCommands": "126030374065",
  "numberOfPowerCycles": "709",
  "powerOnHours": "11223",
  "temperature": "324 Kelvin",
  "unsafeShutdowns": "357"
},
"origin": null,
"platform": {
  "chassisType": "R620",
  "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
  "nodeMemoryGB": 32,
  "nodeType": "FC0025"
},
"powerSupplies": {
  "PS1 status": {
    "powerSupplyFailureDetected": false,
    "powerSupplyHasAC": true,
    "powerSupplyPredictiveFailureDetected": false,
    "powerSupplyPresent": true,
    "powerSupplyPresentLastCheck": true
  },
  "PS2 status": {

```

```

        "powerSupplyFailureDetected": false,
        "powerSupplyHasAC": true,
        "powerSupplyPredictiveFailureDetected": false,
        "powerSupplyPresent": true,
        "powerSupplyPresentLastCheck": true
    },
    "storage": {
        "storage_PCI:0000:00:1f.2": {
            "businfo": "pci@0000:00:1f.2",
            "clock": "66000000",
            "description": "SATA controller",
            "physid": "1f.2",
            "product": "C600/X79 series chipset 6-Port SATA AHCI Controller",
            "vendor": "Intel Corporation",
            "version": "05",
            "width": "32"
        }
    },
    "system": {
        "ubuntu_DMI:0100": {
            "description": "Rack Mount Chassis",
            "product": "SFx010 ()",
            "serial": "HTWlDZ1",
            "vendor": "SolidFire",
            "width": "64"
        }
    },
    "temperatures": {
        "Exhaust Temp": {
            "baseUnit": "C",
            "threshold": 70,
            "value": 41
        },
        "Inlet Temp": {
            "baseUnit": "C",
            "threshold": 42,
            "value": 18
        }
    },
    "uuid": "4C4C4544-0054-5710-8031-C8C04F445A31"
},
"2": { ... },           Storage Node "2"
"3": { ... },           Storage Node "3"
"4": { ... },           Storage Node "4"
"5": { ... },           Fibre Channel Node
}

```

GetLldpInfo

The GetLldpInfo method returns a response similar to the following example.

```

{
  "id": null,
  "result": {
    "lldpInfo": {
      "lldpChassis": {
        "local-chassis": [
          {
            "chassis": [
              {
                "capability": [
                  {
                    "enabled": false,
                    "type": "Bridge"
                  }
                ]
              }
            ]
          }
        ]
      }
    }
  }
}

```

```

    },
    {
      "enabled": false,
      "type": "Router"
    },
    {
      "enabled": false,
      "type": "Wlan"
    },
    {
      "enabled": true,
      "type": "Station"
    }
  ],
  "descr": [
    {
      "value": "Element OS 11.0"
    }
  ],
  "id": [
    {
      "type": "mac",
      "value": "08:00:27:3c:0a:f4"
    }
  ],
  "mgmt-ip": [
    {
      "value": "10.0.2.15"
    },
    {
      "value": "fe80::a00:27ff:fe3c:af4"
    }
  ],
  "name": [
    {
      "value": "SF-93FF"
    }
  ]
}
],
"lldp-med": [
  {
    "capability": [
      {
        "available": true,
        "type": "Capabilities"
      },
      {
        "available": true,
        "type": "Policy"
      },
      {
        "available": true,
        "type": "Location"
      },
      {
        "available": true,
        "type": "MDI/PSE"
      },
      {
        "available": true,
        "type": "MDI/PD"
      },
      {
        "available": true,
        "type": "Inventory"
      }
    ]
  },
  "device-type": [
    {
      "value": "Generic Endpoint (Class I)"
    }
  ]
}

```

```

    }
  ],
  "inventory": [
    {
      "firmware": [
        {
          "value": "VirtualBox"
        }
      ],
      "hardware": [
        {
          "value": "1.2"
        }
      ],
      "manufacturer": [
        {
          "value": "innotek GmbH"
        }
      ],
      "model": [
        {
          "value": "VirtualBox"
        }
      ],
      "serial": [
        {
          "value": "0"
        }
      ],
      "software": [
        {
          "value": "4.14.27-solidfire2"
        }
      ]
    }
  ]
}
],
},
"lldpInterfaces": {
  "lldp": [
    {
      "interface": [
        {
          "age": "0 day, 00:01:04",
          "chassis": [
            {
              "capability": [
                {
                  "enabled": false,
                  "type": "Bridge"
                },
                {
                  "enabled": false,
                  "type": "Router"
                },
                {
                  "enabled": false,
                  "type": "Wlan"
                },
                {
                  "enabled": true,
                  "type": "Station"
                }
              ],
            }
          ],
          "descr": [
            {
              "value": "Element OS 11.0"
            }
          ]
        }
      ]
    }
  ]
}

```

```

    ],
    "id": [
      {
        "type": "mac",
        "value": "08:00:27:3c:0a:f4"
      }
    ],
    "mgmt-ip": [
      {
        "value": "10.0.2.15"
      },
      {
        "value": "fe80::a00:27ff:fe3c:af4"
      }
    ],
    "name": [
      {
        "value": "SF-93FF"
      }
    ]
  ]
},
"lldp-med": [
  {
    "capability": [
      {
        "available": true,
        "type": "Capabilities"
      },
      {
        "available": true,
        "type": "Policy"
      },
      {
        "available": true,
        "type": "Location"
      },
      {
        "available": true,
        "type": "MDI/PSE"
      },
      {
        "available": true,
        "type": "MDI/PD"
      },
      {
        "available": true,
        "type": "Inventory"
      }
    ]
  },
  "device-type": [
    {
      "value": "Generic Endpoint (Class I)"
    }
  ],
  "inventory": [
    {
      "firmware": [
        {
          "value": "VirtualBox"
        }
      ],
      "hardware": [
        {
          "value": "1.2"
        }
      ],
      "manufacturer": [
        {
          "value": "innotek GmbH"
        }
      ]
    }
  ]
}

```

```

        ],
        "model": [
            {
                "value": "VirtualBox"
            }
        ],
        "serial": [
            {
                "value": "0"
            }
        ],
        "software": [
            {
                "value": "4.14.27-solidfire2"
            }
        ]
    }
]
}
],
"name": "eth0",
"port": [
    {
        "aggregation": [
            {
                "value": "7"
            }
        ],
        "auto-negotiation": [
            {
                "advertised": [
                    {
                        "fd": true,
                        "hd": true,
                        "type": "10Base-T"
                    },
                    {
                        "fd": true,
                        "hd": true,
                        "type": "100Base-TX"
                    },
                    {
                        "fd": true,
                        "hd": false,
                        "type": "1000Base-T"
                    }
                ],
                "current": [
                    {
                        "value": "full duplex mode"
                    }
                ],
                "enabled": true,
                "supported": true
            }
        ],
        "descr": [
            {
                "value": "eth0"
            }
        ],
        "id": [
            {
                "type": "mac",
                "value": "08:00:27:3c:0a:f4"
            }
        ]
    }
],
"ttl": [
    {

```

```

        "ttl": "120"
      }
    ],
    "via": "unknown"
  },
  {
    "age": "17722 days, 17:14:28",
    "chassis": [
      {
        "capability": [
          {
            "enabled": false,
            "type": "Bridge"
          },
          {
            "enabled": false,
            "type": "Router"
          },
          {
            "enabled": false,
            "type": "Wlan"
          },
          {
            "enabled": true,
            "type": "Station"
          }
        ],
        "descr": [
          {
            "value": "Element OS 11.0"
          }
        ],
        "id": [
          {
            "type": "mac",
            "value": "08:00:27:3c:0a:f4"
          }
        ],
        "mgmt-ip": [
          {
            "value": "10.0.2.15"
          },
          {
            "value": "fe80::a00:27ff:fe3c:af4"
          }
        ],
        "name": [
          {
            "value": "SF-93FF"
          }
        ]
      }
    ],
    "lldp-med": [
      {
        "capability": [
          {
            "available": true,
            "type": "Capabilities"
          },
          {
            "available": true,
            "type": "Policy"
          },
          {
            "available": true,
            "type": "Location"
          },
          {
            "available": true,
            "type": "MDI/PSE"
          }
        ]
      }
    ]
  }
]

```

```

    },
    {
      "available": true,
      "type": "MDI/PD"
    },
    {
      "available": true,
      "type": "Inventory"
    }
  ],
  "device-type": [
    {
      "value": "Generic Endpoint (Class I)"
    }
  ],
  "inventory": [
    {
      "firmware": [
        {
          "value": "VirtualBox"
        }
      ],
      "hardware": [
        {
          "value": "1.2"
        }
      ],
      "manufacturer": [
        {
          "value": "innotek GmbH"
        }
      ],
      "model": [
        {
          "value": "VirtualBox"
        }
      ],
      "serial": [
        {
          "value": "0"
        }
      ],
      "software": [
        {
          "value": "4.14.27-solidfire2"
        }
      ]
    }
  ]
},
{
  "name": "eth1",
  "port": [
    {
      "aggregation": [
        {
          "value": "7"
        }
      ],
      "auto-negotiation": [
        {
          "advertised": [
            {
              "fd": true,
              "hd": true,
              "type": "10Base-T"
            },
            {
              "fd": true,
              "hd": true,
              "type": "100Base-TX"
            }
          ]
        }
      ]
    }
  ]
}

```



```

        },
        {
            "fd": true,
            "hd": false,
            "type": "1000Base-T"
        }
    ],
    "current": [
        {
            "value": "unknown"
        }
    ],
    "enabled": true,
    "supported": true
}
],
"descr": [
    {
        "value": "eth1"
    }
]
],
"id": [
    {
        "type": "mac",
        "value": "08:00:27:36:79:78"
    }
]
}
],
"ttl": [
    {
        "ttl": "120"
    }
]
],
"via": "unknown"
},
{
    "age": "0 day, 00:01:01",
    "chassis": [
        {
            "capability": [
                {
                    "enabled": false,
                    "type": "Bridge"
                },
                {
                    "enabled": false,
                    "type": "Router"
                },
                {
                    "enabled": false,
                    "type": "Wlan"
                },
                {
                    "enabled": true,
                    "type": "Station"
                }
            ],
            "descr": [
                {
                    "value": "Element OS 11.0"
                }
            ],
            "id": [
                {
                    "type": "mac",
                    "value": "08:00:27:3c:0a:f4"
                }
            ],
            "mgmt-ip": [

```

```

        "value": "10.0.2.15"
      },
      {
        "value": "fe80::a00:27ff:fe3c:af4"
      }
    ],
    "name": [
      {
        "value": "SF-93FF"
      }
    ]
  }
],
"lldp-med": [
  {
    "capability": [
      {
        "available": true,
        "type": "Capabilities"
      },
      {
        "available": true,
        "type": "Policy"
      },
      {
        "available": true,
        "type": "Location"
      },
      {
        "available": true,
        "type": "MDI/PSE"
      },
      {
        "available": true,
        "type": "MDI/PD"
      },
      {
        "available": true,
        "type": "Inventory"
      }
    ],
    "device-type": [
      {
        "value": "Generic Endpoint (Class I)"
      }
    ],
    "inventory": [
      {
        "firmware": [
          {
            "value": "VirtualBox"
          }
        ],
        "hardware": [
          {
            "value": "1.2"
          }
        ],
        "manufacturer": [
          {
            "value": "innotek GmbH"
          }
        ],
        "model": [
          {
            "value": "VirtualBox"
          }
        ],
        "serial": [
          {
            "value": "0"
          }
        ]
      }
    ]
  }
]

```

```

    }
  ],
  "software": [
    {
      "value": "4.14.27-solidfire2"
    }
  ]
}
],
},
"name": "eth2",
"port": [
  {
    "aggregation": [
      {
        "value": "6"
      }
    ],
    "auto-negotiation": [
      {
        "advertised": [
          {
            "fd": true,
            "hd": true,
            "type": "10Base-T"
          },
          {
            "fd": true,
            "hd": true,
            "type": "100Base-TX"
          },
          {
            "fd": true,
            "hd": false,
            "type": "1000Base-T"
          }
        ],
        "current": [
          {
            "value": "full duplex mode"
          }
        ],
        "enabled": true,
        "supported": true
      }
    ],
    "descr": [
      {
        "value": "eth2"
      }
    ],
    "id": [
      {
        "type": "mac",
        "value": "08:00:27:fc:f0:a9"
      }
    ]
  }
],
"ttl": [
  {
    "ttl": "120"
  }
],
"via": "LLDP"
},
{
  "age": "0 day, 00:01:01",
  "chassis": [
    {

```

```

    "capability": [
      {
        "enabled": false,
        "type": "Bridge"
      },
      {
        "enabled": false,
        "type": "Router"
      },
      {
        "enabled": false,
        "type": "Wlan"
      },
      {
        "enabled": true,
        "type": "Station"
      }
    ],
    "descr": [
      {
        "value": "Element OS 11.0"
      }
    ],
    "id": [
      {
        "type": "mac",
        "value": "08:00:27:3c:0a:f4"
      }
    ],
    "mgmt-ip": [
      {
        "value": "10.0.2.15"
      },
      {
        "value": "fe80::a00:27ff:fe3c:af4"
      }
    ],
    "name": [
      {
        "value": "SF-93FF"
      }
    ]
  },
  "lldp-med": [
    {
      "capability": [
        {
          "available": true,
          "type": "Capabilities"
        },
        {
          "available": true,
          "type": "Policy"
        },
        {
          "available": true,
          "type": "Location"
        },
        {
          "available": true,
          "type": "MDI/PSE"
        },
        {
          "available": true,
          "type": "MDI/PD"
        },
        {
          "available": true,
          "type": "Inventory"
        }
      ]
    }
  ]
}

```

```

],
"device-type": [
  {
    "value": "Generic Endpoint (Class I)"
  }
],
"inventory": [
  {
    "firmware": [
      {
        "value": "VirtualBox"
      }
    ],
    "hardware": [
      {
        "value": "1.2"
      }
    ],
    "manufacturer": [
      {
        "value": "innotek GmbH"
      }
    ],
    "model": [
      {
        "value": "VirtualBox"
      }
    ],
    "serial": [
      {
        "value": "0"
      }
    ],
    "software": [
      {
        "value": "4.14.27-solidfire2"
      }
    ]
  }
]
},
],
"name": "eth3",
"port": [
  {
    "aggregation": [
      {
        "value": "6"
      }
    ],
    "auto-negotiation": [
      {
        "advertised": [
          {
            "fd": true,
            "hd": true,
            "type": "10Base-T"
          },
          {
            "fd": true,
            "hd": true,
            "type": "100Base-TX"
          },
          {
            "fd": true,
            "hd": false,
            "type": "1000Base-T"
          }
        ]
      }
    ],
    "current": [
      {

```

```

        "value": "full duplex mode"
      }
    ],
    "enabled": true,
    "supported": true
  }
],
"descr": [
  {
    "value": "eth3"
  }
],
"id": [
  {
    "type": "mac",
    "value": "08:00:27:2c:e4:f8"
  }
]
}
],
"ttl": [
  {
    "ttl": "120"
  }
],
"via": "LLDP"
}
]
}
],
"lldpNeighbors": {
  "lldp": [
    {
      "interface": [
        {
          "age": "0 day, 00:04:34",
          "chassis": [
            {
              "capability": [
                {
                  "enabled": true,
                  "type": "Bridge"
                },
                {
                  "enabled": true,
                  "type": "Router"
                },
                {
                  "enabled": true,
                  "type": "Wlan"
                },
                {
                  "enabled": false,
                  "type": "Station"
                }
              ],
              "descr": [
                {
                  "value": "x86_64"
                }
              ],
              "id": [
                {
                  "type": "mac",
                  "value": "50:7b:9d:2b:36:84"
                }
              ],
              "mgmt-ip": [
                {
                  "value": "192.168.100.1"
                }
              ]
            }
          ]
        }
      ]
    }
  ]
}

```

```

        },
        {
            "value": "fe80::a58e:843:952e:d8eb"
        }
    ],
    "name": [
        {
            "value": "ConventionalWisdom.wlan.netapp.com"
        }
    ]
}
],
"name": "eth2",
"port": [
    {
        "auto-negotiation": [
            {
                "current": [
                    {
                        "value": "full duplex mode"
                    }
                ],
                "enabled": false,
                "supported": false
            }
        ],
        "descr": [
            {
                "value": "vboxnet1"
            }
        ],
        "id": [
            {
                "type": "mac",
                "value": "0a:00:27:00:00:01"
            }
        ],
        "ttl": [
            {
                "value": "120"
            }
        ]
    }
],
"rid": "2",
"via": "LLDP"
},
{
    "age": "0 day, 00:01:01",
    "chassis": [
        {
            "capability": [
                {
                    "enabled": false,
                    "type": "Bridge"
                },
                {
                    "enabled": false,
                    "type": "Router"
                },
                {
                    "enabled": false,
                    "type": "Wlan"
                },
                {
                    "enabled": true,
                    "type": "Station"
                }
            ],
            "descr": [
                {

```

```

        "value": "Element OS 11.0"
      }
    ],
    "id": [
      {
        "type": "mac",
        "value": "08:00:27:3c:0a:f4"
      }
    ],
    "mgmt-ip": [
      {
        "value": "10.0.2.15"
      },
      {
        "value": "fe80::a00:27ff:fe3c:af4"
      }
    ],
    "name": [
      {
        "value": "SF-93FF"
      }
    ]
  ]
},
"lldp-med": [
  {
    "capability": [
      {
        "available": true,
        "type": "Capabilities"
      },
      {
        "available": true,
        "type": "Policy"
      },
      {
        "available": true,
        "type": "Location"
      },
      {
        "available": true,
        "type": "MDI/PSE"
      },
      {
        "available": true,
        "type": "MDI/PD"
      },
      {
        "available": true,
        "type": "Inventory"
      }
    ],
    "device-type": [
      {
        "value": "Generic Endpoint (Class I)"
      }
    ],
    "inventory": [
      {
        "firmware": [
          {
            "value": "VirtualBox"
          }
        ],
        "hardware": [
          {
            "value": "1.2"
          }
        ],
        "manufacturer": [
          {

```



```

        "value": "innotek GmbH"
      }
    ],
    "model": [
      {
        "value": "VirtualBox"
      }
    ],
    "serial": [
      {
        "value": "0"
      }
    ],
    "software": [
      {
        "value": "4.14.27-solidfire2"
      }
    ]
  ]
}
],
"name": "eth2",
"port": [
  {
    "aggregation": [
      {
        "value": "6"
      }
    ],
    "auto-negotiation": [
      {
        "advertised": [
          {
            "fd": true,
            "hd": true,
            "type": "10Base-T"
          },
          {
            "fd": true,
            "hd": true,
            "type": "100Base-TX"
          },
          {
            "fd": true,
            "hd": false,
            "type": "1000Base-T"
          }
        ],
        "current": [
          {
            "value": "full duplex mode"
          }
        ],
        "enabled": true,
        "supported": true
      }
    ],
    "descr": [
      {
        "value": "eth3"
      }
    ],
    "id": [
      {
        "type": "mac",
        "value": "08:00:27:2c:e4:f8"
      }
    ],
    "ttl": [
      {

```

```

        "value": "120"
      }
    ]
  },
  "rid": "1",
  "via": "LLDP"
},
{
  "age": "0 day, 00:04:34",
  "chassis": [
    {
      "capability": [
        {
          "enabled": true,
          "type": "Bridge"
        },
        {
          "enabled": true,
          "type": "Router"
        },
        {
          "enabled": true,
          "type": "Wlan"
        },
        {
          "enabled": false,
          "type": "Station"
        }
      ],
      "descr": [
        {
          "value": "x86_64"
        }
      ],
      "id": [
        {
          "type": "mac",
          "value": "50:7b:9d:2b:36:84"
        }
      ],
      "mgmt-ip": [
        {
          "value": "192.168.100.1"
        },
        {
          "value": "fe80::a58e:843:952e:d8eb"
        }
      ],
      "name": [
        {
          "value": ""
        }
      ]
    }
  ],
  "name": "eth3",
  "port": [
    {
      "auto-negotiation": [
        {
          "current": [
            {
              "value": "full duplex mode"
            }
          ],
          "enabled": false,
          "supported": false
        }
      ],
      "descr": [

```

```

        {
          "value": "vboxnet1"
        }
      ],
      "id": [
        {
          "type": "mac",
          "value": "0a:00:27:00:00:01"
        }
      ],
      "ttl": [
        {
          "value": "120"
        }
      ]
    }
  ],
  "rid": "2",
  "via": "LLDP"
},
{
  "age": "0 day, 00:01:01",
  "chassis": [
    {
      "capability": [
        {
          "enabled": false,
          "type": "Bridge"
        },
        {
          "enabled": false,
          "type": "Router"
        },
        {
          "enabled": false,
          "type": "Wlan"
        },
        {
          "enabled": true,
          "type": "Station"
        }
      ],
      "descr": [
        {
          "value": "Element OS 11.0"
        }
      ],
      "id": [
        {
          "type": "mac",
          "value": "08:00:27:3c:0a:f4"
        }
      ],
      "mgmt-ip": [
        {
          "value": "10.0.2.15"
        },
        {
          "value": "fe80::a00:27ff:fe3c:af4"
        }
      ],
      "name": [
        {
          "value": "SF-93FF"
        }
      ]
    }
  ],
  "lldp-med": [
    {
      "capability": [

```

```

        {
            "available": true,
            "type": "Capabilities"
        },
        {
            "available": true,
            "type": "Policy"
        },
        {
            "available": true,
            "type": "Location"
        },
        {
            "available": true,
            "type": "MDI/PSE"
        },
        {
            "available": true,
            "type": "MDI/PD"
        },
        {
            "available": true,
            "type": "Inventory"
        }
    ],
    "device-type": [
        {
            "value": "Generic Endpoint (Class I)"
        }
    ],
    "inventory": [
        {
            "firmware": [
                {
                    "value": "VirtualBox"
                }
            ],
            "hardware": [
                {
                    "value": "1.2"
                }
            ],
            "manufacturer": [
                {
                    "value": "innotek GmbH"
                }
            ],
            "model": [
                {
                    "value": "VirtualBox"
                }
            ],
            "serial": [
                {
                    "value": "0"
                }
            ],
            "software": [
                {
                    "value": "4.14.27-solidfire2"
                }
            ]
        }
    ]
}
],
"name": "eth3",
"port": [
    {
        "aggregation": [

```

```

        "value": "6"
    },
    "auto-negotiation": [
        {
            "advertised": [
                {
                    "fd": true,
                    "hd": true,
                    "type": "10Base-T"
                },
                {
                    "fd": true,
                    "hd": true,
                    "type": "100Base-TX"
                },
                {
                    "fd": true,
                    "hd": false,
                    "type": "1000Base-T"
                }
            ],
            "current": [
                {
                    "value": "1000BaseTFD"
                }
            ],
            "enabled": true,
            "supported": true
        }
    ],
    "descr": [
        {
            "value": "eth2"
        }
    ],
    "id": [
        {
            "type": "mac",
            "value": "08:00:27:fc:f0:a9"
        }
    ],
    "ttl": [
        {
            "value": "120"
        }
    ]
},
{
    "rid": "1",
    "via": "LLDP"
}
]
}
}
}
}
}
```

GetNetworkConfig

The `GetNetworkConfig` method returns a response similar to the following example.

```
{
  "id": 1,
  "result": {
    "network": {
```

```

    "Bond1G": {
        "#default": false,
        "address": "10.1.1.0",
        "auto": true,
        "bond-downdelay": "0",
        "bond-fail_over_mac": "None",
        "bond-miimon": "100",
        "bond-mode": "ActivePassive",
        "bond-primary_reselect": "Failure",
        "bond-slaves": "eth0 eth1",
        "bond-updelay": "200",
        "dns-nameservers": "10.1.1.0, 10.1.1.0",
        "dns-search": "ten.test.company.net., company.net.",
        "family": "inet",
        "gateway": "10.1.1.0",
        "linkSpeed": 10000,
        "macAddress": "c8:1f:66:ee:59:b9",
        "macAddressPermanent": "00:00:00:00:00:00",
        "method": "static",
        "mtu": "9000",
        "netmask": "255.255.240.0",
        "network": "10.1.1.0",
        "physical": {
            "address": "10.1.1.0",
            "macAddress": "c8:1f:66:ee:59:b9",
            "macAddressPermanent": "00:00:00:00:00:00",
            "mtu": "9000",
            "netmask": "255.255.240.0",
            "network": "10.1.1.0",
            "upAndRunning": true
        },
        "routes": [],
        "status": "UpAndRunning",
        "symmetricRouteRules": [
            "ip route add 10.1.1.1/20 dev Bond1G src 10.1.2.2
table Bond1G",
            "ip rule add from 10.1.1.1 table Bond1G",
            "ip route add default via 10.1.1.254"
        ],
        "upAndRunning": true,
        "virtualNetworkTag": "0"
    },
    "Bond1G": {
        "#default": true,
        "address": "10.1.1.0",
        "addressV6": "",
        "auto": true,
        "bond-downdelay": "0",
        "bond-fail_over_mac": "None",
        "bond-miimon": "100",
        "bond-mode": "ActivePassive",
        "bond-primary_reselect": "Failure",
        "bond-slaves": "eth2 eth3",
        "bond-updelay": "200",
        "dns-nameservers": "10.1.1.0, 10.1.1.0",
        "dns-search": "ten.test.company.net., company.net.",
        "family": "inet",
        "gateway": "10.1.1.254",
        "gatewayV6": "",
        "linkSpeed": 1000,
        "macAddress": "c8:1f:66:ee:59:bd",
        "macAddressPermanent": "00:00:00:00:00:00",
        "method": "static",
        "mtu": "1500",
        "netmask": "255.255.240.0",
        "network": "10.1.1.0",
        "physical": {
            "address": "10.1.1.0",
            "macAddress": "c8:1f:66:ee:59:bd",
            "macAddressPermanent": "00:00:00:00:00:00",
            "mtu": "1500",

```

```

        "netmask": "255.255.240.0",
        "network": "10.1.1.0",
        "upAndRunning": true
    },
    "routes": [],
    "status": "UpAndRunning",
    "symmetricRouteRules": [
        "ip route add 10.1.1.1/20 dev Bond1G src 10.1.2.2
table Bond1G",
        "ip rule add from 10.1.1.1 table Bond1G",
        "ip route add default via 10.1.1.254"
    ],
    "upAndRunning": true,
    "virtualNetworkTag": "0"
},
"eth0": {
    "auto": true,
    "bond-master": "Bond10G",
    "family": "inet",
    "linkSpeed": 10000,
    "macAddress": "c8:1f:66:ee:59:b9",
    "macAddressPermanent": "c8:1f:66:ee:59:b9",
    "method": "bond",
    "physical": {
        "address": "0.0.0.0",
        "macAddress": "c8:1f:66:ee:59:b9",
        "macAddressPermanent": "c8:1f:66:ee:59:b9",
        "netmask": "N/A",
        "network": "N/A",
        "upAndRunning": true
    },
    "status": "UpAndRunning",
    "upAndRunning": true
},
"eth1": {
    "auto": true,
    "bond-master": "Bond10G",
    "family": "inet",
    "linkSpeed": 10000,
    "macAddress": "c8:1f:66:ee:59:b9",
    "macAddressPermanent": "c8:1f:66:ee:59:bb",
    "method": "bond",
    "physical": {
        "address": "0.0.0.0",
        "macAddress": "c8:1f:66:ee:59:b9",
        "macAddressPermanent": "c8:1f:66:ee:59:bb",
        "netmask": "N/A",
        "network": "N/A",
        "upAndRunning": true
    },
    "status": "UpAndRunning",
    "upAndRunning": true
},
"eth2": {
    "auto": true,
    "bond-master": "Bond1G",
    "family": "inet",
    "linkSpeed": 1000,
    "macAddress": "c8:1f:66:ee:59:bd",
    "macAddressPermanent": "c8:1f:66:ee:59:bd",
    "method": "bond",
    "physical": {
        "address": "0.0.0.0",
        "macAddress": "c8:1f:66:ee:59:bd",
        "macAddressPermanent": "c8:1f:66:ee:59:bd",
        "netmask": "N/A",
        "network": "N/A",
        "upAndRunning": true
    },
    "status": "UpAndRunning",
    "upAndRunning": true
}

```

```

    },
    "eth3": {
      "auto": true,
      "bond-master": "Bond1G",
      "family": "inet",
      "linkSpeed": 1000,
      "macAddress": "c8:1f:66:ee:59:bd",
      "macAddressPermanent": "c8:1f:66:ee:59:bf",
      "method": "bond",
      "physical": {
        "address": "0.0.0.0",
        "macAddress": "c8:1f:66:ee:59:bd",
        "macAddressPermanent": "c8:1f:66:ee:59:bf",
        "netmask": "N/A",
        "network": "N/A",
        "upAndRunning": true
      },
      "status": "UpAndRunning",
      "upAndRunning": true
    },
    "lo": {
      "auto": true,
      "family": "inet",
      "linkSpeed": 0,
      "macAddress": "00:00:00:00:00:00",
      "macAddressPermanent": "00:00:00:00:00:00",
      "method": "loopback",
      "physical": {
        "address": "0.0.0.0",
        "macAddress": "00:00:00:00:00:00",
        "macAddressPermanent": "00:00:00:00:00:00",
        "netmask": "N/A",
        "network": "N/A",
        "upAndRunning": true
      },
      "status": "UpAndRunning",
      "upAndRunning": true
    }
  },
  }
}

```

GetNodeHardwareInfo (output for iSCSI)

The GetNodeHardwareInfo method for iSCSI returns a response similar to the following example.

```

{
  "id": 1,
  "result": {
    "nodeHardwareInfo": {
      "bus": {
        "core_DMI:0200": {
          "description": "Motherboard",
          "physid": "0",
          "product": "0H47HH",
          "serial": "..CN7475141I0271.",
          "vendor": "SolidFire",
          "version": "A07"
        }
      }
    },
    "driveHardware": [
      {
        "canonicalName": "sdb",
        "connected": true,
        "dev": 2064,
        "devPath": "/dev/slot0",
        "driveType": "Slice",
        "lifeRemainingPercent": 98,

```



```

        "lifetimeReadBytes": 0,
        "lifetimeWriteBytes": 14383412879360,
        "name": "scsi-SATA_SAMSUNG_MZ7GE24S1M9NWAG601096",
        "path": "/dev/sdb",
        "pathLink": "/dev/slot0",
        "powerOnHours": 14311,
        "product": "SAMSUNG MZ7GE240HMGR-00003",
        "reallocatedSectors": 0,
        "reserveCapacityPercent": 100,
        "scsiCompatId": "scsi-
SATA_SAMSUNG_MZ7GE24S1M9NWAG601096",
        "scsiState": "Running",
        "securityAtMaximum": false,
        "securityEnabled": false,
        "securityFrozen": false,
        "securityLocked": false,
        "securitySupported": true,
        "serial": "S1M9NWAG601096",
        "size": 240057409536,
        "slot": 0,
        "uuid": "97daf7b1-06e2-0d64-8494-cd5c73d38ac4",
        "vendor": "Samsung",
        "version": "EXT1303Q"
    },
    {
        "canonicalName": "sdh",
        "connected": true,
        "dev": 2160,
        "devPath": "/dev/slot1",
        "driveType": "Block",
        "lifeRemainingPercent": 99,
        "lifetimeReadBytes": 0,
        "lifetimeWriteBytes": 727843479552,
        "name": "scsi-SATA_SAMSUNG_MZ7GE24S1M9NWAG601479",
        "path": "/dev/sdh",
        "pathLink": "/dev/slot1",
        "powerOnHours": 14311,
        "product": "SAMSUNG MZ7GE240HMGR-00003",
        "reallocatedSectors": 0,
        "reserveCapacityPercent": 100,
        "scsiCompatId": "scsi-
SATA_SAMSUNG_MZ7GE24S1M9NWAG601479",
        "scsiState": "Running",
        "securityAtMaximum": false,
        "securityEnabled": false,
        "securityFrozen": false,
        "securityLocked": false,
        "securitySupported": true,
        "serial": "S1M9NWAG601479",
        "size": 240057409536,
        "slot": 1,
        "uuid": "dd3dc3cf-3649-a817-e273-0dfce5e40d3a",
        "vendor": "Samsung",
        "version": "EXT1303Q"
    }
]

```

GetNodeHardwareInfo (output for Fibre Channel nodes)

The GetNodeHardwareInfo method for Fibre Channel nodes returns a response similar to the following example.

```

{
  "id": null,
  "result": {
    "nodeHardwareInfo": {
      "bus": {

```

```

"core_DMI:0200": {
  "description": "Motherboard",
  "physid": "0",
  "product": "0H47HH",
  "serial": "..CN747513AA0541.",
  "version": "A07"
},
"fiber:0_PCI:0000:04:00.0": {
  "businfo": "pci@0000:04:00.0",
  "clock": "33000000",
  "description": "Fibre Channel",
  "physid": "0",
  "product": "ISP8324-based 16Gb Fibre Channel to PCI Express Adapter",
  "vendor": "QLogic Corp.",
  "version": "02",
  "width": "64"
},
"fiber:0_PCI:0000:42:00.0": {
  "businfo": "pci@0000:42:00.0",
  "clock": "33000000",
  "description": "Fibre Channel",
  "physid": "0",
  "product": "ISP8324-based 16Gb Fibre Channel to PCI Express Adapter",
  "vendor": "QLogic Corp.",
  "version": "02",
  "width": "64"
},
"fiber:1_PCI:0000:04:00.1": {
  "businfo": "pci@0000:04:00.1",
  "clock": "33000000",
  "description": "Fibre Channel",
  "physid": "0.1",
  "product": "ISP8324-based 16Gb Fibre Channel to PCI Express Adapter",
  "vendor": "QLogic Corp.",
  "version": "02",
  "width": "64"
},
"fiber:1_PCI:0000:42:00.1": {
  "businfo": "pci@0000:42:00.1",
  "clock": "33000000",
  "description": "Fibre Channel",
  "physid": "0.1",
  "product": "ISP8324-based 16Gb Fibre Channel to PCI Express Adapter",
  "vendor": "QLogic Corp.",
  "version": "02",
  "width": "64"
}
},
"fans": {
  "Fan1A RPM": {
    "baseUnit": "RPM",
    "threshold": 840,
    "value": 3360
  },
  "Fan1B RPM": {
    "baseUnit": "RPM",
    "threshold": 840,
    "value": 3120
  }
},
"fibreChannelPorts": [
  {
    "firmware": "7.04.00 (d0d5)",
    "hbaPort": 1,
    "internalPortID": 2,
    "model": "QLE2672",
    "nPortID": "0x060019",
    "nodeID": 6,
    "pciSlot": 3,
    "serial": "BFE1335E04217",
    "speed": "8 Gbit",

```

```

"state": "Online",
"switchWwn": "20:01:00:2a:6a:9c:71:01",
"wwnn": "5f:47:ac:c8:30:26:c9:00",
"wwpn": "5f:47:ac:c0:30:26:c9:0a"
},
{
  "firmware": "7.04.00 (d0d5)",
  "hbaPort": 2,
  "internalPortID": 3,
  "model": "QLE2672",
  "nPortID": "0xc70019",
  "nodeID": 6,
  "pciSlot": 3,
  "serial": "BFE1335E04217",
  "speed": "8 Gbit",
  "state": "Online",
  "switchWwn": "20:01:00:2a:6a:98:a3:41",
  "wwnn": "5f:47:ac:c8:30:26:c9:00",
  "wwpn": "5f:47:ac:c0:30:26:c9:0b"
},
{
  "firmware": "7.04.00 (d0d5)",
  "hbaPort": 1,
  "internalPortID": 0,
  "model": "QLE2672",
  "nPortID": "0xc70017",
  "nodeID": 6,
  "pciSlot": 2,
  "serial": "BFE1341E09515",
  "speed": "8 Gbit",
  "state": "Online",
  "switchWwn": "20:01:00:2a:6a:98:a3:41",
  "wwnn": "5f:47:ac:c8:30:26:c9:00",
  "wwpn": "5f:47:ac:c0:30:26:c9:08"
},
{
  "firmware": "7.04.00 (d0d5)",
  "hbaPort": 2,
  "internalPortID": 1,
  "model": "QLE2672",
  "nPortID": "0x060017",
  "nodeID": 6,
  "pciSlot": 2,
  "serial": "BFE1341E09515",
  "speed": "8 Gbit",
  "state": "Online",
  "switchWwn": "20:01:00:2a:6a:9c:71:01",
  "wwnn": "5f:47:ac:c8:30:26:c9:00",
  "wwpn": "5f:47:ac:c0:30:26:c9:09"
}
],
"memory": {
  "firmware_": {
    "capacity": "8323072",
    "date": "08/29/2013",
    "description": "BIOS",
    "physid": "0",
    "size": "65536",
    "version": "2.0.19"
  },
  "memory_DMI:1000": {
    "description": "System Memory",
    "physid": "1000",
    "size": "34359738368",
    "slot": "System board or motherboard"
  }
},
"network": {
  "network:0_": {
    "description": "Ethernet interface",
    "logicalname": "Bond1G",

```

```

"physid": "1",
"serial": "c8:1f:66:df:04:da"
},
"network:0_PCI:0000:01:00.0": {
"businfo": "pci@0000:01:00.0",
"capacity": "1000000000",
"clock": "33000000",
"description": "Ethernet interface",
"logicalname": "eth0",
"physid": "0",
"product": "NetXtreme II BCM57800 1/10 Gigabit Ethernet",
"serial": "c8:1f:66:df:04:d6",
"vendor": "Broadcom Corporation",
"version": "10",
"width": "64"
},
"network:0_PCI:0000:41:00.0": {
"businfo": "pci@0000:41:00.0",
"capacity": "1000000000",
"clock": "33000000",
"description": "Ethernet interface",
"logicalname": "eth4",
"physid": "0",
"product": "NetXtreme II BCM57810 10 Gigabit Ethernet",
"serial": "00:0a:f7:41:7a:30",
"vendor": "Broadcom Corporation",
"version": "10",
"width": "64"
},
"network:1_": {
"description": "Ethernet interface",
"logicalname": "Bond10G",
"physid": "2",
"serial": "c8:1f:66:df:04:d6"
},
"network:1_PCI:0000:01:00.1": {
"businfo": "pci@0000:01:00.1",
"capacity": "1000000000",
"clock": "33000000",
"description": "Ethernet interface",
"logicalname": "eth1",
"physid": "0.1",
"product": "NetXtreme II BCM57800 1/10 Gigabit Ethernet",
"serial": "c8:1f:66:df:04:d8",
"vendor": "Broadcom Corporation",
"version": "10",
"width": "64"
},
"network:1_PCI:0000:41:00.1": {
"businfo": "pci@0000:41:00.1",
"capacity": "1000000000",
"clock": "33000000",
"description": "Ethernet interface",
"logicalname": "eth5",
"physid": "0.1",
"product": "NetXtreme II BCM57810 10 Gigabit Ethernet",
"serial": "00:0a:f7:41:7a:32",
"vendor": "Broadcom Corporation",
"version": "10",
"width": "64"
},
"network:2_PCI:0000:01:00.2": {
"businfo": "pci@0000:01:00.2",
"capacity": "1000000000",
"clock": "33000000",
"description": "Ethernet interface",
"logicalname": "eth2",
"physid": "0.2",
"product": "NetXtreme II BCM57800 1/10 Gigabit Ethernet",
"serial": "c8:1f:66:df:04:da",
"size": "1000000000",

```

```

"vendor": "Broadcom Corporation",
"version": "10",
"width": "64"
},
"network:3_PCI:0000:01:00.3": {
"businfo": "pci@0000:01:00.3",
"capacity": "1000000000",
"clock": "33000000",
"description": "Ethernet interface",
"logicalname": "eth3",
"physid": "0.3",
"product": "NetXtreme II BCM57800 1/10 Gigabit Ethernet",
"serial": "c8:1f:66:df:04:dc",
"size": "1000000000",
"vendor": "Broadcom Corporation",
"version": "10",
"width": "64"
}
},
"networkInterfaces": {
"Bond10G": {
"isConfigured": true,
"isUp": true
},
"Bond1G": {
"isConfigured": true,
"isUp": true
},
"eth0": {
"isConfigured": true,
"isUp": true
},
"eth1": {
"isConfigured": true,
"isUp": true
},
"eth2": {
"isConfigured": true,
"isUp": true
},
"eth3": {
"isConfigured": true,
"isUp": true
},
"eth4": {
"isConfigured": true,
"isUp": true
},
"eth5": {
"isConfigured": true,
"isUp": true
}
},
"platform": {
"chassisType": "R620",
"cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @ 2.50GHz",
"nodeMemoryGB": 32,
"nodeType": "SFFC"
},
"powerSupplies": {
"PS1 status": {
"powerSupplyFailureDetected": false,
"powerSupplyHasAC": true,
"powerSupplyPredictiveFailureDetected": false,
"powerSupplyPresent": true
},
"PS2 status": {
"powerSupplyFailureDetected": false,
"powerSupplyHasAC": true,
"powerSupplyPredictiveFailureDetected": false,
"powerSupplyPresent": true
}
}
}

```

```

    },
    "storage": {
      "storage_PCI:0000:00:1f.2": {
        "businfo": "pci@0000:00:1f.2",
        "clock": "66000000",
        "description": "SATA controller",
        "physid": "1f.2",
        "product": "C600/X79 series chipset 6-Port SATA AHCI Controller",
        "vendor": "Intel Corporation",
        "version": "05",
        "width": "32"
      }
    },
    "system": {
      "fcv-2_DMI:0100": {
        "description": "Rack Mount Chassis",
        "product": "(SKU=NotProvided;ModelName=)",
        "serial": "HTX1DZ1",
        "width": "64"
      }
    },
    "temperatures": {
      "Exhaust Temp": {
        "baseUnit": "C",
        "threshold": 70,
        "value": 38
      },
      "Inlet Temp": {
        "baseUnit": "C",
        "threshold": 42,
        "value": 13
      }
    },
    "uuid": "4C4C4544-004D-5310-8052-C4C04F335431"
  }
}

```

GetNvramInfo

The `GetNvramInfo` method returns a response similar to the following example.

```

{
  id: 1,
  result: {
    nvramInfo: {
      details: {
        errors: {
          numOfErrorLogEntries: "0"
        },
        extended: {
          dialogVersion: "4",
          event: [
            {
              name: "flushToFlash",
              time: "2014-02-24 20:30:28",
              value: "0"
            },
            {
              name: "flushToFlash",
              time: "1946-02-06 17:16:42",
              value: "0"
            },
            {
              name: "flushToFlash",
              time: "2014-02-25 00:48:06",

```

```

        value: "0"
      },
      {
        name: "flushToFlash",
        time: "2014-02-25 15:44:07",
        value: "0"
      },
      {
        name: "flushToFlash",
        time: "2014-03-17 17:21:46",
        value: "0"
      },
      {
        name: "flushToFlash",
        time: "2014-03-17 17:59:30",
        value: "0"
      },
      {
        name: "flushToFlash",
        time: "2014-03-17 18:06:27",
        value: "0"
      },
      {
        name: "flushToFlash",
        time: "2014-03-17 21:43:17",
        value: "0"
      },
      {
        name: "excessiveCurrent",
        time: "2014-02-25 00:00:29",
        value: "39"
      },
      {
        name: "excessiveCurrent",
        time: "2014-03-01 00:00:24",
        value: "23"
      }
    ],
    eventOccurrences: [
      {
        count: "15",
        name: "flushToFlash"
      },
      {
        count: "2",
        name: "excessiveCurrent"
      }
    ],
    initialCapacitance: "6.653 F",
    initialEsr: "0.097 Ohm",
    measurement: [
      {
        level_0: " 0",
        level_1: " 112",
        level_2: " 670919",
        level_3: " 455356",
        level_4: " 90215",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "enterpriseFlashControllerTemperature",
        recent: "64 C"
      },
      {
        level_0: " 0",
        level_1: " 27",
        level_2: " 456896",
        level_3: " 717565",
        level_4: " 39422",
        level_5: " 2692",

```

```

        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "capacitor1And2Temperature",
        recent: "28.64 C"
    },
    {
        level_0: " 0",
        level_1: " 2080",
        level_2: " 907196",
        level_3: " 280178",
        level_4: " 26539",
        level_5: " 609",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "capacitor3And4Temperature",
        recent: "28.60 C"
    },
    {
        errorPeriod: {
            duration: "24",
            startTime: "2014-02-06 00:23:54",
            worst: "8"
        },
        level_0: " 0",
        level_1: " 839",
        level_2: " 272794",
        level_3: " 404758",
        level_4: " 35216",
        level_5: " 377818",
        level_6: " 103891",
        level_7: " 21274",
        level_8: " 12",
        level_9: " 0",
        name: "rearVentAmbientTemperature",
        recent: "46.82 C"
    },
    {
        level_0: " 0",
        level_1: " 742749",
        level_2: " 460016",
        level_3: " 13837",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "rms200BoardTemperature",
        recent: "50.62 C"
    },
    {
        name: "voltageOfCapacitor1",
        recent: "2.308 V"
    },
    {
        name: "voltageOfCapacitor2",
        recent: "2.305 V"
    },
    {
        name: "voltageOfCapacitor3",
        recent: "2.314 V"
    },
    {
        name: "voltageOfCapacitor4",
        recent: "2.307 V"
    },
    {
        level_0: " 175052",

```



```

        level_1: " 51173",
        level_2: " 435788",
        level_3: " 12766",
        level_4: " 4",
        level_5: " 6",
        level_6: " 541813",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "capacitorPackVoltage",
        recent: "9.233 V"
    },
    {
        level_0: " 0",
        level_1: " 0",
        level_2: " 0",
        level_3: " 0",
        level_4: " 0",
        level_5: " 0",
        level_6: " 4",
        level_7: " 1",
        level_8: " 4",
        level_9: " 6",
        name: "capacitorPackVoltageAtEndOfFlushToFlash",
        recent: "5.605 V"
    },
    {
        name: "currentDerivedFromV3V4",
        recent: "0.000 A"
    },
    {
        level_0: " 7",
        level_1: " 4",
        level_2: " 3",
        level_3: " 1",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "derivedEnergy",
        recent: "175 Joules"
    },
    {
        level_0: " 0",
        level_1: " 0",
        level_2: " 0",
        level_3: " 0",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 17",
        level_8: " 19",
        level_9: " 7",
        name: "derivedCapacitanceOfThePack",
        recent: "5.959 F"
    },
    {
        level_0: " 0",
        level_1: " 43",
        level_2: " 0",
        level_3: " 0",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "derivedEsrOfCapacitorPack",
        recent: "0.104 Ohm"
    }

```

```

    },
    {
        level_0: " 0",
        level_1: " 0",
        level_2: " 0",
        level_3: " 0",
        level_4: " 15",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "timeToRunFlushToFlash",
        recent: "22.40 Seconds"
    },
    {
        level_0: " 0",
        level_1: " 0",
        level_2: " 7",
        level_3: " 0",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "timeToRunRestore",
        recent: "20.44 Seconds"
    },
    {
        level_0: " 0",
        level_1: " 1",
        level_2: " 3",
        level_3: " 2",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 1",
        name: "timeToChargeCapacitors",
        recent: "48 Seconds"
    },
    {
        level_0: " 448586",
        level_1: " 2998",
        level_2: " 0",
        level_3: " 0",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name: "correctableBitsInErrorOnReadingAPage"
    },
    {
        level_0: " 2998",
        level_1: " 0",
        level_2: " 0",
        level_3: " 0",
        level_4: " 0",
        level_5: " 0",
        level_6: " 0",
        level_7: " 0",
        level_8: " 0",
        level_9: " 0",
        name:
"correctableBitsInErrorOnReadingTheWorstBchRegionOfAPage"
    },
    {

```

```

        level_0: " 0",
        level_1: " 37",
        level_2: " 280274",
        level_3: " 422999",
        level_4: " 245814",
        level_5: " 242470",
        level_6: " 24447",
        level_7: " 561",
        level_8: " 0",
        level_9: " 0",
        name: "fanInletAmbientTemperature",
        recent: "41.74 C"
    },
    ],
    predictedCapacitanceDepletion: "504328 uF",
    smartCounters: [
        {
            name: "numberOf512ByteBlocksReadFromDdr",
            value: "218284648"
        },
        {
            name: "numberOf512ByteBlocksWrittenToDdr",
            value: "12031567354"
        },
        {
            name: "numberOfHostReadCommands",
            value: "5366315"
        },
        {
            name: "numberOfHostWriteCommands",
            value: "1266099334"
        },
        {
            name: "controllerBusyTimeMinutes",
            value: "0"
        },
        {
            name: "numberOfPowerCycles",
            value: "13"
        },
        {
            name: "powerOnHours",
            value: "1009"
        },
        {
            name: "unsafeShutdowns",
            value: "5"
        },
        {
            name: "mediaErrors",
            value: "0"
        },
        {
            name: "numberOfErrorLogs",
            value: "2"
        }
    ],
    snapshotTime: "2014-03-20 16:43:49"
},
firmware: {
    activeSlotNumber: "2",
    slot1Version: "1e5817bc",
    slot2Version: "1e0d70ac",
    slot3Version: "1e5817bc",
    slot4Version: "1e5817bc"
},
smart: {
    availableSpace: "0%",
    availableSpaceThreshold: "0%",
    controllerBusyTimeMinutes: "0",
    criticalErrorVector: "0x0",

```

```

        mediaErrors: "0",
        numberOf512ByteBlocksRead: "218284648",
        numberOf512ByteBlocksWritten: "12031567354",
        numberOfErrorInfoLogs: "2",
        numberOfHostReadCommands: "5366315",
        numberOfHostWriteCommands: "1266099334",
        numberOfPowerCycles: "13",
        powerOnHours: "1009",
        temperature: "323 Kelvin",
        unsafeShutdowns: "5"
    },
    },
    status: "Warning",
    statusInfo: {
        warning: [
            "excessiveCurrent (2x)"
        ]
    },
    type: "RMS-200"
}
}
}

```

ListActiveNodes

The `ListActiveNodes` method returns a response similar to the following example.

```

{
  "id": 1,
  "result": {
    "nodes": [
      {
        "associatedFServiceID": 0,
        "associatedMasterServiceID": 1,
        "attributes": {},
        "cip": "172.27.21.23",
        "cipi": "Bond10G",
        "fibreChannelTargetPortGroup": null,
        "mip": "172.27.1.23",
        "mipi": "Bond1G",
        "name": "PSN-1-23",
        "nodeID": 1,
        "platformInfo": {
          "chassisType": "R620",
          "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @
2.50GHz",
          "nodeMemoryGB": 72,
          "nodeType": "SF3010"
        },
        "sip": "172.27.21.23",
        "sipi": "Bond10G",
        "softwareVersion": "9.0.0.1298",
        "uuid": "4C4C4544-0056-3810-804E-B5C04F4C5631",
        "virtualNetworks": [
          {
            "address": "10.1.2.4",
            "virtualNetworkID": 1
          },
          {
            "address": "10.2.2.10",
            "virtualNetworkID": 2
          }
        ]
      },
      {
        "associatedFServiceID": 0,
        "associatedMasterServiceID": 4,
        "attributes": {},

```

```

2.50GHz",
    "cip": "172.27.21.24",
    "cipi": "Bond10G",
    "fibreChannelTargetPortGroup": null,
    "mip": "172.27.1.24",
    "mipi": "Bond1G",
    "name": "PSN-1-24",
    "nodeID": 2,
    "platformInfo": {
        "chassisType": "R620",
        "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @
2.50GHz",
        "nodeMemoryGB": 72,
        "nodeType": "SF3010"
    },
    "sip": "172.27.21.24",
    "sipi": "Bond10G",
    "softwareVersion": "9.0.0.1298",
    "uuid": "4C4C4544-0042-4210-804E-C3C04F4C5631",
    "virtualNetworks": [
        {
            "address": "10.1.2.5",
            "virtualNetworkID": 1
        },
        {
            "address": "10.2.2.11",
            "virtualNetworkID": 2
        }
    ]
},
{
    "associatedFServiceID": 0,
    "associatedMasterServiceID": 2,
    "attributes": {},
    "cip": "172.27.21.25",
    "cipi": "Bond10G",
    "fibreChannelTargetPortGroup": null,
    "mip": "172.27.1.25",
    "mipi": "Bond1G",
    "name": "PSN-1-25",
    "nodeID": 3,
    "platformInfo": {
        "chassisType": "R620",
        "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @
2.50GHz",
        "nodeMemoryGB": 72,
        "nodeType": "SF3010"
    },
    "sip": "172.27.21.25",
    "sipi": "Bond10G",
    "softwareVersion": "9.0.0.1298",
    "uuid": "4C4C4544-0053-4210-8051-C6C04F515631",
    "virtualNetworks": [
        {
            "address": "10.1.2.6",
            "virtualNetworkID": 1
        },
        {
            "address": "10.2.2.12",
            "virtualNetworkID": 2
        }
    ]
},
{
    "associatedFServiceID": 0,
    "associatedMasterServiceID": 3,
    "attributes": {},
    "cip": "172.27.21.26",
    "cipi": "Bond10G",
    "fibreChannelTargetPortGroup": null,
    "mip": "172.27.1.26",
    "mipi": "Bond1G",

```

```

        "name": "PSN-1-26",
        "nodeID": 4,
        "platformInfo": {
            "chassisType": "R620",
            "cpuModel": "Intel(R) Xeon(R) CPU E5-2640 0 @
2.50GHz",
            "nodeMemoryGB": 72,
            "nodeType": "SF3010"
        },
        "sip": "172.27.21.26",
        "sipi": "Bond10G",
        "softwareVersion": "9.0.0.1298",
        "uuid": "4C4C4544-0056-3810-804E-B4C04F4C5631",
        "virtualNetworks": [
            {
                "address": "10.1.2.7",
                "virtualNetworkID": 1
            },
            {
                "address": "10.2.2.13",
                "virtualNetworkID": 2
            }
        ]
    }
}

```

ListActiveVolumes

The `ListActiveVolumes` method returns a response similar to the following example.

```

{
    "id": 1,
    "result": {
        "volumes": [
            {
                "access": "readWrite",
                "accountID": 1,
                "attributes": {},
                "blockSize": 4096,
                "createTime": "2016-06-23T14:19:12Z",
                "deleteTime": "",
                "enable512e": false,
                "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo1.1",
                "name": "HulkDemo1",
                "purgeTime": "",
                "qos": {
                    "burstIOPS": 1500,
                    "burstTime": 60,
                    "curve": {
                        "4096": 100,
                        "8192": 160,
                        "16384": 270,
                        "32768": 500,
                        "65536": 1000,
                        "131072": 1950,
                        "262144": 3900,
                        "524288": 7600,
                        "1048576": 15000
                    },
                    "maxIOPS": 1000,
                    "minIOPS": 100
                },
                "scsiEUIDeviceID": "306f746f00000001f47acc0100000000",
                "scsiNAADeviceID": "6f47acc100000000306f746f00000001",
                "sliceCount": 1,
                "status": "active",
            }
        ]
    }
}

```

```

        "totalSize": 53687091200,
        "virtualVolumeID": null,
        "volumeAccessGroups": [
            1
        ],
        "volumeID": 1,
        "volumePairs": []
    },
    {
        "access": "readWrite",
        "accountID": 1,
        "attributes": {},
        "blockSize": 4096,
        "createTime": "2016-06-23T14:19:14Z",
        "deleteTime": "",
        "enable512e": false,
        "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo6.6",
        "name": "HulkDemo6",
        "purgeTime": "",
        "qos": {
            "burstIOPS": 1500,
            "burstTime": 60,
            "curve": {
                "4096": 100,
                "8192": 160,
                "16384": 270,
                "32768": 500,
                "65536": 1000,
                "131072": 1950,
                "262144": 3900,
                "524288": 7600,
                "1048576": 15000
            },
            "maxIOPS": 1000,
            "minIOPS": 100
        },
        "scsiEUIDeviceID": "306f746f000000006f47acc0100000000",
        "scsiNAADeviceID": "6f47acc1000000000306f746f000000006",
        "sliceCount": 1,
        "status": "active",
        "totalSize": 53687091200,
        "virtualVolumeID": null,
        "volumeAccessGroups": [
            1
        ],
        "volumeID": 6,
        "volumePairs": []
    },
    {
        "access": "readWrite",
        "accountID": 1,
        "attributes": {},
        "blockSize": 4096,
        "createTime": "2016-06-23T14:19:14Z",
        "deleteTime": "",
        "enable512e": false,
        "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo7.7",
        "name": "HulkDemo7",
        "purgeTime": "",
        "qos": {
            "burstIOPS": 1500,
            "burstTime": 60,
            "curve": {
                "4096": 100,
                "8192": 160,
                "16384": 270,
                "32768": 500,
                "65536": 1000,
                "131072": 1950,
                "262144": 3900,
                "524288": 7600,
            }
        }
    }

```

```

        "1048576": 15000
    },
    "maxIOPS": 1000,
    "minIOPS": 100
},
"scsiEUIDeviceID": "306f746f00000007f47acc0100000000",
"scsiNAADeviceID": "6f47acc100000000306f746f00000007",
"sliceCount": 1,
"status": "active",
"totalSize": 53687091200,
"virtualVolumeID": null,
"volumeAccessGroups": [
    1
],
"volumeID": 7,
"volumePairs": []
},
{
    "access": "readWrite",
    "accountID": 1,
    "attributes": {},
    "blockSize": 4096,
    "createTime": "2016-06-23T14:19:15Z",
    "deleteTime": "",
    "enable512e": false,
    "ign": "ign.2010-01.com.solidfire:0oto.hulkdemo8.8",
    "name": "HulkDemo8",
    "purgeTime": "",
    "qos": {
        "burstIOPS": 1500,
        "burstTime": 60,
        "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
        },
        "maxIOPS": 1000,
        "minIOPS": 100
    },
    "scsiEUIDeviceID": "306f746f00000008f47acc0100000000",
    "scsiNAADeviceID": "6f47acc100000000306f746f00000008",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 53687091200,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
        1
    ],
    "volumeID": 8,
    "volumePairs": []
},
{
    "access": "readWrite",
    "accountID": 1,
    "attributes": {},
    "blockSize": 4096,
    "createTime": "2016-06-23T14:19:15Z",
    "deleteTime": "",
    "enable512e": false,
    "ign": "ign.2010-01.com.solidfire:0oto.hulkdemo9.9",
    "name": "HulkDemo9",
    "purgeTime": "",
    "qos": {
        "burstIOPS": 1500,
        "burstTime": 60,

```



```

        "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
        },
        "maxIOPS": 1000,
        "minIOPS": 100
    },
    "scsiEUIDeviceID": "306f746f00000009f47acc0100000000",
    "scsiNAADeviceID": "6f47acc100000000306f746f00000009",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 53687091200,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
        1
    ],
    "volumeID": 9,
    "volumePairs": []
},
{
    "access": "readWrite",
    "accountID": 1,
    "attributes": {},
    "blockSize": 4096,
    "createTime": "2016-06-23T14:19:16Z",
    "deleteTime": "",
    "enable512e": false,
    "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo12.12",
    "name": "HulkDemo12",
    "purgeTime": "",
    "qos": {
        "burstIOPS": 1500,
        "burstTime": 60,
        "curve": {
            "4096": 100,
            "8192": 160,
            "16384": 270,
            "32768": 500,
            "65536": 1000,
            "131072": 1950,
            "262144": 3900,
            "524288": 7600,
            "1048576": 15000
        },
        "maxIOPS": 1000,
        "minIOPS": 100
    },
    "scsiEUIDeviceID": "306f746f00000000cf47acc0100000000",
    "scsiNAADeviceID": "6f47acc100000000306f746f00000000c",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 53687091200,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
        1
    ],
    "volumeID": 12,
    "volumePairs": []
},
{
    "access": "readWrite",
    "accountID": 1,
    "attributes": {},
    "blockSize": 4096,

```

```

    "createTime": "2016-06-23T14:19:18Z",
    "deleteTime": "",
    "enable512e": false,
    "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo16.16",
    "name": "HulkDemo16",
    "purgeTime": "",
    "qos": {
      "burstIOPS": 1500,
      "burstTime": 60,
      "curve": {
        "4096": 100,
        "8192": 160,
        "16384": 270,
        "32768": 500,
        "65536": 1000,
        "131072": 1950,
        "262144": 3900,
        "524288": 7600,
        "1048576": 15000
      },
      "maxIOPS": 1000,
      "minIOPS": 100
    },
    "scsiEUIDeviceID": "306f746f00000010f47acc0100000000",
    "scsiNAADeviceID": "6f47acc100000000306f746f00000010",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 53687091200,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
      1
    ],
    "volumeID": 16,
    "volumePairs": []
  },
  {
    "access": "readWrite",
    "accountID": 1,
    "attributes": {},
    "blockSize": 4096,
    "createTime": "2016-06-23T14:19:18Z",
    "deleteTime": "",
    "enable512e": false,
    "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo17.17",
    "name": "HulkDemo17",
    "purgeTime": "",
    "qos": {
      "burstIOPS": 1500,
      "burstTime": 60,
      "curve": {
        "4096": 100,
        "8192": 160,
        "16384": 270,
        "32768": 500,
        "65536": 1000,
        "131072": 1950,
        "262144": 3900,
        "524288": 7600,
        "1048576": 15000
      },
      "maxIOPS": 1000,
      "minIOPS": 100
    },
    "scsiEUIDeviceID": "306f746f00000011f47acc0100000000",
    "scsiNAADeviceID": "6f47acc100000000306f746f00000011",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 53687091200,
    "virtualVolumeID": null,
    "volumeAccessGroups": [
      1
    ]
  }
}

```

```

],
"volumeID": 17,
"volumePairs": []
},
{
  "access": "readWrite",
  "accountID": 1,
  "attributes": {},
  "blockSize": 4096,
  "createTime": "2016-06-23T14:19:18Z",
  "deleteTime": "",
  "enable512e": false,
  "iqn": "iqn.2010-01.com.solidfire:0oto.hulkdemo18.18",
  "name": "HulkDemo18",
  "purgeTime": "",
  "qos": {
    "burstIOPS": 1500,
    "burstTime": 60,
    "curve": {
      "4096": 100,
      "8192": 160,
      "16384": 270,
      "32768": 500,
      "65536": 1000,
      "131072": 1950,
      "262144": 3900,
      "524288": 7600,
      "1048576": 15000
    },
    "maxIOPS": 1000,
    "minIOPS": 100
  },
  "scsiEUIDeviceID": "306f746f00000012f47acc0100000000",
  "scsiNAADeviceID": "6f47acc100000000306f746f00000012",
  "sliceCount": 1,
  "status": "active",
  "totalSize": 53687091200,
  "virtualVolumeID": null,
  "volumeAccessGroups": [
    1
  ],
  "volumeID": 18,
  "volumePairs": []
},
{
  "access": "readWrite",
  "accountID": 1,
  "attributes": {},
  "blockSize": 4096,
  "createTime": "2016-06-24T15:21:59Z",
  "deleteTime": "",
  "enable512e": true,
  "iqn": "iqn.2010-01.com.solidfire:0oto.bk.24",
  "name": "BK",
  "purgeTime": "",
  "qos": {
    "burstIOPS": 15000,
    "burstTime": 60,
    "curve": {
      "4096": 100,
      "8192": 160,
      "16384": 270,
      "32768": 500,
      "65536": 1000,
      "131072": 1950,
      "262144": 3900,
      "524288": 7600,
      "1048576": 15000
    },
    "maxIOPS": 15000,
    "minIOPS": 50
  }
}

```

```

    },
    "scsiEUIDeviceID": "306f746f00000018f47acc0100000000",
    "scsiNAADeviceID": "6f47acc100000000306f746f00000018",
    "sliceCount": 1,
    "status": "active",
    "totalSize": 10737418240,
    "virtualVolumeID": null,
    "volumeAccessGroups": [],
    "volumeID": 24,
    "volumePairs": [
      {
        "clusterPairID": 2,
        "remoteReplication": {
          "mode": "Async",
          "pauseLimit": 3145728000,
          "remoteServiceID": 14,
          "resumeDetails": "",
          "snapshotReplication": {
            "state": "Idle",
            "stateDetails": ""
          },
          "state": "Active",
          "stateDetails": ""
        },
        "remoteSliceID": 8,
        "remoteVolumeID": 8,
        "remoteVolumeName": "PairingDoc",
        "volumePairUUID": "229fcfb3-2d35-4625-865a-
d04bb9455cef"
      }
    ]
  }
}

```

TestHardwareConfig

The TestHardwareConfig method returns a response similar to the following example.

```

{
  "id": 1,
  "result": {
    "details": {
      "BIOS_REVISION": {
        "Passed": true,
        "actual": "11",
        "comparator": ">=",
        "expected": "10"
      },
      "BIOS_VERSION": {
        "Passed": true,
        "actual": "112",
        "comparator": ">=",
        "expected": "104"
      },
      "BMC_FIRMWARE_REVISION": {
        "Passed": true,
        "actual": "16",
        "comparator": ">=",
        "expected": "10"
      },
      "BMC_IPMI_VERSION": {
        "Passed": true,
        "actual": "20",
        "comparator": ">=",
        "expected": "20"
      }
    }
  }
}

```

```

"CPU": {
  "Passed": true,
  "actual": "Intel(R) Xeon(R) CPU E5-2640 0 @ 250GHz",
  "comparator": "==",
  "expected": "Intel(R) Xeon(R) CPU E5-2640 0 @ 250GHz"
},
"CPU_CORES": {
  "Passed": true,
  "actual": "6",
  "comparator": "==",
  "expected": "6"
},
"CPU_CORES_ENABLED": {
  "Passed": true,
  "actual": "6",
  "comparator": "==",
  "expected": "6"
},
"CPU_THREADS": {
  "Passed": true,
  "actual": "12",
  "comparator": "==",
  "expected": "12"
},
"DRIVES_SIZE": {
  "Passed": true,
  "actual": "300069052416",
  "comparator": "==",
  "expected": "300069052416"
},
"LSI_VERSION": {
  "Passed": true,
  "actual": "13005700",
  "comparator": ">=",
  "expected": "13005700"
},
"MARVELL_BOARD_REV": {
  "Passed": true,
  "actual": "34",
  "comparator": ">=",
  "expected": "33"
},
"MARVELL_DDR_CONFIG": {
  "Passed": true,
  "actual": "9",
  "comparator": ">=",
  "expected": "9"
},
"MARVELL_DRIVER": {
  "Passed": true,
  "actual": "171",
  "comparator": ">=",
  "expected": "170"
},
"MARVELL_EEPROM": {
  "Passed": true,
  "actual": "13",
  "comparator": ">=",
  "expected": "13"
},
"MARVELL_FIRMWARE": {
  "Passed": true,
  "actual": "170",
  "comparator": ">=",
  "expected": "170"
},
"MARVELL_SSD_FIRMWARE": {
  "Passed": true,
  "actual": "3F0VGWAM",
  "comparator": ">=",
  "expected": "3F0VGWAM"
}

```

```

    },
    "MEMORY_BYTES": {
      "Passed": true,
      "actual": "154618822656",
      "comparator": "==",
      "expected": "154618822656"
    },
    "MEMORY_HZ": {
      "Passed": true,
      "actual": "1333000000",
      "comparator": "==",
      "expected": "1333000000"
    },
    "NETWORK_VENDOR_MATCHES": {
      "Passed": true,
      "actual": "4",
      "comparator": "==",
      "expected": "4"
    },
    "NUM_CPU": {
      "Passed": true,
      "actual": "2",
      "comparator": "==",
      "expected": "2"
    },
    "NUM_DRIVES": {
      "Passed": true,
      "actual": "10",
      "comparator": "==",
      "expected": "10"
    },
    "NUM_MEMORY_BANKS": {
      "Passed": true,
      "actual": "24",
      "comparator": "==",
      "expected": "24"
    },
    "NUM_MEMORY_BANKS_USED": {
      "Passed": true,
      "actual": "12",
      "comparator": "==",
      "expected": "12"
    },
    "NVRAM_VENDOR": {
      "Passed": true,
      "actual": "Marvell Technology Group Ltd",
      "comparator": "==",
      "expected": "Marvell Technology Group Ltd"
    },
    "PLATFORM": "R620",
    "ROOT_DISK_REMOVABLE": {
      "Passed": true,
      "actual": "",
      "comparator": "==",
      "expected": ""
    },
    "ROOT_DISK_SLOT": {
      "Passed": true,
      "actual": "0",
      "comparator": "==",
      "expected": "0"
    },
    "SAS_DRIVER": {
      "Passed": true,
      "actual": "mpt2sas",
      "comparator": "==",
      "expected": "mpt2sas"
    },
    "SAS_VENDOR": {
      "Passed": true,
      "actual": "LSI Logic \\/ Symbios Logic",

```

```
        "comparator": "==",
        "expected": "LSI Logic \\/ Symbios Logic"
    },
    "SSD_VERSION": {
        "Passed": true,
        "actual": "0362",
        "comparator": ">=",
        "expected": "0362"
    }
},
"duration": "24.6398sec",
"result": "Passed"
}
```

Contacting NetApp Support

If you need help with or have questions or comments about NetApp products, contact NetApp Support.

- Web: mysupport.netapp.com
- Phone:
 - 888.4.NETAPP (888.463.8277) (US and Canada)
 - 00.800.44.638277 (EMEA/Europe)
 - +800.800.80.800 (Asia/Pacific)

Copyright

Copyright © 2019 NetApp, Inc. All rights reserved. Printed in the U.S.

No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

Data contained herein pertains to a commercial item (as defined in FAR 2.101) and is proprietary to NetApp, Inc. The U.S. Government has a non-exclusive, non-transferrable, non-sublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b).

Trademark

NETAPP, the NETAPP logo, and the marks listed on the NetApp Trademarks page are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.

<http://www.netapp.com/us/legal/netapptmlist.aspx>

How to send comments about documentation and receive update notifications

You can help us to improve the quality of our documentation by sending us your feedback. You can receive automatic notification when production-level (GA/FCS) documentation is initially released or important changes are made to existing production-level documents.

If you have suggestions for improving this document, send us your comments by email.

doccomments@netapp.com

To help us direct your comments to the correct division, include in the subject line the product name, version, and operating system.

If you want to be notified automatically when production-level documentation is released or important changes are made to existing production-level documents, follow Twitter account @NetAppDoc.

You can also contact us in the following ways:

- NetApp, Inc., 1395 Crossman Ave., Sunnyvale, CA 94089 U.S.
- Telephone: +1 (408) 822-6000
- Fax: +1 (408) 822-4501
- Support telephone: +1 (888) 463-8277

Index

A

- access types
 - methods available for [468](#)
- account [16](#)
- account methods [101](#)
- account object [16](#)
- accounts
 - adding [101](#)
 - getting by ID [102](#)
 - getting by username [103](#)
 - getting efficiency statistics for [104](#)
 - listing all [106](#)
 - modifying settings on [107](#)
 - removing [109](#)
- active paired volumes
 - listing [250](#)
- active volumes
 - getting list of [359](#)
- API authentication [14](#)
- API methods
 - administration APIs [110](#)
 - asynchronous [14](#)
 - cluster creation APIs [163](#)
 - configuring LDAP APIs [185](#)
 - configuring nodes APIs [192](#)
 - Fibre Channel nodes APIs [177](#)
 - managing account APIs [101](#)
 - managing cluster APIs [118](#)
 - managing drives APIs [168](#)
 - managing ONTAP relationships [258](#)
 - managing snapshots APIs [413](#)
 - managing volumes APIs [323](#)
 - pairing volume APIs [246](#)
 - returning a list of [89](#)
 - system configuration APIs [280](#)
 - virtual networking APIs [314](#)
 - virtual volume APIs [446](#)
- asynchronous methods [14](#)
- asynchronous results
 - getting [94, 99](#)
- authentication
 - setting login session timeout [160](#)

B

- backup targets
 - deleting [400](#)
 - getting information about [351, 360](#)
 - modifying [382](#)
 - removing [400](#)
- bulk operations
 - getting information about [361](#)
- bulk read operations
 - getting information about [361](#)
- bulk volume jobs
 - updating status of [410](#)
- bulk write operations
 - getting information about [361](#)

C

- certificate
 - getting details from [18](#)
- cloning multiple volumes
 - stopping [327](#)
- cloning volumes [330](#)
- cluster
 - creating new [164](#)
 - getting Element version [134](#)
 - getting feature status [136](#)
 - getting fullness level [127](#)
 - getting information about [131](#)
 - getting information from bootstrap configuration [166](#)
 - getting login session information [138](#)
 - getting statistics [133](#)
 - initializing a cluster [164](#)
 - listing active nodes [141](#)
 - listing all drives [173](#)
 - listing cluster events [145](#)
 - listing cluster faults [143](#)
 - listing nodes [141](#)
 - listing pending nodes [151](#)
 - listing PendingActive nodes [153](#)
 - listing specific drives [173](#)
 - removing drives [174](#)
 - restarting nodes [161](#)
 - shutting down nodes [161](#)
 - testing [237](#)
- cluster admin
 - adding [110](#)
 - modifying settings [114](#)
- Cluster Admin
 - Getting information about [111](#)
 - listing [113](#)
 - removing [115](#)
- cluster capacity
 - compression efficiency rates [125](#)
 - deduplication efficiency rates [125](#)
 - getting measurements [125](#)
 - overall efficiency rates [125](#)
 - thin provisioning efficiency rates [125](#)
- cluster configuration
 - getting [198](#)
 - setting [224](#)
- cluster creation
 - checking proposed nodes before [163](#)
- cluster fault codes [461](#)
- cluster faults
 - clearing [120](#)
- cluster hardware
 - getting information about [130](#)
- cluster interface preferences
 - creating [121](#)
 - deleting [121](#)
 - getting information about [132](#)
 - listing [144](#)
 - modifying [159](#)
- cluster master node

- getting ID [133](#)
- cluster methods [118](#)
- cluster pair
 - removing [253](#)
- cluster pairing
 - completing [247](#)
 - starting [254](#)
- cluster pairs
 - listing [249](#)
- cluster state
 - getting [199](#)
- cluster statistics
 - getting [133](#)
- cluster support bundle
 - creating [193](#)
- clusters
 - adding virtual network to [314](#)
 - pairing [246](#)
 - removing a pair [253](#)
- comments
 - how to send feedback about documentation [531](#)
- common methods [89](#)
- common objects [16](#)
- configuration
 - setting [225](#)
- connectivity [229](#)
- creating backup target information [341](#)
- creating initiators [342](#)
- creating volume access groups [339](#)
- creating World Wide Port Names [342](#)
- creating WWPNs [342](#)
- currently active SSL certificate
 - retrieving for a cluster [296](#)
 - retrieving for a node [294](#)

D

- deleting initiators [344](#)
- documentation
 - how to receive automatic notification of changes to [531](#)
 - how to send feedback about [531](#)
- drive API methods [168](#)
- drive configuration
 - getting [201](#)
- drive hardware
 - listing [217](#)
- drive information [201](#)
- drives
 - adding to cluster [168](#)
 - getting hardware information [169](#)
 - getting statistics [170](#)
 - listing [172](#)
 - removing data [221](#)
 - resetting [221](#)
 - resetting encryption key [175](#)
 - secure erasing [175](#)
 - testing [234](#)
 - validating hardware [234](#)

E

- encryption
 - disabling [122](#)
 - enabling [123](#)
- ensemble [229](#), [312](#)

F

- fault [32](#)
- feedback
 - how to send comments about documentation [531](#)
- Fibre Channel API methods [177](#)
- Fibre Channel ports
 - listing [178](#)
- Fibre Channel ports on a node
 - listing [181](#)
- Fibre Channel sessions
 - listing [180](#)

G

- getting for a single node [214](#)

H

- hardware sensor information
 - getting [205](#)
 - reporting [208](#)

I

- information
 - how to send feedback about improving documentation [531](#)
- initiators
 - adding to volume access group [323](#)
 - creating [342](#)
 - deleting [344](#)
 - getting list of [364](#)
 - modifying [383](#)
- IP address availability [312](#)
- IQNs
 - getting list of [364](#)
- iSCSI connection
 - listing information about [149](#)

L

- LDAP [185](#)
- LDAP API methods [185](#)
- LDAP authentication
 - disabling [189](#)
 - enabling [186](#)
 - testing [190](#)
- LDAP cluster admin
 - adding [185](#)
- LDAP configuration
 - getting [189](#)
- listing active volumes [375](#)
- listing pending volumes [375](#)

- LLDP configuration for a storage cluster
 - getting information about [286](#)
- LLDP info for individual storage nodes
 - getting information about [287](#)
- local connectivity
 - testing [238](#)

M

- management connection
 - testing [230](#)
 - using MVIP to test [230](#)
- multitenant networking API methods
 - prerequisites [314](#)

N

- NetApp Support
 - contacting [528](#)
- network configuration
 - getting [211](#)
 - resetting to factory defaults [300](#)
 - setting [227](#)
 - testing [239](#)
- network interface [215](#)
- network interfaces
 - listing [215](#)
- node
 - adding to a cluster [118](#)
 - getting configuration information [200](#)
 - getting hardware configuration [202](#)
 - getting hardware information [204](#)
 - getting information from bootstrap configuration [166](#)
 - getting statistics [140](#)
 - listing statistics [148](#)
 - performing hardware tests [235](#)
 - resetting to factory settings [220](#)
 - restarting [228](#)
 - restarting networking services [222](#)
 - restarting services [223](#)
 - setting cluster configuration [224](#)
 - setting configuration [225](#)
 - setting network configuration [227](#)
 - shutting down [228](#)
- node API methods [192](#)
- node hardware
 - getting information about [139](#)
- nodes
 - getting network interface information [211](#)
- NTP [287](#)
- NTP information
 - getting [287](#)
 - setting [304](#)
- NVRAM [288](#)
- NVRAM information
 - getting [288](#)
- cluster [19](#)
- ClusterAdmin [20](#)
- clusterCapacity [21](#)
- clusterInfo [22](#)
- clusterPair [24](#)
- clusterStats [24](#)
- clusterStructure [27](#)
- drive [27](#)
- driveStats [29](#)
- error [30](#)
- event [30](#)
- fibreChannelPort [33](#)
- fipsErrorNodeReport [34](#)
- fipsNodeReport [35](#)
- fipsReport [35](#)
- groupSnapshot [35](#)
- hardwareInfo [36](#)
- host (virtual volumes) [37](#), [38](#)
- ldapConfiguration [38](#)
- loggingServer [39](#)
- network (all interfaces) [43](#)
- network (bonded interfaces) [40](#)
- network (Ethernet interfaces) [43](#)
- network (local interfaces) [45](#)
- network (SNMP) [46](#)
- networkInterface [46](#)
- node [47](#)
- nodeStats [48](#)
- ontapVersionInfo [49](#)
- pendingActiveNode [50](#)
- pendingNode [51](#)
- protectionDomainResiliency [53](#)
- protectionDomainTolerance [53](#)
- protectionSchemeResiliency [54](#)
- protectionSchemeTolerance [54](#)
- protocolEndpoint [55](#)
- QoS (Quality of Service) [56](#)
- QoSPolicy (Quality of Service) [56](#)
- schedule [57](#)
- session (Fibre Channel) [59](#)
- session (iSCSI) [59](#)
- snapMirrorClusterIdentity [61](#)
- snapMirrorEndpoint [62](#)
- snapMirrorJobScheduleCronInfo [62](#)
- snapMirrorLunInfo [63](#)
- snapMirrorNetworkInterface [63](#)
- snapMirrorNode [64](#)
- snapMirrorPolicy [65](#)
- snapMirrorPolicyRule [66](#)
- snapMirrorRelationship [66](#)
- snapMirrorVolume [61](#), [69](#)
- snapMirrorVolumeInfo [70](#)
- snapMirrorVserver [70](#)
- snapMirrorVserverAggregateInfo [71](#)
- snapshot [72](#)
- snmpTrapRecipient [74](#)
- storageContainer [74](#)
- syncJob [75](#)
- task (virtual volumes) [76](#)
- usmUser [78](#)
- virtualNetwork [78](#)
- virtualVolume [79](#)
- volume [80](#)

O

- objects
 - binding (virtual volumes) [18](#)
 - bulkVolumeJob [17](#)

- volumeAccessGroup [83](#)
- volumePair [84](#)
- volumeStats [85](#)
- ONTAP API version support
 - getting information about [265](#)
- order of operations [246](#)
- origin certificate
 - getting [98](#)

P

- paired volumes [250](#)
- pending operation
 - getting [214](#)
- ping
 - testing [241](#)
- private key
 - setting for the cluster [310](#)
 - setting for the management node [302](#)
- proposed storage node additions
 - checking [192](#)
- protection domain levels
 - listing [297](#)
- protection domains [52](#), [297](#)
- protocol endpoints [450](#)
- purging a deleted volume [398](#)
- purging multiple deleted volumes [399](#)

Q

- QoS
 - configuring default values [405](#)
- QoS object [14](#)
- QoS policies
 - creating [334](#)
 - deleting [345](#)
 - getting information about [355](#)
 - listing [365](#)
 - modifying [385](#)
- QoS policy [56](#)
- QoS usage
 - generating a histogram for [368](#)
- QoS values
 - configuring the default [405](#)
 - getting default values [354](#)
- Quality of Service [14](#)
- Quality of Service (QoS) [56](#)

R

- remote connectivity
 - testing [243](#)
- remote logging hosts
 - getting [289](#)
 - setting [305](#)
- replication [246](#)
- replication API methods [246](#)
- Request endpoints [13](#)
- Request object members [12](#)
- resiliency [52](#)
- response examples
 - GetClusterHardwareInfo [473](#)

- GetConfig [472](#)
- GetLldpInfo [482](#)
- GetNetworkConfig [501](#)
- GetNodeHardwareInfo (output for Fibre Channel nodes) [505](#)
- GetNodeHardwareInfo (output for iSCSI) [504](#)
- GetNvramInfo [510](#)
- ListActiveNodes [516](#)
- ListActiveVolumes [518](#)
- TestHardwareConfig [524](#)
- Response object members [13](#)
- restarting services [223](#)

S

- security [18](#)
- services
 - restarting [223](#)
- SnapMirror aggregates
 - listing [267](#)
- SnapMirror API methods [258](#)
- SnapMirror cluster identity
 - getting information about [265](#)
- SnapMirror endpoints
 - creating relationships with [260](#), [263](#), [271](#)
 - deleting [264](#)
 - listing [267](#)
 - modifying settings [274](#)
- SnapMirror interfaces
 - listing [268](#)
- SnapMirror LUNs
 - listing [268](#)
- SnapMirror nodes
 - getting information about [269](#)
- SnapMirror policies
 - listing [270](#)
- SnapMirror relationships
 - aborting [258](#)
 - breaking [258](#)
 - creating [261](#)
 - deleting [264](#)
 - initializing [266](#)
 - modifying [275](#)
 - quiescing [277](#)
 - resuming [278](#)
 - resuming quiesced [278](#)
 - resyncing [278](#)
 - stopping incomplete data transfers for [258](#)
 - updating the destination volume in [276](#)
- SnapMirror schedules
 - getting information about [270](#)
- SnapMirror volumes
 - breaking a relationship [259](#)
 - listing [272](#)
- SnapMirror Vservers
 - listing [273](#)
- snapshot schedules
 - getting information about [427](#)
- snapshots
 - changing interval [435](#)
 - creating [423](#)
 - creating for volume group [413](#)
 - creating new from existing [443](#)

- deleting [426](#)
- deleting multiple [425](#)
- deleting schedule [435](#)
- getting information about [428](#)
- listing attributes of [431](#)
- listing information about [428](#), [430](#)
- modifying attributes [433](#), [439](#)
- modifying schedule [435](#)
- overview [413](#)
- pausing schedule [435](#)
- rolling back volumes [441](#)
- scheduling automatic [416](#)
- SNMP
 - disabling [281](#)
 - enabling [124](#), [282](#)
- SNMP ACL
 - getting [290](#)
 - setting [306](#)
- SNMP functionality
 - testing [312](#)
- SNMP information
 - getting [291](#), [307](#)
- SNMP state
 - getting [292](#)
- SNMP trap information
 - getting [293](#)
 - setting [309](#)
- SolidFire API
 - authentication [14](#)
 - overview [12](#)
- SSH
 - disabling for a single node [197](#)
 - disabling for the entire cluster [280](#)
 - enabling for a single node [198](#)
 - enabling for the entire cluster [281](#)
- SSH service status
 - getting for the entire cluster [283](#)
- SSH status [214](#)
- SSL [18](#), [294](#), [296](#), [299](#), [302](#), [310](#)
- SSL certificate
 - removing for the cluster [299](#)
 - removing for the management node [299](#)
 - retrieving [294](#), [296](#)
 - setting for the cluster [310](#)
 - setting for the management node [302](#)
- storage cluster
 - listing services [150](#)
- storage cluster configuration information
 - backing up [284](#)
 - restoring [300](#)
- storage cluster FIPS 140-2 feature support
 - getting information on [285](#)
- storage connection
 - testing [232](#)
 - using SVIP to test [232](#)
- storage systems
 - naming conventions [314](#)
- suggestions
 - how to send feedback about documentation [531](#)
- support bundle
 - creating [195](#)
 - deleting [196](#)
- support bundles [120](#)

- supported replication modes [247](#)
- synchronization jobs
 - getting information about [366](#)
- system configuration [280](#)
- system configuration methods [280](#)
- system limits
 - getting information about [96](#)

T

- Terms of Use banner
 - configuring [116](#), [301](#)
 - getting the status of [112](#)
- test SNMP traps [312](#)
- test traps
 - sending [312](#)
- testing [229](#), [312](#)
- tests
 - listing [218](#)
- tolerance [52](#)
- Twitter
 - how to receive automatic notification of documentation changes [531](#)

U

- unmanaged SnapMirror endpoints
 - creating relationships with [261](#)
 - modifying [275](#)
- utilities
 - listing [219](#)

V

- virtual networks
 - adding to cluster [314](#)
 - listing [319](#)
 - modifying existing [317](#)
 - removing [321](#)
- virtual volume API methods [446](#)
- virtual volume bindings
 - to protocol endpoints [453](#)
- virtual volume hosts
 - known to a cluster [454](#), [457](#)
- virtual volume storage containers
 - creating [446](#)
 - deleting [447](#)
 - efficiency information for [448](#)
 - modifying [459](#)
- virtual volumes
 - bound to protocol endpoints [453](#)
 - list of [455](#)
 - retrieving how many [449](#)
- virtual volumes in a cluster [453](#)
- volume access groups
 - creating [339](#)
 - deleting [350](#)
 - getting efficiency information [356](#)
 - getting information about [374](#)
 - getting LUN mapping [177](#)
 - modifying [154](#), [396](#)
 - removing initiators from [401](#)

- removing volumes from [154, 396, 403](#)
 - updating initiators from [154, 396](#)
- volume activity information
 - listing [377](#)
- volume API methods [323](#)
- volume clone
 - stopping [326](#)
- volume copy
 - stopping [326](#)
- volume pair
 - modifying [251](#)
 - removing [159, 254](#)
- volume pairing
 - completing [248](#)
 - starting [255](#)
- volume read sessions
 - starting [407](#)
- volume snapshot API methods [413](#)
- volume write sessions
 - starting [409](#)
- volumes
 - adding to volume access group [325](#)
 - cloning [327, 330](#)
 - creating [336](#)
 - creating group snapshots of [413](#)
 - creating snapshots of [423](#)
 - defining LUN assignments for [183](#)
 - deleting [346](#)
 - deleting group snapshots of [425](#)
 - deleting multiple [348](#)
 - getting a list of [369](#)
 - getting activity information [372, 378](#)
 - getting activity measurements [352](#)
 - getting default QoS values for [354](#)

- getting information about [358](#)
 - getting the count [356](#)
 - listing active [375](#)
 - listing activity by volume [379](#)
 - listing activity by volume access group [381](#)
 - listing activity information [379, 381](#)
 - listing pending [375](#)
 - marked for deletion [362](#)
 - modifying [391](#)
 - modifying settings on [387](#)
 - overwriting data [333](#)
 - pairing [246](#)
 - purging multiple [399](#)
 - purging single [398](#)
 - removing a pair [254](#)
 - restoring deleted [405](#)
 - scheduling automatic snapshots of [416](#)
 - starting read session [407](#)
 - starting write session [409](#)
 - stopping clone process [326](#)
 - stopping copy process [326](#)
 - stopping group cloning process [327](#)
- VVol storage containers
 - creating [446](#)
 - deleting [447](#)
 - efficiency information for [448](#)
 - modifying [459](#)

W

- WWPNs
 - getting list of [364](#)